



CLI Configuration Guide for Cisco Unified SIP Proxy Release 10.2

August 27, 2020

Cisco Systems, Inc.
www.cisco.com

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The following information is for FCC compliance of Class A devices: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio-frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to correct the interference at their own expense.

The following information is for FCC compliance of Class B devices: The equipment described in this manual generates and may radiate radio-frequency energy. If it is not installed in accordance with Cisco's installation instructions, it may cause interference with radio and television reception. This equipment has been tested and found to comply with the limits for a Class B digital device in accordance with the specifications in part 15 of the FCC rules. These specifications are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation.

Modifying the equipment without Cisco's written authorization may result in the equipment no longer complying with FCC requirements for Class A or Class B digital devices. In that event, your right to use the equipment may be limited by FCC regulations, and you may be required to correct any interference to radio or television communications at your own expense.

You can determine whether your equipment is causing interference by turning it off. If the interference stops, it was probably caused by the Cisco equipment or one of its peripheral devices. If the equipment causes interference to radio or television reception, try to correct the interference by using one or more of the following measures:

- Turn the television or radio antenna until the interference stops.
- Move the equipment to one side or the other of the television or radio.
- Move the equipment farther away from the television or radio.
- Plug the equipment into an outlet that is on a different circuit from the television or radio. (That is, make certain the equipment and the television or radio are on circuits controlled by different circuit breakers or fuses.)

Modifications to this product not authorized by Cisco Systems, Inc. could void the FCC approval and negate your authority to operate the product.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

CLI Configuration Guide for Cisco Unified SIP Proxy Release 10.2

© 2022 Cisco Systems, Inc. All rights reserved.



Overview of Cisco Unified SIP Proxy Release 10.2 1-1

- About This Document 1-1
- Administration Interfaces 1-1
 - Command-Line Interface 1-1
 - Graphical User Interface 1-2
- Commercial Open Source Licensing 1-2
- Obtaining Documentation and Submitting a Service Request 1-2
- Technical Assistance 1-2

Initial Configuration Tasks 1-1

- Configuring SNMP MIB 1-1
 - About SNMP MIB Support 1-1
 - Definitions 1-2
 - Prerequisites 1-2
 - Restrictions 1-3
 - Structure 1-3
 - Cisco Unified SIP Proxy SNMP MIBs 1-3
 - MIB Objects 1-4
 - cuspscalar 1-4
 - cusptable 1-7
 - cuspsnotifcontrollinfo 1-8
 - MIB Notifications (Traps) 1-9
 - Configuring Community String 1-12
 - Summary Steps 1-13
 - Detailed Steps 1-13
 - Example 1-13
 - Configuring SNMP Traps 1-13
 - Summary Steps 1-13
 - Detailed Steps 1-14
 - Example 1-14
 - Configuring CPU Threshold Values for Traps 1-15
 - Summary Steps 1-15
 - Detailed Steps 1-15
 - Example 1-15

Configuring Smart Licensing	1-15
About Smart Licensing	1-16
Summary Steps	1-16
Detailed Steps	1-17
Example	1-17
Setting Backup Parameters	1-18
About Backup Parameters	1-18
Prerequisites	1-18
Summary Steps	1-18
Detailed Steps	1-19
Example	1-19
Configuring NTP Servers	1-20
Adding NTP Servers	1-20
About Adding NTP Servers	1-20
Summary Steps	1-20
Detailed Steps	1-21
Examples of Adding NTP Servers	1-21
Removing an NTP Server	1-22
Summary Steps	1-22
Detailed Steps	1-22
Displaying NTP Server Information	1-23
Commands to Display NTP Server Information	1-23
Examples of Showing NTP Server Information	1-23
Setting the Time Zone	1-24
Example of Setting the Time Zone	1-24
Configuring Sub-interfaces	1-25
Summary Steps	1-25
Detailed Steps	1-26
Example	1-26
Configuring the Cisco Unified SIP Proxy	1-1
Configuring Logical Networks	1-1
Summary Steps	1-1
Detailed Steps	1-2
Example	1-2
Configuring Trigger Conditions	1-2
Summary Steps	1-2
Detailed Steps	1-3
Example	1-4

Configuring Server Groups	1-4
About Server Groups	1-4
Summary Steps	1-5
Detailed Steps	1-5
Example	1-6
Configuring Route Tables	1-6
About Route Tables	1-6
Summary Steps	1-6
Detailed Steps	1-7
Example	1-7
Configuring Normalization Policies	1-8
Summary Steps	1-8
Detailed Steps	1-8
Example	1-9
Configuring Lookup Policies	1-9
Summary Steps	1-9
Detailed Steps	1-10
Example	1-10
Configuring Routing Triggers	1-11
Summary Steps	1-11
Detailed Steps	1-11
Example	1-12
Configuring Normalization Triggers	1-12
Summary Steps	1-12
Detailed Steps	1-12
Example	1-13
Configuring Listen and Record-Route Ports	1-13
Summary Steps	1-13
Detailed Steps	1-14
Example	1-14
Configuring a Hostname	1-14
Summary Steps	1-14
Detailed Steps	1-15
Example	1-15
Configuring Transport Layer Security (TLS)	1-15
Creating and Importing a Signed Certificate	1-15
Prerequisites	1-16
Summary Steps	1-16
Detailed Steps	1-16

Example of Creating a Signed Certificate	1-17
Creating and Importing a Self-Signed Certificate	1-18
Summary Steps	1-18
Detailed Steps	1-19
Example	1-21
Updating Web Session with an Imported Signed Certificate	1-22
Summary Steps	1-22
Detailed Steps	1-22
Example of Updating Web Session with an Imported Signed Certificate	1-22
Configuring TLS on Cisco Unified SIP Proxy	1-23
Summary Steps	1-23
Detailed Steps	1-23
Example of Configuring TLS	1-24
Configuring Lite Mode	1-24
Summary Steps	1-25
Detailed Steps	1-25
Example	1-25
Configuring Performance Control	1-25
About Performance Control	1-26
Summary Steps	1-26
Detailed Steps	1-26
Example	1-26
Committing the Configuration	1-26
Configuring Users and Groups	2-1
Adding and Modifying a User	2-1
Required Data for This Procedure	2-1
Examples	2-4
Examples	2-5
Adding and Modifying a Group	2-5
Required Data for This Procedure	2-6
Examples	2-7
Examples	2-8
Backing Up and Restoring Data	1-1
About Backing Up and Restoring Data	1-1
Restrictions for Backing Up and Restoring Data	1-1
Backing Up Files	1-2
About Backing Up Files	1-2
Summary Steps	1-2

Detailed Steps	1-3
Examples	1-3
Restoring Files	1-4
About Restoring Files	1-4
Summary Steps	1-4
Detailed Steps	1-5
Related Topics	1-5
Maintaining the Cisco Unified SIP Proxy System	1-1
Copying Configurations	1-1
Copying the Startup Configuration from the Hard Disk to Another Location	1-1
Copying the Startup Configuration from the Network SFTP Server to Another Location	1-2
Copying the Running Configuration from the Hard Disk to Another Location	1-2
Copying the Running Configuration from the Network TFTP Server to Another Location	1-3
Checking Hard Disk Memory Wear Activity	1-3
Patch Upgrade	1-1
About Patch Upgrade	1-1
Downloading the Patch File	1-1
Configuring Patch Upgrade	1-1
Summary Steps	1-1
Detailed Steps	1-2
Installing the Patch File	1-2
Summary Steps	1-2
Detailed Steps	1-3
Troubleshooting	1-1
Using CLI Commands to Troubleshoot the System	1-1
About Logging	1-1
Log Commands	1-2
Example of Log Output	1-2
Using Trace Commands	1-2
Using Show Commands	1-3
Troubleshooting Configuration Changes	1-3
Related Topics	1-3
Configuration Example	1-1



Overview of Cisco Unified SIP Proxy Release 10.2

- [About This Document, page 1](#)
- [Administration Interfaces, page 1](#)
- [Commercial Open Source Licensing, page 2](#)
- [Obtaining Documentation and Submitting a Service Request, page 2](#)
- [Technical Assistance, page 2](#)

About This Document

This document contains information about how to configure the Cisco Unified SIP Proxy system using the CLI. Use it in conjunction with the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.2](#), which lists all the CLI commands.

Administration Interfaces

Cisco Unified SIP Proxy Release 10.2 utilizes both a command-line interface (CLI) and a graphical user interface (GUI).

- [Command-Line Interface, page 1](#)
- [Graphical User Interface, page 2](#)

Command-Line Interface

The CLI is a text-based interface that is accessed through a Telnet or SSH session directly to the Cisco Unified SIP Proxy appliance or, via the Console through the hypervisor. Those familiar with Cisco IOS command structure and routers will see similarities.

The Cisco Unified SIP Proxy commands are structured much like the Cisco IOS CLI commands. However, the Cisco Unified SIP Proxy CLI commands do not affect Cisco IOS configurations. After you log in to Cisco Unified SIP Proxy, the command environment is no longer the Cisco IOS environment.

The CLI is accessible from a PC or server anywhere in the IP network.

Graphical User Interface

Cisco Unified SIP Proxy Release 10.2 also has a GUI that is used to configure and operate the Cisco Unified SIP Proxy system.

For information on using the GUI, see the online help in the application or the [GUI Configuration Guide for Cisco Unified SIP Proxy Release 10.2](#).

GUI information is not within the scope of this document.

Commercial Open Source Licensing

Some components of the software created for Cisco Unified SIP Proxy Release 10.2 are provided through open source or commercial licensing. These components and the associated copyright statements can be found at:

<https://www.cisco.com/c/en/us/about/legal/open-source-documentation-responsive.html>

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Technical Assistance

Description	Link
<p>The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies.</p> <p>To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and RSS Feeds.</p> <p>Access to most tools on the Cisco Support website requires a Cisco.com username and password.</p>	<p>https://www.cisco.com/c/en_in/support/index.html</p>
<p>Use the Cisco Feature Navigator website to find information about platform support and Cisco IOS and Catalyst OS software image support. An account on Cisco.com is not required.</p>	<p>http://www.cisco.com/go/cfn</p>



Initial Configuration Tasks

- [Configuring SNMP MIB, page 1](#)
- [Configuring Smart Licensing, page 15](#)
- [Setting Backup Parameters, page 18](#)
- [Configuring NTP Servers, page 20](#)
- [Setting the Time Zone, page 24](#)
- [Configuring Sub-interfaces, page 25](#)

Configuring SNMP MIB

- [About SNMP MIB Support, page 1](#)
- [Cisco Unified SIP Proxy SNMP MIBs, page 3](#)
- [Configuring Community String, page 12](#)
- [Configuring SNMP Traps, page 13](#)

About SNMP MIB Support

The Cisco Unified SIP Proxy (Unified SIP Proxy) includes SNMP integration for Release 10.2 with support for Cisco-USP-MIB. It is an enhancement from the SNMP MIB basic support introduced in Unified SIP Proxy Release 8.5. The Cisco Unified SIP Proxy Release 10.2 is SNMP version 2 (SNMPv2c) compliant.

Unified SIP Proxy integrates an SNMP agent and SNMP MIBs to monitor the health and to conduct performance monitoring and data collection for Unified SIP Proxy. Cisco-USP-MIB and Cisco-Process-MIB monitor the following data:

- Call Statistics
- Server Group Tables
- License State
- Memory and CPU Utilization
- System State

The SNMP integration sends notifications that helps to effectively monitor and manage performance and all the relevant system-specific data. Cisco-Process-MIB is supported in Cisco Unified SIP Proxy Release 10.2 for generating traps on configured CPU thresholds.

You can configure SNMP to send notifications to one or more monitoring systems. The maximum number of SNMP trap hosts that you can configure is limited to five.

Definitions

Table 1 Definition of SNMP MIB Related Terms

Term	Definition
Simple Network Management Protocol (SNMP)	It is a common network protocol that describes information passed between SNMP-enabled applications.
SNMP Agent	An SNMP Agent acts as a client to an SNMP management application by providing data values for registered OIDs.
Management Information Base (MIB)	MIBs are a defined hierarchy of data values managed by an SNMP Agent application.
SNMP Notification (Trap)/Informs	Information shared by a network entity with the management station to monitor a fault, exception, or an attribute value change. Traps do not need acknowledgment, but informs request acknowledgment. From SNMPv2, traps are known as notifications.
Object Identifiers (OID)	It is a unique string of digits representing the value defined in an MIB.
SNMP GET	SNMP GET is an SNMP message used to fetch the value for a particular OID.
SNMP SET	SNMP SET is an SNMP request used to modify information on the target agent (controlling agent behavior or configuration of agent).

Prerequisites

For using Cisco-USP-MIB, you must ensure that the following prerequisites are met:

- Configure Community Strings.
- Administrators of the Unified SIP Proxy must be familiar with the Cisco Command-line Interface (CLI) or the Graphical User Interface (GUI).
- Use a MIB browser or Network Management System (NMS) to interact with the Cisco Unified SIP Proxy Release 10.2.
- Upload the CISCO-USP-MIB to the NMS.
- Ensure that MIB browser or NMS provides SNMP v2c compliance.

Restrictions

SNMP MIB support in Cisco Unity SIP Proxy Release 10.2 is known to have the following limitations or restrictions:

- No Support for SNMP Version 3 (SNMPv3)
- Certain MIB objects in the Cisco Unified SIP Proxy MIB tree are not supported. For a list of MIB objects that are not supported, see [MIB Objects](#).
- If both read-only and read-write community strings are same for SNMP MIBs, then read-only takes preference and SET operations are not allowed.
- If the element table contains nested server group as an element, it does not display the partial state. The element state is shown as either up or down.

Structure

The SNMP MIB structure for Unified SIP Proxy has the following main considerations:

- The Unified SIP Proxy is uniquely identified within the Cisco management (9) group by the number –.1.3.6.1.4.1.9.9.827.
- Use either of the following methods to identify objects in the CISCO-USP-MIB:
 - The object identifier –.1.3.6.1.4.1.9.9.827.<Cisco-USP- MIB-variable>
 - The object name – iso(1).org(3).dod(6).internet(1).private(4).enterprise(1).cisco(9).ciscoMgmt(9).CISCO-USP-MIB(827).<Cisco- USP-MIB-variable>
- Cisco Unified SIP Proxy Release 10.2 supports the following traps in Cisco-Process-MIB for CPU utilization monitoring:
 - cpmCPURisingThreshold (.1.3.6.1.4.1.9.9.109.2.0.1)
 - cpmCPUFallingThreshold (.1.3.6.1.4.1.9.9.109.2.0.2)

The Unified SIP Proxy MIB structure has the following groups and subgroups:

- MIBNotifs
- MIBObjects
 - cuspScalar
 - cuspTable
 - cuspNotifControlInfo
- MIBConform

Cisco Unified SIP Proxy SNMP MIBs

The Cisco Unified SIP Proxy captures the following in a management information base.

- MIB Objects
- MIB Notifications (Traps)

MIB Objects

The supported Cisco Unified SIP Proxy MIB Objects are:

- cuspScalar
 - cuspCallStats
 - cuspMessageStats
 - cuspThresholdValues
- cuspTable
- cuspNotifControlInfo

Cisco Unified SIP Proxy Release 10.2 does not support the following MIB objects:

- cuspMemoryThresholdAlert
- cuspDiskSpaceThresholdAlert
- cuspBackupProcessFailAlert
- cuspConnectionExceptionAlert
- cuspThresholdValues
- cuspDiskSpaceThresholdValue
- cuspMemoryThresholdValue
- cuspMessageStats
- cuspStrayMessageCount
- cuspNoOfMessagesRecieved
- cuspMemoryThresholdAlertEnable
- cuspExtensiveLoggingAlertEnable
- cuspDiskSpaceThresholdAlertEnable
- cuspBackupProcessFailAlertEnable
- cuspConnectionExceptionAlertEnable
- cuspDiskSpaceUsed

cuspScalar

This table contains a list of Unified SIP Proxy scalars. An entry in this table represents Unified SIP Proxy information relevant to licenses, system state, and memory.

Table 2 MIB Description for *cuspscalar*

MIB	OID	Description
cusplastCounterResetTime	.1.3.6.1.4.1.9.9.827.1.1.1	Gives the timestamps in date and time when the call counter was last reset. All counters related to calls, Calls Per Second (CPS) and messages are reset when the counter is reset.
cuspsystemState	.1.3.6.1.4.1.9.9.827.1.1.2	Gives the Cisco Unified SIP Proxy system state as UP or DOWN.
cuspsystemUpTime	.1.3.6.1.4.1.9.9.827.1.1.3	Gives information on the active time of the Cisco Unified SIP Proxy system.
cusplicenseLimit	.1.3.6.1.4.1.9.9.827.1.1.4	Gives the license limit information. Calls are rejected if the license limit is exceeded.
cusplicenseState	.1.3.6.1.4.1.9.9.827.1.1.5	Gives the current license state of Cisco Unified SIP Proxy.
cuspsmartAgentState	.1.3.6.1.4.1.9.9.827.1.1.6	Gives the current license state of the SmartLicense Agent.
cuspsystemConfiguredMemory	.1.3.6.1.4.1.9.9.827.1.1.7	Gives the total memory (RAM) configured on Cisco Unified SIP Proxy in Megabytes.
cuspsystemMemoryUsed	.1.3.6.1.4.1.9.9.827.1.1.8	Gives the Cisco Unified SIP Proxy current memory (RAM) usage information in Megabytes.
cuspsystemDiskSpaceUsed	.1.3.6.1.4.1.9.9.827.1.1.9	Gives the current disk utilization of CUSP in MB (Mega Byte).

cuspcallstats

This Unified SIP Proxy MIB defines data related to calls.

Table 3 MIB Description for *cuspcallstats*

MIB	OID	Description
cusptotalCalls	.1.3.6.1.4.1.9.9.827.1.1.10.1	The total number of calls since the last counter reset.
cusptotalFailedCalls	.1.3.6.1.4.1.9.9.827.1.1.10.2	The total number of failed calls since last counter reset.
cuspcps	.1.3.6.1.4.1.9.9.827.1.1.10.3	The current running Calls Per Second (CPS) information.
cuspsystemAvgCPSOneMin	.1.3.6.1.4.1.9.9.827.1.1.10.4	The average CPS in the last one minute.
cuspsystemMaxCPSOneMin	.1.3.6.1.4.1.9.9.827.1.1.10.5	The Maximum value of CPS in the last one minute.

MIB	OID	Description
cuspdroppedCallsOneSec	.1.3.6.1.4.1.9.9.827.1.1.10.6	The count on number of calls dropped in the last one second.
cuspdAvgDroppedCallsOneMin	.1.3.6.1.4.1.9.9.827.1.1.10.7	The average of 'dropped calls per second' in the last one minute.
cuspdMaxDroppedCallsOneMin	.1.3.6.1.4.1.9.9.827.1.1.10.8	The Maximum of 'dropped calls per second' in the last one minute.
cuspcallsRoutedOneSec	.1.3.6.1.4.1.9.9.827.1.1.10.9	The number of calls routed through CUSP in one second.
cuspdAvgCallsRoutedOneMin	.1.3.6.1.4.1.9.9.827.1.1.10.10	The average of 'calls routed per second' in last one minute.
cuspdMaxCallsRoutedOneMin	.1.3.6.1.4.1.9.9.827.1.1.10.11	The maximum of 'calls routed per second' in the last one minute.
cuspcallsDroppedExceedingLicense	.1.3.6.1.4.1.9.9.827.1.1.10.12	The total calls dropped due to exceeding license limit.

**Note**

There is no CLI and GUI equivalent for the data retrieved through MIB objects related to Calls Per Second (CPS) such as cuspcps, cuspdAvgCPSOneMin, cuspdMaxCPSOneMin, cuspdDroppedCallsOneSec, cuspdAvgDroppedCPSOneMin, cuspdMaxDroppedCPSOneMin, cuspcallsRoutedOneSec, cuspdAvgCallsRoutedOneMin, and cuspdMaxCallsRoutedOneMin. For example, GUI provides data for a five-minute average CPS while the MIB object cuspcps retrieves CPS data only for the last second.

**Note**

CUSP dropped call MIB objects are not updated if the license is in unidentified state.

**Note**

If call rate limit is set to a value lesser than license limit, cuspcallsDroppedExceedingLicense MIB counts calls that are dropped due to call rate limit.

cuspthresholdValues

The Unified SIP proxy MIB object cuspthresholdValues (.1.3.6.1.4.1.9.9.827.1.1.12) provides threshold value information (as configured by user) on disk space and memory utilization.

Table 4 MIB Description for cuspthresholdValues

MIB	OID	Description
cuspdiskSpaceThresholdValue	.1.3.6.1.4.1.9.9.827.1.1.12.1	The percentage threshold value configured by the user. If the percentage disk space utilization exceeds this limit, then cuspdiskSpaceThresholdAlert notification is sent.

MIB	OID	Description
cuspmemoryThresholdValue	.1.3.6.1.4.1.9.9.827.1.1.12.2	The percentage threshold value configured by the user. If the percentage memory utilization exceeds this limit, then cuspmemoryThresholdAlert notification is sent.

cuspmemoryThresholdValue

The Unified SIP proxy MIB object cuspmemoryThresholdValue (.1.3.6.1.4.1.9.9.827.1.2) consists of two main subgroups of objects:

- cuspmemoryThresholdValue (OID:.1.3.6.1.4.1.9.9.827.1.2.1)
- cuspmemoryThresholdValue (OID:.1.3.6.1.4.1.9.9.827.1.2.2)



Note

If data is retrieved from multiple network elements using cuspmemoryThresholdValue MIBs, the CPU utilization can spike beyond the optimum levels.

cuspmemoryThresholdValue

The MIB cuspmemoryThresholdValue represents a list of server groups that are part of active configuration. Server groups define the elements with which the Cisco Unified SIP Proxy system interacts for each network.

Table 5 MIB Description for cuspmemoryThresholdValue

MIB	OID	Description
cuspmemoryThresholdValueEntry	.1.3.6.1.4.1.9.9.827.1.2.1.1	An entry (conceptual row) in the ServerGroup Table.
cuspmemoryThresholdValueIndex	.1.3.6.1.4.1.9.9.827.1.2.1.1.1	A unique value, greater than zero, for each server group.
cuspmemoryThresholdValueName	.1.3.6.1.4.1.9.9.827.1.2.1.1.2	The name of the server group.
cuspmemoryThresholdValueNetwork	.1.3.6.1.4.1.9.9.827.1.2.1.1.3	The network to which the server group belongs.
cuspmemoryThresholdValueStatus	.1.3.6.1.4.1.9.9.827.1.2.1.1.4	The Server group status is given as up, partial down, and down.
cuspmemoryThresholdValuePingStatus	.1.3.6.1.4.1.9.9.827.1.2.1.1.5	Server group ping status.
cuspmemoryThresholdValueLBType	.1.3.6.1.4.1.9.9.827.1.2.1.1.6	The load balancing algorithm for the server group.



Note

CuspmemoryThresholdValuePingStatus MIB object retrieves the information of a group, irrespective of the global ping status.

cuspElementTable

The MIB cuspElementTable provides a list of elements in a server group table. Also, the table contains information on status (up or down) of the element, its Q-value, weight, and transport type.

Table 6 MIB Description for cuspElementTable

MIB	OID	Description
cuspElementEntry	.1.3.6.1.4.1.9.9.827.1.2.2.1	An entry (conceptual row) in the cuspElementTable.
cuspElementIndex	.1.3.6.1.4.1.9.9.827.1.2.2.1.1	A unique value, greater than zero, for each element.
cuspElementName	.1.3.6.1.4.1.9.9.827.1.2.2.1.2	The Server group element ID.
cuspElementStatus	.1.3.6.1.4.1.9.9.827.1.2.2.1.3	The server group element status as up or down.
cuspElementQValue	.1.3.6.1.4.1.9.9.827.1.2.2.1.4	The Q value of the server group element. Q value range is 0.0 to 1.0.
cuspElementWeight	.1.3.6.1.4.1.9.9.827.1.2.2.1.5	The weight of the server group element. Weight is used for load balancing between server group elements.
cuspElementPort	.1.3.6.1.4.1.9.9.827.1.2.2.1.6	Gives the port number of the server group element.
cuspElementTransport	.1.3.6.1.4.1.9.9.827.1.2.2.1.7	The transport type of the server group element. Transport type can be udp, tcp, or tls.
cuspElementTotalCalls	.1.3.6.1.4.1.9.9.827.1.2.2.1.8	The total routed calls to the server group element.
cuspElementFailedCalls	.1.3.6.1.4.1.9.9.827.1.2.2.1.9	The total failed calls on the server group element.

cuspNotifControlInfo

The MIB cuspNotifControlInfo (OID is .1.3.6.1.4.1.9.9.827.1.3) contains object that manages (enabling and disabling) the traps defined in CiscoUspMIBNotifs.

Table 7 MIB Description for cuspNotifControlInfo

MIB	OID	Description
cuspNotifSeverity	.1.3.6.1.4.1.9.9.827.1.3.1	The classification on the event severity.
cuspNotifDetail	.1.3.6.1.4.1.9.9.827.1.3.2	The detailed information on error encountered.
cuspSystemStateAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.3	Controls generation of cuspSystemStateAlert, cuspConnectionExceptionAlert.

MIB	OID	Description
cuspsServerGroupAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.4	Controls the generation of cuspsServerGroupElementAlert and cuspsServerGroupAlert.
cuspsServerGroupElementAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.5	Controls the generation of cuspsServerGroupElementAlert.
cuspsLicenseExceededAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.6	Controls the generation of cuspsLicenseExceededAlert.
cuspsLicenseStateAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.7	Controls the generation of cuspsLicenseStateAlert.
cuspsExtensiveLoggingAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.8	Controls the generation of cuspsExtensiveLoggingAlert.
cuspsDiskSpaceThresholdAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.9	Controls the generation of cuspsDiskSpaceThresholdAlert.
cuspsMemoryThresholdAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.10	Controls the generation of cuspsMemoryThresholdAlert.
cuspsBackupProcessFailAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.11	Controls the generation of cuspsBackupProcessFailAlert notification.
cuspsConnectionExceptionAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.12	Controls the generation of cuspsConnectionExceptionAlert.
cuspsSIPMessageQueueOverflowAlertEnable	.1.3.6.1.4.1.9.9.827.1.3.13	Controls the generation of cuspsSIPMessageQueueOverflowAlert.

MIB Notifications (Traps)

Unified SIP Proxy generates trap notifications when the Network Management Station (NMS) or the administrator has to be informed about an event. The notification describes the operation state information of a service when a condition occurs. Traps provide information on issues that occur in the network element without polling for SNMP objects.

The administrator can control traps using the Command-line Interface (CLI), the Graphical User Interface (GUI), or through SNMP. By default, the traps are set to disabled state.

Unified SIP Proxy Release 10.2 supports a generic trap and raises SNMP traps on the following events:

- License Limit is exceeded
- System Failure
- Change in Server element state
- Change in Server group element state

Unified SIP Proxy Release 10.2 does not support SNMP traps on the following events:

- Backup Process Failure
- Memory threshold is exceeded
- Disk space threshold is exceeded
- Extensive Debug level logging

- Connection Exception

Table 8 MIB Description for MIB Traps

MIB	OID	Description
cuspsystemStateAlert	.1.3.6.1.4.1.9.9.827.0.1	Generated when the Cisco Unified SIP Proxy system goes up or down. This notification can be enabled or disabled by setting <code>cuspsystemStateAlertEnable</code> . CLI command to configure the trap: snmp-server enable traps System-State
cuspserverGroupElementAlert	.1.3.6.1.4.1.9.9.827.0.2	Generated when the status of server group element changes. This notification can be enabled or disabled by setting <code>cuspserverGroupAlertEnable</code> . CLI command to configure the trap: snmp-server enable traps SG-Element
cuspserverGroupAlert	.1.3.6.1.4.1.9.9.827.0.3	Generated when all the elements in the server group go down. Also, it is generated when any one element in the server group comes up after all the elements in the group were down. This notification is enabled or disabled by setting <code>cuspserverGroupAlertEnable</code> . CLI command to configure the trap: snmp-server enable traps Server-Group
cuspmemoryThresholdAlert	.1.3.6.1.4.1.9.9.827.0.4	Generated when Cisco Unified SIP Proxy memory usage exceeds the <code>cuspmemoryThresholdValue</code> . This notification can be enabled or disabled by setting <code>cuspthresholdAlertEnable</code> .
cusplicenseExceededAlert	.1.3.6.1.4.1.9.9.827.0.5	Generated when average CPS exceeds <code>cusplicenseLimit</code> . This notification can be enabled or disabled by setting <code>cusplicenseExceededAlertEnable</code> . CLI command to configure the trap: snmp-server enable traps License-Exceeded

MIB	OID	Description
cusLicenseStateAlert	.1.3.6.1.4.1.9.9.827.0.6	Generated when Cisco Unified SIP Proxy license state changes. This notification is enabled or disabled by setting cusLicenseStateAlertEnable CLI command to configure the trap: snmp-server enable traps License-State
cusExtensiveLoggingAlert	.1.3.6.1.4.1.9.9.827.0.7	Generated when extensive debug level logging is enabled in Cisco Unified SIP Proxy. Extensive logging has an impact on performance and system stability. This notification can be enabled or disabled by setting cusExtensiveLoggingAlertEnable. CLI Command to configure the trap: snmp-server enable traps Extensive-Logging
cusDiskSpaceThresholdAlert	.1.3.6.1.4.1.9.9.827.0.8	Generated when the Cisco Unified SIP Proxy Disk usage exceeds the cusDiskSpaceThresholdValue. This notification can be enabled or disabled by setting cusThresholdAlertEnable.
cusBackupProcessFailAlert	.1.3.6.1.4.1.9.9.827.0.9	Generated when backup process fails. This notification is enabled or disabled by setting cusBackupProcessFailAlertEnabl.
cusConnectionExceptionAlert	.1.3.6.1.4.1.9.9.827.0.10	Generated when a connection exception occurs. This notification can be enabled or disabled by setting cusSystemStateAlertEnable.

MIB	OID	Description
cusSIPMessageQueueOverflowAlert	.1.3.6.1.4.1.9.9.827.0.11	Generated when the Cisco Unified SIP Proxy system queue is full. Queue full indicates that either Cisco Unified SIP Proxy is overloaded or encountering network issues. The time interval between two successive notifications is 5 minutes. Notification is not sent within this time frame even if the queue is full. This back-off timer of 5 minutes prevents the Cisco Unified SIP Proxy overload. This notification can be enabled or disabled by setting <code>cusSIPMessageQueueOverflowAlertEnable</code> . CLI command to configure the trap: snmp-server enable traps SIP-Message-Queue-Overflow
cpmCPURisingThreshold	.1.3.6.1.4.1.9.9.109.2.0.1	Sent when configured rising CPU utilization threshold is reached and CPU utilization remains above the threshold for configured interval, and such a notification is requested. CLI command to configure the trap: snmp-server enable traps CPU-Rising
cpmCPUFallingThreshold	.1.3.6.1.4.1.9.9.109.2.0.2	Sent when the configured falling threshold is reached and CPU utilization remains under threshold for configured interval, and such a notification is requested. CLI command to configure the trap: snmp-server enable traps CPU-Falling

**Note**

`cusLicenseExceededAlert` is not generated if the license is in unidentified state.

Configuring Community String

Configure community string to poll data using MIB objects.

Summary Steps

1. `config terminal`
2. `snmp-server community community string {RO | RW}`
3. `end`
4. `write memory`

Detailed Steps

	Command or Action	Purpose
Step 1	config Example: se-10-1-0-0# <code>config terminal</code>	Enables privileged EXEC mode.
Step 2	snmp-server community community string {RO RW} Example: se-10-1-0-0(config)# <code>snmp-server community public RW</code>	Configures the community string. The access could be read-only or read-write based on the selected configuration.
Step 3	end Example: se-10-1-0-0(config)# <code>end</code>	Exits the privileged EXEC mode.
Step 4	write memory Example: se-10-1-0-0# <code>write memory</code>	Stores the configuration in the startup configuration file.

Example

The following example configures Community Strings on the Cisco Unified SIP Proxy:

```
se-10-1-0-0# config terminal
se-10-1-0-0(config)# snmp-server community public RW
se-10-1-0-0(config)# end
se-10-1-0-0# write memory
```

Configuring SNMP Traps

Summary Steps

1. `config terminal`
2. `snmp-server host IP Address community string`
3. `snmp-server enable traps [All | System-State | Server-Group | SG-Element | CPU-Rising | CPU-Falling | License-Exceeded | Extensive-Logging | SIP-Message-Queue-Overflow]`
4. `snmp-server enable traps`

5. **end**
6. **write memory**

Detailed Steps

	Command or Action	Purpose
Step 1	config Example: se-10-1-0-0# config terminal	Enables privileged EXEC mode.
Step 2	snmp-server host <i>IP Address community string</i> Example: se-10-1-0-0(config)# snmp-server host 10.104.54.108 public	Specifies the host that receives SNMP notifications.
Step 3	snmp-server enable traps [All System-State Server-Group SG-Element CPU-Rising CPU-Falling License-State License-Exceeded Extensive-Logging SIP-Message-Queue-Overflow] Example: se-10-1-0-0(config)# snmp-server enable traps SG-Element	Activates the traps selected. The command snmp-server enable traps all activates all traps. To activate a specific trap, follow snmp-server enable traps with the subcommand specific to that trap.
Step 4	snmp-server enable traps Example: se-10-1-0-0(config)# snmp-server enable traps	Enables trap generation from Cisco Unified SIP Proxy to the configured hosts. Traps are sent to the host only when this global command is enabled.
Step 5	end Example: se-10-1-0-0(config)# end	Exits the privileged EXEC mode.
Step 6	write memory Example: se-10-1-0-0# write memory	Stores the configuration in the startup configuration file.

Example

The following example configures SNMP Traps on the Cisco Unified SIP Proxy:

```
se-10-1-0-0# config terminal
se-10-1-0-0(config)# snmp-server host 10.104.54.108 public
se-10-1-0-0(config)# snmp-server enable traps SG-Element
se-10-1-0-0(config)# snmp-server enable traps
se-10-1-0-0(config)# end
se-10-1-0-0# write memory
```


**Note**

The trap body information can only be seen on the trap listener host. However, a generic trap notification will be logged in the vCUSP **atrace.log** logs.

Configuring CPU Threshold Values for Traps

To define rising and falling CPU threshold values for traps, perform these steps:

Summary Steps

1. `config terminal`
2. `process cpu threshold type total rising percentage interval seconds falling percentage interval seconds`

Detailed Steps

	Command or Action	Purpose
Step 1	config Example: se-10-1-0-0# config terminal	Enables privileged EXEC mode.
Step 2	process cpu threshold type {total} rising percentage interval seconds falling percentage interval seconds Example: se-10-1-0-0(config)# process cpu threshold type {total} rising 80 interval 300 falling 5 interval 300	Sets the CPU thresholding notifications types and values. <ul style="list-style-type: none"> • In this example, the CPU utilization threshold is set to 80 percent for a rising threshold notification and 5 percent for a falling threshold notification. The polling interval is set as 300 seconds.

Example

The following example configures CPU thresholding values for SNMP traps on the Cisco Unified SIP Proxy:

```
se-10-1-0-0# config terminal
se-10-1-0-0(config)# process cpu threshold type {total} rising 80 interval 300 falling 5 interval 300
```

Configuring Smart Licensing

- [About Smart Licensing, page 16](#)
- [Summary Steps, page 16](#)
- [Detailed Steps, page 17](#)
- [Example, page 17](#)

About Smart Licensing

Cisco Smart Software Licensing is a standardized licensing platform that facilitates you to deploy and manage Cisco software licenses easily and quickly. Cisco Smart Software Licensing establishes a pool of software licenses that can be used across your network in a flexible and automated manner. It also provides visibility to your purchased and deployed licenses in your network. Cisco Smart Software Licensing removes the need for Product Activation Keys (PAKs) and reduces your license activation and registration time.

**Note**

For more information on Smart Licensing, see <http://www.cisco.com/go/smartlicensing>.

Summary Steps

1. **enable**
2. **license smart destinationAddr** *url*
3. **license smart httpProxyAddr** *url*
4. **license smart activate cusp** *count*
5. **license smart register token_id** *token*

Detailed Steps

	Command or Action	Purpose
Step 1	enable Example: se-10-1-0-0# enable	Enables privileged EXEC mode. <ul style="list-style-type: none"> Enter your password if prompted.
Step 2	license smart destinationAddr <i>https://tools.cisco.com/its/service/oddce/services/DDCEService</i> Example: se-10-1-0-0# license smart destinationAddr <i>https://tools.cisco.com/its/service/oddce/services/DDCEService</i>	Connects to the central licensing server.
Step 3	license smart httpProxyAddr 10.1.1.1 Example: se-10-1-0-0# license smart httpProxyAddr 10.1.1.1	Sets the HTTP(S) proxy server address for smart licensing.
Step 4	license smart activate cusp count Example: se-10-1-0-0# license smart activate cusp 100	Activates the request number of licenses. The count must be multiple of 5.
Step 5	license smart register token_id token Example: se-10-1-0-0# license smart register token_id <i>MjgxZjdkY2RtMwY5Ny00YTk4LOI2N2MtNjcxNmYaMTkzZGFhLHE0MjA3MjY0%0AMjI5NDZ8OVA0dmNzSjdIeG4MMHIzTmZubNFzMHhKOTYyeHlUZwQzQzVIM3Jk%0AHV3MD0A3D%0N</i>	Registers the device instance with the Cisco licensing cloud. This step is performed only once per device instance. The license agent registers the product with Cisco and receives back an identity certificate. This certificate is saved and automatically used for all future communications with Cisco. The license agent automatically renews the registration information with Cisco after one year.

Example

The following example configures Smart License on the Cisco Unified SIP Proxy:

```

se-10-1-0-0# enable
se-10-1-0-0# license smart destinationAddr
https://tools.cisco.com/its/service/oddce/services/DDCEService
se-10-1-0-0# license smart httpProxyAddr 10.1.1.1
se-10-1-0-0# license smart activate cusp 100
se-10-1-0-0# license smart register token_id
MjgxZjdkY2RtMwY5Ny00YTk4LOI2N2MtNjcxNmYaMTkzZGFhLHE0MjA3MjY0%0AMjI5NDZ8OVA0dmNzSjdIeG4MMHIzTmZubNFzMHhKOTYyeHlUZwQzQzVIM3Jk%0AHV3MD0A3D%0N

```

Setting Backup Parameters

- [About Backup Parameters, page 18](#)
- [Prerequisites, page 18](#)
- [Summary Steps, page 18](#)
- [Detailed Steps, page 19](#)
- [Example, page 19](#)

About Backup Parameters

Cisco Unified SIP Proxy backup and restore functions use an SFTP server to store and retrieve data. The backup function copies the files from Cisco Unified SIP Proxy to the SFTP server and the restore function copies the files from the SFTP server to Cisco Unified SIP Proxy. The SFTP server can reside anywhere in the network as long as the backup and restore functions can access it with an IP address or hostname.

All Cisco Unified SIP Proxy backup files are stored on the specified server. You can copy the backup files to other locations or servers, if necessary.

The backup parameters specify the SFTP server to use for storing Cisco Unified SIP Proxy backup files and the number of backups that are stored before the system overwrites the oldest one.

Prerequisites

- Verify that an SFTP administrator or other user who can log in to the SFTP server has full permission on the SFTP server, such as read, write, overwrite, create, and delete permissions for files and directories.
- Gather the SFTP server URL and the username and password of the SFTP server login.
Make sure that the SFTP server URL is pointing to the absolute path of the backup directory. For example, `sftp://<hostname>/full/path/from/root/to/backup_directory`.
- Determine the number of revisions to save before the oldest backup is overwritten.

Summary Steps

1. **configure terminal**
2. **backup server url** *backup-sftp-url* **username** *backup-sftp-usrname* **password** *backup-sftp-password*
3. **backup revisions number** *number*
4. **end**
5. **show backup**

Detailed Steps

	Command or Action	Purpose
Step 1	<code>configure terminal</code> <code>se-10-1-0-0# config terminal</code>	Enters configuration mode.
Step 2	<code>backup server url sftp-url username sftp-username password sftp-password</code> Example: <code>se-10-1-0-0(config)> backup server url sftp://main/backups username "admin" password "wxyz"</code> <code>se-10-1-0-0(config)> backup server url sftp://192.0.2.15/backups username "admin" password "wxyz"</code>	Sets the backup parameters. Note You must configure the backup server before you can configure the backup revisions. <ul style="list-style-type: none"> • server url—The <i>sftp-url</i> value is the URL to the network SFTP server where the backup files will be stored. • The <i>sftp-username</i> and <i>sftp-password</i> values are the username and password for the network SFTP server. <p>In the example, main is the hostname of the SFTP server and backups is the directory where backup files are stored.</p> <p>Note /backups is an absolute path to the backups directory.</p>
Step 3	<code>backup revisions number</code> Example: <code>se-10-1-0-0(config)> backup revisions 5</code>	Sets the number of backup files that will be stored. When the system reaches this number of backups, it deletes the oldest stored file.
Step 4	<code>end</code> Example: <code>se-10-0-0-0(config)> end</code>	Exits configuration mode.
Step 5	<code>show backup</code> Example: <code>se-10-1-0-0> show backup</code>	Displays the backup server configuration information, including the SFTP server URL and the maximum number of backup files available.

Example

The following example configures a backup server and displays the **show backup** output:

```
se-10-1-0-0> enable
se-10-1-0-0# configure terminal
se-10-1-0-0(config)> backup revisions 5
se-10-1-0-0(config)> backup server url sftp://10.12.0.1/sftp username "admin" password "wxyz"
se-10-1-0-0(config)> end
se-10-1-0-0> show backup
Server URL:                               sftp://10.12.0.1/sftp
User Account on Server:
Number of Backups to Retain:              5
se-10-1-0-0>
```

Related Topics

- For information about the CLI commands, see the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.2](#).
- For information about backing up and restoring your configuration, see [Backing Up and Restoring Data](#).

Configuring NTP Servers

When you install the Cisco Unified SIP Proxy software, the system gives you the option of adding up to two Network Time Protocol (NTP) servers. You can add additional NTP servers (the system supports up to three NTP servers), remove one or more NTP servers, or display NTP server information using the CLI.

- [Adding NTP Servers, page 20](#)
- [Removing an NTP Server, page 22](#)
- [Displaying NTP Server Information, page 23](#)

Adding NTP Servers

- [About Adding NTP Servers, page 20](#)
- [Summary Steps, page 20](#)
- [Detailed Steps, page 21](#)
- [Examples of Adding NTP Servers, page 21](#)

About Adding NTP Servers

You can specify an NTP server using its IP address or its hostname.

Cisco Unified SIP Proxy uses the DNS server to resolve the hostname to an IP address and stores the IP address as an NTP server. If DNS resolves the hostname to more than one IP address, Cisco Unified SIP Proxy randomly chooses one of the IP addresses that is not already designated as an NTP server. If you do not want to go with the random choice, set the **prefer** attribute for one server.

To configure an NTP server with multiple IP addresses for a hostname, repeat the configuration steps using the same hostname. Each iteration assigns the NTP server to its remaining IP addresses.

Summary Steps

1. **configure terminal**
2. **ntp server** {hostname | ip-address} [**prefer**]
3. **end**
4. **show ntp status**
5. **show ntp configuration**
6. **copy running-config startup-config**

Detailed Steps

	Command or Action	Purpose
Step 1	<code>configure terminal</code> Example: se-10-1-0-0# <code>configure terminal</code>	Enters configuration mode.
Step 2	<code>ntp server {hostname ip-address} [prefer]</code> Example: se-10-1-0-0(config)> <code>ntp server 192.0.2.14</code> se-10-1-0-0(config)> <code>ntp server 192.0.2.17 prefer</code>	Specifies the hostname or IP address of the NTP server. If more than one server is configured, the server with the prefer attribute is used before the others.
Step 3	<code>end</code> Example: se-10-1-0-0(config)> <code>exit</code>	Exits configuration mode.
Step 4	<code>show ntp status</code> Example: se-10-1-0-0> <code>show ntp status</code>	Displays statistics about the NTP server.
Step 5	<code>show ntp configuration</code> Example: se-10-1-0-0> <code>show ntp configuration</code>	Displays the configured NTP servers.
Step 6	<code>copy running-config startup-config</code> Example: se-10-1-0-0> <code>copy running-config startup-config</code>	Copies the configuration changes to the startup configuration.

Examples of Adding NTP Servers

The following commands configure the NTP server:

```
se-10-1-0-0# configure terminal
se-10-1-0-0(config)> ntp server 192.0.2.14
se-10-1-0-0(config)> exit
se-10-1-0-0>
```

The output from the `show ntp status` command looks similar to the following:

```
se-10-1-0-0> show ntp status

NTP reference server 1:      192.0.2.14
Status:                     sys.peer
Time difference (secs):     3.268110099434328E8
Time jitter (secs):         0.1719226837158203
```

Removing an NTP Server

You can remove an NTP server using its IP address or hostname.

- [Summary Steps, page 22](#)
- [Detailed Steps, page 22](#)

Summary Steps

1. **configure terminal**
2. **no ntp server** {hostname | ip-address}
3. **exit**
4. **show ntp status**
5. **show ntp configuration**
6. **copy running-config startup-config**

Detailed Steps

	Command or Action	Purpose
Step 1	configure terminal Example: se-10-1-0-0# configure terminal	Enters configuration mode.
Step 2	no ntp server {hostname ip-address} Example: se-10-1-0-0(config) > no ntp server 192.0.2.14 se-10-1-0-0(config) > no ntp server myhost	Specifies the hostname or IP address of the NTP server to remove.
Step 3	exit Example: se-10-1-0-0(config) > exit	Exits configuration mode.
Step 4	show ntp status Example: se-10-1-0-0> show ntp status	Displays statistics about the NTP server.
Step 5	show ntp configuration Example: se-10-1-0-0> show ntp status	Displays the configured NTP servers.
Step 6	copy running-config startup-config Example: se-10-1-0-0> copy running-config startup-config	Copies the configuration changes to the startup configuration.

Displaying NTP Server Information

- [Commands to Display NTP Server Information, page 23](#)
- [Examples of Showing NTP Server Information, page 23](#)

Commands to Display NTP Server Information

The following commands are available to display NTP server configuration information and status:

- **show ntp associations**
- **show ntp servers**
- **show ntp source**
- **show ntp status**

Examples of Showing NTP Server Information

The following is sample output for the **show ntp associations** command:

```
se-10-1-0-0> show ntp associations

ind assID status  conf reach auth condition  last_event cnt
=====
  1 61253 8000   yes  yes  none    reject
```

The following is sample output for the **show ntp servers** command:

```
se-10-1-0-0> show ntp servers

      remote          refid      st t when poll reach  delay  offset  jitter
=====
  1.100.6.9          0.0.0.0    16 u   - 1024   0   0.000   0.000 4000.00
space reject,      x falsetick,    . excess,      - outlyer
+ candidate,      # selected,    * sys.peer,    o pps.peer
```

The following is sample output for the **show ntp source** command:

```
se-10-1-0-0> show ntp source

127.0.0.1: stratum 16, offset 0.000013, synch distance 8.67201
0.0.0.0:      *Not Synchronized*
```

The following is sample output for the **show ntp status** command:

```
se-10-1-0-0> show ntp status

NTP reference server :      10.100.6.9
Status:                  reject
Time difference (secs):    0.0
Time jitter (secs):       4.0
```

Related Topics

- For information about the CLI commands, see the CLI Command Reference for [Cisco Unified SIP Proxy Release 10.2](#).
- For information about the initial installation of the Cisco Unified SIP Proxy system and the post installation configuration tool, see the [Installation Guide for Cisco Unified SIP Proxy Release 10.2](#). For information about copying the configuration, see [Copying Configurations, page 1](#).

Setting the Time Zone

When you install the Cisco Unified SIP Proxy software, the system prompts you to set the time zone. If you need to change it, use the **clock timezone** command in Cisco Unified SIP Proxy configuration mode.

To display the time zone, use the **show clock detail** command in module EXEC mode.

Example of Setting the Time Zone

```

se-10-1-0-0# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
se-10-1-0-0(config)> clock timezone
Please identify a location so that time zone rules can be set correctly.
Please select a continent or ocean.
1) Africa                4) Arctic Ocean        7) Australia            10) Pacific Ocean
2) Americas              5) Asia                8) Europe
3) Antarctica           6) Atlantic Ocean     9) Indian Ocean
>? 2
Please select a country.
1) Anguilla                29) Honduras
2) Antigua & Barbuda      30) Jamaica
3) Argentina              31) Martinique
4) Aruba                   32) Mexico
5) Bahamas                33) Montserrat
6) Barbados                32) Netherlands Antilles
7) Belize                  34) Nicaragua
8) Bolivia                 35) Panama
9) Brazil                  36) Paraguay
10) Canada                 37) Peru
11) Caribbean NL          38) Puerto Rico
12) Cayman Islands        39) St Barthelemy
13) Chile                  40) St Kitts & Nevis
14) Colombia              41) St Lucia
15) Costa Rica            42) St Maarten (Dutch)
16) Cuba                   43) St Martin (French)
17) Curacao               44) St Pierre & Miquelon
18) Dominica              45) St Vincent
19) Dominican Republic   46) Suriname
20) Ecuador                47) Trinidad & Tobago
21) El Salvador           48) Turks & Caicos Is
22) French Guiana        49) United States
23) Greenland             50) Uruguay
24) Grenada                51) Venezuela
25) Guadeloupe            52) Virgin Islands (UK)
26) Guatemala             53) Virgin Islands (US)
27) Guyana
28) Haiti
>? 49
Please select one of the following time zone regions.
1) Eastern (most areas)
2) Eastern - MI (most areas)
3) Eastern - KY (Louisville area)
4) Eastern - KY (Wayne)
5) Eastern - IN (most areas)
6) Eastern - IN (Da, Du, K, Mn)
7) Eastern - IN (Pulaski)
8) Eastern - IN (Crawford)
9) Eastern - IN (Pike)
10) Eastern - IN (Switzerland)
11) Central (most areas)

```

```

12) Central - IN (Perry)
13) Central - IN (Starke)
14) Central - MI (Wisconsin border)
15) Central - ND (Oliver)
16) Central - ND (Morton rural)
17) Mountain (most areas)
18) Mountain - ID (south); OR (east)
19) Mountain Time - Navajo
20) MMST - Arizona (except navajo)
21) Pacific
22) Alaska (most areas)
23) Alaska - Juneau area
24) Alaska - Sitka area
25) Alaska - Annette Island
26) Alaska - Yakutat
27) Alaska (west)
28) Aleutian Islands
29) Hawaii
>? 21

```

The following information has been given:

```

United States
Pacific Time

```

```

Therefore TZ='America/Los_Angeles' will be used.
Local time is now:      Mon Sep 23 17:23:54 PDT 2019.
Universal Time is now: Tue Sep 24 00:23:54 UTC 2019.
Is the above information OK?
1) Yes
2) No
>? 1

```

```

Save the change to startup configuration and reload the module for the new time zone to
take effect.
se-10-1-0-0(config)>

```

Configuring Sub-interfaces

You can define multiple sub-interfaces on Virtual Cisco Unified SIP Proxy (vCUSP) and there is no specific restriction on the number of sub-interfaces from vCUSP.

- [Summary Steps, page 20](#)
- [Detailed Steps, page 21](#)
- [Example, page 26](#)



Note

Ensure that all the sub-interfaces are configured with IP addresses from the same subnet, as the trunk port config with sub-interfaces are not supported on vCUSP 10.x and later.

Summary Steps

1. **configure terminale**
2. **Interface FastEthernet**
3. **ipaddress**

4. end

Detailed Steps

	Command or Action	Purpose
Step 1	configure Example: se-10-64-86-166# > conf t	Enters Cisco Unified SIP Proxy configuration mode.
Step 2	interface FastEthernet Example: se-10-64-86-166 (config)# interface FastEthernet 0.11	Enters interface FastEthernet.
Step 3	ip address Example: se-10-64-86-166 (config-subif)# ip address 10.64.86.159 255.255.255.0	Configures subinterface for Fastethernet 0.11 under configuration mode.
Step 4	end Example: se-10-64-86-166 (config-subif)# end	Exits network command mode.

Example

The following example configures subinterface for Fastethernet:

```
se-10-64-86-166 (config) > cusp
se-10-64-86-166 (config-subif) # interface FastEthernet 0.11
se-10-64-86-166 (config-subif) # ip address 10.64.86.159 255.255.255.0
se-10-64-86-166 (config) # end
```



Configuring the Cisco Unified SIP Proxy

- [Configuring Logical Networks, page 1](#)
- [Configuring Trigger Conditions, page 2](#)
- [Configuring Server Groups, page 4](#)
- [Configuring Route Tables, page 6](#)
- [Configuring Normalization Policies, page 8](#)
- [Configuring Lookup Policies, page 9](#)
- [Configuring Routing Triggers, page 11](#)
- [Configuring Normalization Triggers, page 12](#)
- [Configuring Listen and Record-Route Ports, page 13](#)
- [Configuring a Hostname, page 14](#)
- [Configuring Transport Layer Security \(TLS\), page 15](#)
- [Configuring Lite Mode, page 24](#)
- [Configuring Performance Control, page 25](#)
- [Committing the Configuration, page 26](#)

Configuring Logical Networks

Each interface on the Cisco Unified SIP Proxy is associated with a logical network. Logical networks are used to organize server groups, listen points, and other properties. SIP messages are associated with the network on which they arrive.

- [Summary Steps, page 1](#)
- [Detailed Steps, page 2](#)
- [Example, page 2](#)

Summary Steps

1. `culp`
2. `configure`
3. `sip network network`

4. end network

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	sip network network Example: se-10-1-0-0(cusp-config)> sip network service-provider	Creates a network and puts you into network command mode. In this case, the network that is being created is called “service provider”.
Step 4	end network Example: se-10-1-0-0(cusp-config-network)> end network	Exits network command mode.

Example

The following example creates a network called “service-provider”:

```
se-10-1-0-0> cusp
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> sip network service-provider
se-10-1-0-0(cusp-config-network)> end network
```

Configuring Trigger Conditions

You create trigger conditions to allow Cisco Unified SIP Proxy to respond with the appropriate action for various call flows. In general, the more complex the call flow is, the more complex the trigger must be.

- [Summary Steps, page 2](#)
- [Detailed Steps, page 3](#)
- [Example, page 4](#)

Summary Steps

1. cusp

2. **configure**
3. **trigger condition** *trigger-condition-name*
4. **sequence** *sequence-number*
5. (Optional) **in-network** *network-name*
6. (Optional) **mid-dialog**
7. end sequence
8. end trigger condition

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	trigger condition <i>trigger-condition-name</i> Example: se-10-1-0-0(cusp-config)> trigger condition call-from-service-provider	Creates a trigger condition and puts you into trigger command mode. In this case, the trigger that is being created is called “call-from-service-provider”.
Step 4	sequence <i>sequence-number</i> Example: se-10-1-0-0(cusp-config-trigger)> sequence 1	Creates a sequence with the specified number and puts you into trigger sequence command mode. The number indicates the order in which triggers are evaluated. In this case, the sequence that is being created is sequence number 1.
Step 5	in-network <i>network-name</i> Example: se-10-1-0-0(cusp-config-trigger-seq)> in-network service-provider	Optional. Specifies the incoming network name for the trigger condition. In this case, the incoming network is the “service-provider” network.
Step 6	mid-dialog Example: se-10-1-0-0(cusp-config-trigger-seq)> mid-dialog	Optional. A special trigger that bypasses routing policies on mid-dialog messages.

	Command or Action	Purpose
Step 7	end sequence Example: se-10-1-0-0(cusp-config-trigger-seq) > end sequence	Exits the trigger sequence command mode.
Step 8	end trigger condition Example: se-10-1-0-0(cusp-config-trigger) > end trigger condition	Exits the trigger command mode.

Example

In this example, Cisco Unified SIP Proxy only reacts based on the network the call came in on, so the triggers are simple.

```
se-10-1-0-0> cusp
se-10-1-0-0(cusp) > configure
se-10-1-0-0(cusp-config) > trigger condition call-from-service-provider
se-10-1-0-0(cusp-config-trigger) > sequence 1
se-10-1-0-0(cusp-config-trigger-seq) > in-network service-provider
se-10-1-0-0(cusp-config-trigger-seq) > end sequence
se-10-1-0-0(cusp-config-trigger) > end trigger condition

se-10-1-0-0(cusp-config) > trigger condition mid-dialog
se-10-1-0-0(cusp-config-trigger) > sequence 1
se-10-1-0-0(cusp-config-trigger-seq) > mid-dialog
se-10-1-0-0(cusp-config-trigger-seq) > end sequence
se-10-1-0-0(cusp-config-trigger) > end trigger condition
```

Configuring Server Groups

- [About Server Groups, page 4](#)
- [Summary Steps, page 5](#)
- [Detailed Steps, page 5](#)
- [Example, page 6](#)

About Server Groups

Server groups define the elements that Cisco Unified SIP Proxy interacts with for each network. The server group name that is used is inserted into the SIP URI of the outgoing request. Some devices, such as Cisco Unified Communications Manager, validate the URI of requests before processing, which means that the end device might need to be configured with a Fully Qualified Domain Name (FQDN) to allow for this.

Two of the fields for each individual element, q-value and weight, are important to use to specify the priorities of elements, and also for load balancing. Calls are routed to specific elements based on q-value. The element with the highest q-value receives all traffic routed to that server group. If multiple elements have the same q-value, traffic is distributed between them based on the load-balancing option used. The

default load-balancing is based on call-id, but weight can also be used. If weight is used, the percentage of traffic that an element receives is equal to its weight divided by the sum of up elements with the same q-value's weights. The sum of their weights does not need to equal 100. You can change the weights and q-values to configure a different priority or load-balancing scheme.

Summary Steps

1. **cusp**
2. **configure**
3. **server-group sip group *server-group-name network***
4. **element ip-address *ipaddress port {udp | tcp | tls} [q-value *q-value*] [weight *weight*]***
5. **lb-type {global | highest-q | request-uri | call-id | to-uri | weight }**
6. **end server-group**

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	server-group sip group <i>server-group-name network</i> Example: se-10-1-0-0(cusp-config)> server-group sip group sp.example.com service-provider	Creates a SIP server group and enters server group command mode. In this case, the server group being created is called “sp.example.com” and it uses the network called “service-provider”.
Step 4	element ip-address <i>ipaddress port {udp tcp tls} [q-value <i>q-value</i>] [weight <i>weight</i>]</i> Example: se-10-1-0-0(cusp-config-sg)> element ip-address 192.168.10.3 5060 tls q-value 1.0 weight 100	Creates an IP element for a SIP server group and determines the characteristics of the SIP server group. Note You can enter this command multiple times.

	Command or Action	Purpose
Step 5	lb-type {global highest-q request-uri call-id to-uri weight } Example: se-10-1-0-0(cusp-config-sg) > lb-type weight	Configures the load-balancing algorithm for the SIP server group. In this example, it specifies that the element will be selected proportional to its weight relative to the weights of other elements of the same q-value.
Step 6	end server-group Example: se-10-1-0-0(cusp-config-sg) > end server-group	Exits the server group command mode.

Example

```

se-10-1-0-0> cusp
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> server-group sip group sp.example.com service-provider
se-10-1-0-0(cusp-config-sg)> element ip-address 192.168.10.3 5060 tls q-value 1.0 weight
100
se-10-1-0-0(cusp-config-sg)> element ip-address 192.168.10.4 5060 tls q-value 1.0 weight
50
se-10-1-0-0(cusp-config-sg)> element ip-address 192.168.10.5 5060 tls q-value 1.0 weight
50
se-10-1-0-0(cusp-config-sg)> lb-type weight
se-10-1-0-0(cusp-config-sg)> end server-group

```

Configuring Route Tables

- [About Route Tables, page 6](#)
- [Summary Steps, page 6](#)
- [Detailed Steps, page 7](#)
- [Example, page 7](#)

About Route Tables

You must configure route tables to direct SIP requests to their appropriate destinations. Each route table consists of a set of keys that are matched based on the lookup policy. For example, each key might represent the prefix of a phone number dialed.

Summary Steps

1. **cusp**
2. **configure**
3. **route table** *table-name*
4. **key** *key* **response** *response-code*
5. **key** *key* **target-destination** *target-destination network*

6. end route table

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	route table table-name Example: se-10-1-0-0(cusp-config)> route table service-provider-table	Creates a route table and enters route table command mode. In this case, it creates a route table called "service-provider-table".
Step 4	key key response response-code Example: se-10-1-0-0(cusp-config-rt)> key * response 404	Assigns a response code to a lookup key. In this example, it returns a response of "404" to everything.
Step 5	key key target-destination target-destination network Example: se-10-1-0-0(cusp-config-rt)> key 510 target-destination cube-sp.example.com cube-sp	Replaces the key part of the target destination with a specified value. Note You can enter this command multiple times.
Step 6	end route table Example: se-10-1-0-0(cusp-config-rt)> end route table	Exits the route table command mode.

Example

```

se-10-1-0-0> cusp
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> route table service-provider-table
se-10-1-0-0(cusp-config-rt)> key * response 404
se-10-1-0-0(cusp-config-rt)> key 510 target-destination cube-sp.example.com cube-sp
se-10-1-0-0(cusp-config-rt)> end route table

```

Configuring Normalization Policies

Normalization policies modify SIP messages to account for incompatibilities between networks. In this case, the service provider cannot handle phone numbers with the escape sequence “91,” so the sequence must be removed from the request-uri and TO header.

- [Summary Steps, page 8](#)
- [Detailed Steps, page 8](#)
- [Example, page 9](#)

Summary Steps

1. **cusps**
2. **configure**
3. **policy normalization** *policy_name*
4. **uri-component update request-uri** {user | host | host-port | phone | uri} {all | match-string} *replace-string*
5. **uri-component update header** {first | last | all} {user | host | host-port | phone | uri} {all | match-string} *replace-string*
6. **end policy**

Detailed Steps

	Command or Action	Purpose
Step 1	cusps Example: se-10-1-0-0> cusps	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusps)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	policy normalization <i>policy-name</i> Example: se-10-1-0-0(cusps-config)> policy normalization outgoing-norm-policy	Creates a normalization policy and enters policy normalization command mode. In this example, the normalization policy is called “outgoing-norm-policy”.
Step 4	uri-component update request-uri {user host host-port phone uri} {all match-string} <i>replace-string</i> Example: se-10-1-0-0(cusps-config-norm)> uri-component update request-uri user ^91 ""	Configures a normalization policy step that updates a URI component field within a request URI.

	Command or Action	Purpose
Step 5	<pre>uri-component update header {first last all} {user host host-port phone uri} {all match-string} replace-string</pre> <p>Example: se-10-1-0-0(cusp-config-norm) > uri-component update TO all user ^91 ""</p>	Configures a normalization policy step that updates a URI component field within a header of the source message.
Step 6	<pre>end policy</pre> <p>Example: se-10-1-0-0(cusp-config-norm) > end policy</p>	Exits policy normalization command mode.

Example

```
se-10-1-0-0> cusp
se-10-1-0-0(cusp) > configure
se-10-1-0-0(cusp-config) > policy normalization outgoing-norm-policy
se-10-1-0-0(cusp-config-norm) > uri-component update request-uri user ^91 ""
se-10-1-0-0(cusp-config-norm) > uri-component update TO all user ^91 ""
se-10-1-0-0(cusp-config-norm) > end policy
```

Configuring Lookup Policies

Lookup policies decide how the keys in the route tables are used. Each key represents the beginning of the phone number dialed because each policy states to match the user component of the request-uri against the keys in its route table. The user component of the request-uri is the phone number called. The rule used to match is prefix, which means that the longest prefix match in the route table is used. So if the dialed number is 510-1XX-XXXX, the call is sent to the cme.example.com server group. If the dialed number is 510-XXX-XXXX, the call is sent to the cucm.example.com server group. The four policies in the following example are identical, except that they each refer to their specific table.

- [Summary Steps, page 9](#)
- [Detailed Steps, page 10](#)
- [Example, page 10](#)

Summary Steps

1. **cusp**
2. **configure**
3. **policy lookup** *policy-name*
4. **sequence** *sequence-number table-name* **field** {in-network | local-ip-address | local-ip-port | remote-ip-address | remote-ip-port} | **header** {p-asserted identity| from | to | diversion| remote-party-id} | **request uri** [uri component {param| user | phone | host| host-port| uri}]
5. **rule** {exact | prefix | subdomain | subnet | fixed *length*} [case-insensitive]
6. **end sequence**

7. end policy

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	policy lookup <i>policy-name</i> Example: se-10-1-0-0(cusp-config)> policy lookup service-provider-policy	Creates a policy with the specified name and enters policy lookup command mode. In this case, creates a policy called “service-provider-policy”.
Step 4	sequence <i>sequence-number table-name field {in-network local-ip-address local-ip-port remote-ip-address remote-ip-port} header {p-asserted identity from to diversion remote-party-id} request uri [uri component {param user phone host host-port uri}]</i> Example: se-10-1-0-0(cusp-config-lookup)> sequence 1	Creates a sequence with the specified number and enters policy lookup sequence command mode. Sequences are performed according to the order of their number.
Step 5	rule { <i>exact prefix subdomain subnet fixed length</i> } [<i>case-insensitive</i>] Example: se-10-1-0-0(cusp-config-lookup-seq)> rule prefix	Creates a rule that determines the routing algorithm for the lookup policy. In this case, it creates a rule that specifies that the lookup policy searches for the longest prefix match.
Step 6	end sequence Example: se-10-1-0-0(cusp-config-lookup-seq)> end sequence	Exits policy lookup sequence command mode.
Step 7	end policy Example: se-10-1-0-0(cusp-config-lookup)> end policy	Exits policy lookup command mode.

Example

```

se-10-1-0-0> cusp
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> policy lookup service-provider-policy

```

```

se-10-1-0-0(cusp-config-lookup) > sequence 1 service-provider-table request-uri
uri-component user
se-10-1-0-0(cusp-config-lookup-seq) > rule prefix
se-10-1-0-0(cusp-config-lookup-seq) > end sequence
se-10-1-0-0(cusp-config-lookup) > end policy

```

Configuring Routing Triggers

Routing triggers correlate trigger conditions with lookup policies. A single policy is chosen based on which corresponding condition is matched. The conditions are evaluated in ascending order based on sequence number. The mid-dialog condition is the first one so that the policy step is skipped for mid-dialog messages. Based on the following configuration, after the INVITE message is successfully routed, all subsequent messages (which are mid-dialog) bypass routing policies.

- [Summary Steps, page 11](#)
- [Detailed Steps, page 11](#)
- [Example, page 12](#)

Summary Steps

1. **cusp**
2. **configure**
3. **trigger routing sequence** *sequence-number* {**by-pass** | **policy** *policy*} [**condition** *trigger-condition*]

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0 > cusp	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp) > configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	trigger routing sequence <i>sequence-number</i> { by-pass policy <i>policy</i> } [condition <i>trigger-condition</i>] Example: se-10-1-0-0(cusp-config) > trigger routing sequence 2 policy service-provider-policy condition call-from-service-provider	Associates a routing policy with a trigger condition. In this example, the second sequence follows the previously-created policy called “service-provider-policy” and the previously-created trigger called “call-from-service-provider”.

Example

```

se-10-1-0-0> cusp
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> trigger routing sequence 1 by-pass condition mid-dialog
se-10-1-0-0(cusp-config)> trigger routing sequence 2 policy service-provider-policy
condition call-from-service-provider
se-10-1-0-0(cusp-config)> trigger routing sequence 3 policy cube-sp-policy condition
call-from-cube-sp
se-10-1-0-0(cusp-config)> trigger routing sequence 4 policy cube-es-policy condition
call-from-cube-es
se-10-1-0-0(cusp-config)> trigger routing sequence 5 policy enterprise-policy condition
call-from-enterprise

```

Configuring Normalization Triggers

Normalization triggers correlate trigger conditions with normalization policies. There are two types of triggers: pre-normalization, which occurs before routing, and post-normalization, which occurs after routing. Similar to routing policies, a special policy bypasses normalization on mid-dialog messages.

- [Summary Steps, page 12](#)
- [Detailed Steps, page 12](#)
- [Example, page 13](#)

Summary Steps

1. **cusp**
2. **configure**
3. **trigger pre-normalization sequence** *sequence-number* {**by-pass** | **policy** *policy*} [**condition** *trigger-condition*]

Detailed Steps

	Command or Action	Purpose
Step 1	cusp Example: se-10-1-0-0> cusp	Enters Cisco Unified SIP Proxy EXEC mode.

	Command or Action	Purpose
Step 2	configure	Enters Cisco Unified SIP Proxy configuration mode.
	Example: se-10-1-0-0(cusp) > configure	
Step 3	trigger pre-normalization sequence <i>sequence-number</i> {by-pass policy <i>policy</i> } [condition <i>trigger-condition</i>]	Configures a pre-normalization algorithm for incoming SIP messages to a normalization policy. In this example, the second sequence follows the previously-created policy called “outgoing-norm-policy” and the previously-created trigger called “call-from-cube-sp”.
	Example: se-10-1-0-0(cusp-config) > trigger pre-normalization sequence 2 policy outgoing-norm-policy condition call-from-cube-sp	

Example

```
se-10-1-0-0> cusp
se-10-1-0-0(cusp) > configure
se-10-1-0-0(cusp-config) > trigger pre-normalization sequence 1 by-pass condition
mid-dialog
se-10-1-0-0(cusp-config) > trigger pre-normalization sequence 2 policy outgoing-norm-policy
condition call-from-cube-sp
```

Configuring Listen and Record-Route Ports

You must configure listen and record-route ports for each network. For the listen and record-route ports, the actual addresses of the Cisco Unified SIP Proxy module are used. The **sip record-route** command inserts the record-route header into outgoing requests. The **sip listen** command allows for Cisco Unified SIP Proxy to accept incoming requests on that port.

- [Summary Steps, page 13](#)
- [Detailed Steps, page 14](#)
- [Example, page 14](#)

Summary Steps

1. **cusp**
2. **configure**
3. **sip record-route** *network_name* **{tcp | tls | udp}** *ip_address* [*port*]
4. **sip listen** *network_name* **{tcp | tls | udp}** *ip_address* *port*

Detailed Steps

	Command or Action	Purpose
Step 1	<code>cusp</code> Example: <code>se-10-1-0-0> cusp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-1-0-0(cusp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>sip record-route network_name {tcp tls udp} ip_address [port]</code> Example: <code>se-10-1-0-0(cusp-config)> sip record-route service-provider udp 10.10.10.99 5060</code>	Enables record-routing for a SIP network. In this example, the “service-provider” network is associated with a record-route configuration and the IP address that populates the record-route header field is “10.10.10.99” and the port that populates the record-route header is 5060.
Step 4	<code>sip listen network_name {tcp tls udp} ip_address port</code> Example: <code>se-10-1-0-0(cusp-config)> sip listen service-provider udp 10.10.10.99 5060</code>	Creates a listener that listens for SIP traffic on a specific SIP network, host, and port.

Example

```
se-10-1-0-0> cusp
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> sip record-route service-provider udp 10.10.10.99 5060
se-10-1-0-0(cusp-config)> sip listen service-provider udp 10.10.10.99 5060
```

Configuring a Hostname

If the upstream element is using DNS SRV for routing to the two Cisco Unified SIP Proxies in a network, you must configure the two Cisco Unified SIP Proxies to have the same FQDN by entering the **sip alias** command in Cisco Unified SIP Proxy configuration mode on both Cisco Unified SIP Proxies.

- [Summary Steps, page 14](#)
- [Detailed Steps, page 15](#)
- [Example, page 15](#)

Summary Steps

1. `cusp`

2. **configure**
3. **sip alias** *hostname*

Detailed Steps

	Command or Action	Purpose
Step 1	cusps Example: se-10-1-0-0> cusps	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	configure Example: se-10-1-0-0(cusp)> configure	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	sip alias <i>hostname</i> Example: se-10-1-0-0(cusp-config)> sip alias <i>myhost</i>	Configures the hostname of this instance.

Example

```
se-10-1-0-0> cusps
se-10-1-0-0(cusp)> configure
se-10-1-0-0(cusp-config)> sip alias myhost
```

Configuring Transport Layer Security (TLS)

- [Creating and Importing a Signed Certificate, page 15](#)
- [Creating and Importing a Self-Signed Certificate, page 18](#)
- [Updating Web Session with an Imported Signed Certificate, page 22](#)
- [Configuring TLS on Cisco Unified SIP Proxy, page 23](#)

Creating and Importing a Signed Certificate

Cisco Unified SIP Proxy supports TLS, Transmission Control Protocol (TCP), and User Datagram Protocol (UDP). Establishing TLS connections requires some extra steps because the connections require authentication using signed certificates.

- [Prerequisites, page 16](#)
- [Summary Steps, page 16](#)
- [Detailed Steps, page 16](#)
- [Example of Creating a Signed Certificate, page 17](#)

Prerequisites

You need an SFTP server or HTTP to import certificate requests.

Summary Steps

1. **configure terminal**
2. **crypto key generate [rsa {label *label-name* | modulus *modulus-size*} | default]**
3. **crypto key certreq label *label-name* url {sftp: | http:}**
4. **crypto key import rsa label *label-name* {der url {sftp: | http: } | pem { terminal | url {sftp: | http: }} [default]**
5. **crypto key import cer label *mykey* url sftp:**
6. **offline**
7. **reload**

Detailed Steps

	Command or Action	Purpose
Step 1	configure terminal Example: se-10-1-0-0# configure terminal	Enters configuration mode.
Step 2	crypto key generate [rsa {label <i>label-name</i> modulus <i>modulus-size</i>} default] Example: se-10-1-0-0(config) > crypto key generate rsa label mykey modulus 512 default	Creates an RSA private key.
Step 3	crypto key certreq label <i>label-name</i> url {sftp: http:} Example: se-10-1-0-0(config) > crypto key certreq label mykey url sftp:	Creates a certificate request to be signed.
Step 4	crypto key import rsa label <i>label-name</i> {der url {sftp: http: } pem { terminal url {sftp: http: }} [default] Example: se-10-1-0-0(config) > crypto key import trustcacert label rootCA url sftp:	After the certificate request is signed, imports the trusted certificate authority (CA) certificate that you used to sign the request.

	Command or Action	Purpose
Step 5	<pre>crypto key import rsa label <i>label-name</i> {der url {sftp: http: } pem { terminal url {sftp: http: }} [default]</pre> <p>Example: se-10-1-0-0(config)> crypto key import cer label mykey url sftp:</p>	After the root CA is imported, imports the signed certificate.
Step 6	<pre>offline</pre> <p>Example: se-10-1-0-0> offline !!!WARNING!!!: Putting the system offline will terminate all active calls. Do you wish to continue[n]?: y</p>	Initiates Cisco Unified SIP Proxy offline mode.
Step 7	<pre>reload</pre> <p>Example: se-10-1-0-0(offline)> reload</p>	Restarts the Cisco Unified SIP Proxy system and enables Cisco Unified SIP Proxy to verify the imported trusted certificate.

Example of Creating a Signed Certificate

```
se-10-1-0-0# configure terminal
se-10-1-0-0(config)> crypto key generate rsa label mykey modulus 512 default
Key generation in progress. Please wait...
The label name for the key is mykey

se-10-1-0-0(config)> crypto key certreq label mykey url sftp:
Address or name of remote host? test:test123@192.168.202.216
Username (ENTER if none)? anonymous
Password (not shown)?
Destination path? netmod/mykey.csr
Uploading CSR file succeed

se-10-1-0-0(config)> crypto key import trustcacert label rootCA url sftp:
Import certificate file...
Address or name of remote host? test:test123@192.168.202.216
Source filename? netmod/rootCA/cacert.pem
1212 bytes received.

se-10-1-0-0(config)> crypto key import cer label mykey url sftp:
Import certificate file...
Address or name of remote host? test:test123@192.168.202.216
Source filename? netmod/mycert.cer
952 bytes received.
Import succeeded
```

What To Do Next

- Import the trusted CA certificates for any of the TLS peer elements.

Creating and Importing a Self-Signed Certificate

- [Summary Steps, page 18](#)
- [Detailed Steps, page 19](#)
- [Example, page 21](#)

Summary Steps

1. **vim** *<filename>* (This is an example only. You can use any text editor as such.)
2. **openssl req -new -newkey rsa:2048 -nodes -keyout** *<key>* **-out** *<csr>* **-config** *<configuration file name>*
3. **openssl x509 -req -days** *<days>* **-in** *<csr>* **-signkey** *<key>* **-out** *<certificate>*
4. **configure terminal**
5. **crypto key import trustcert label** *<label_name>* **terminal**

**Note**

Execute the steps 4 and 5 on the Unified SIP Proxy CLI command. Use a different host to run the steps 1 through 3, such as Linux, where OpenSSL is available.

Detailed Steps

	Command or Action	Purpose
Step 1	<p><code>vim <filename></code> (This is an example only. You can use any text editor as such.)</p> <p>Example:</p> <pre>Linux-server-test\$ vim abc distinguished_name = req_distinguished_name [req_distinguished_name] countryName = Country Name (2 letter code) countryName_default = US countryName_min = 2 countryName_max = 2 stateOrProvinceName = State or Province Name (full name) stateOrProvinceName_default = California localityName = Locality Name (eg, city) localityName_default = San Jose organizationName = Organization Name (eg, company) organizationName_default = Cisco Systems, Inc. organizationalUnitName = Organizational Unit Name (eg, section) organizationalUnitName_default = Cisco Webex commonName = Common Name (eg, YOUR name) commonName_max = 64 emailAddress = Email Address emailAddress_default = csg-avops@cisco.com emailAddress_max = 40</pre>	On a Linux server, create a configuration file.
Step 2	<pre>openssl req -new -newkey rsa:2048 -nodes -keyout <key> -out <csr> -config <configuration file name></pre> <p>Example:</p> <pre>openssl req -new -newkey rsa:2048 -nodes -keyout me90sjvce001.webex.com.key -out me90sjvce001.webex.com.csr -config abc</pre>	Generate key and csr pair.
Step 3	<pre>openssl x509 -req -days <days> -in <csr> -signkey <key> -out <certificate></pre> <p>Example:</p> <pre>openssl x509 -req -days 720 -in me90sjvce001.webex.com.csr -signkey me90sjvce001.webex.com.key -out me90sjvce001.webex.com.cer</pre>	Sign the CSR file with your own key.

Command or Action	Purpose
<p>Step 4</p> <pre>configure terminal</pre> <p>Example: se-10-0-0-0> configure terminal</p>	<p>Log in to Cisco Unified SIP Proxy and enter the configuration mode.</p>
<p>Step 5</p> <pre>crypto key import trustcert label <label_name> terminal</pre> <p>Example: se-10-0-0-0(config)# crypto key import trustcert label sample_cert terminal</p> <pre>% Self-signed CA certificate: -----BEGIN CERTIFICATE----- MIIDLjCCAhagAwIBAgIBATANBgkqhkiG9w0BAQUFADAwMS4wLAYDVQQ DEyVJT1Mt U2VsZi1TaWduZWQtQ2VydGlmawNhdGUtMzc4ODk3MTYzMB4XDTE3MDE xODA2MzYy N1oXDTIwMDEwMTAwMDAwMFowMDEuMCwGA1UEAxMlSU9TLVNlbG9YtU21 nbmVklLUNl cnRpZmljYXR1LlTM3ODg5NzE2MzCCAS1wDQYJKoZIhvcNAQEBBQADggE PADCCAQoC ggEBAI/k+Jl/RdXkUu3aBp8qIMVA7ifpRehG9AXJKlqOafc9Ly92hwn xeLGV/U8k Xlo/fuoyaNyLIu9GwS1BfvM3yH0thhX+T5RHgcj3s1Yct16HUW93M/E JYluo5RDE NAXJ2UXa/Ut19ZGjCvat8h3N4QduP2ulIsK1IqyYLRwD1fiSNFrdZB 2zzIE1M7g eeitn4n1INHivtH0jOmO4En/FjUa3YPCFEyB1/U17YGWN/GOHguCsZ1 uL8W9yAT5 PqluaipVxWoCzXCb74BSxTJiHs/tmpGkIH57RvLKxgqr5vHXCOsWsQ 6/C9z6My3 tvE6dtLHuP2Rgr6r+3xOhKdqcheCAwEAAANTMFEwDwYDVR0TAQH/BAU wAwEB/zAf BgNVHSMEGDAwBSIzQ0OrJrnxzR8LEQ2VIIffVfP02DadBgNVHQ4EFgQ UiM0Djqya 58c0fCxEN1SCH1RaTtgwDQYJKoZIhvcNAQEFBQADggEBAByrhWv9DZ 0sZZt7Smc o5pgIIFFOtGQYc+ei7H6QNzW5iNSZbSPBAIpmVMQWHVS6cOvJ/N63ay Q+1TN3rZm wmOU9tFExBzjge0nX+Go+0KdWNNQG4XO8SU7BKwM8iWTsM1jt1j6cb9 Bv1kMgXW0 5K5AzVYTbaTP/OMoMCsuOJts+GI/Q82H7t1IbdJFbbu3iVEN+gf3coU rHa4X2jLr K3EVLniCLedkcXdy5TppTvQM9j1FzkGMiRwAlFlp/Vh2CtigJy8GZ4p Wt5QzjO6m KuP6FZxGPNe8F5BsFCWNM5aHPa8MUq1FKZMuUb50w43SZRT3xfI2WLv 1yd49f65T mBA= -----END CERTIFICATE-----</pre>	<p>Import the Self-Signed Certificate to Cisco Unified SIP Proxy. Copy the content of the certificate created and paste it when prompted.</p>

Updating Web Session with an Imported Signed Certificate

From Cisco Unified SIP Proxy Release 10.1 onwards, HTTPS is enabled by default. You need not manually generate a crypto key and pass it to the web session security to enable HTTPS. However, you should be able to import a signed certificate that you generated externally, and update the web session with this new key label.

Summary Steps

1. **configure**
2. **crypto key import rsa label *label-name* {der url {sftp: | http: } | pem { terminal | url {sftp: | http: }} [default]**
3. **web session security keylabel *labelname***
4. **end**

Detailed Steps

	Command or Action	Purpose
Step 1	configure terminal Example: se-10-1-0-0# configure terminal	Enters configuration mode.
Step 2	crypto key import rsa label <i>label-name</i> {der url {sftp: http: } pem { terminal url {sftp: http: }} [default] Example: se-10-1-0-0(config) > crypto key import cer label mykey url sftp:	Imports the signed certificate.
Step 3	web session security keylabel <i>labelname</i> Example: se-10-1-0-0(cusp-config) > web session security keylabel mykey	Associates a security key for HTTPS.
Step 4	end Example: se-10-1-0-0(cusp-config) > end	Exits to privileged EXEC mode.

Example of Updating Web Session with an Imported Signed Certificate

```
se-10-1-0-0# configure terminal
se-10-1-0-0(config) > crypto key import cer label mykey url sftp:
Import certificate file...
Address or name of remote host? 192.0.2.2
```

```
Source filename? netmod/mycert.cer
952 bytes received.
Import succeeded
se-10-1-0-0(cusp-config) > web session security keylabel mykey
se-10-1-0-0(cusp-config) > end
```

Configuring TLS on Cisco Unified SIP Proxy

After you import the certificates, you must enable TLS connections. If you want more security, you can create a list of trusted peers. If you create such a list, only connections from those peers are accepted. The peer's hostname entry must be the peer's subjectAltName in its certificate. If subjectAltName is not used in the certificate, the peer's hostname entry must be CN.

- [Summary Steps, page 23](#)
- [Detailed Steps, page 23](#)
- [Example of Configuring TLS, page 24](#)

Summary Steps

1. `cusp`
2. `configure`
3. `sip tls`
4. `sip tls trusted-peer {peer's-hostname}`
5. `sip tls connection-setup-timeout {value in seconds}`
6. `sip tls [v1.0 | v1.1 | v1.2]`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>cusp</code> Example: se-10-1-0-0 > <code>cusp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: se-10-1-0-0(cusp) > <code>configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>sip tls</code> Example: se-10-1-0-0(cusp-config) > <code>sip tls</code>	Enables the use of SIP TLS connections with other SIP entities, providing secure communication over the Internet.

	Command or Action	Purpose
Step 4	<pre> sip tls trusted-peer {peer's-hostname} Example: se-10-1-0-0(cusp-config) > sip tls trusted-peer example.com </pre>	Creates a list of trusted peers.
Step 5	<pre> sip tls connection-setup-timeout {value in seconds} Example: se-10-1-0-0(cusp-config) > sip tls connection-setup-timeout <1-60> </pre>	It is the time specified in Cisco Unified SIP Proxy by the user to establish connection with the trusted peer. The default value is 1 second. The range of values is 1 to 60 seconds.
Step 6	<pre> sip tls [v1.0 v1.1 v1.2] Example: se-10-1-0-0(cusp-config) > sip tls v1.0 </pre>	Enables SIP TLS versions. The default value is all TLS versions with fall-back. The connection between the user and the trusted peer fails to establish when the user tries to connect using the TLS version that the trusted peer does not support. In the case where the trusted peer does not support a specific TLS version, the user retries the connection with the trusted peer using the downgraded version of TLS. For example, if the trusted peer does not support TLS v1.2, then the user retries the connection using TLS v1.1.

Example of Configuring TLS

```

se-10-1-0-0> cusp
se-10-1-0-0(cusp) > configure
se-10-1-0-0(cusp-config) > sip tls
se-10-1-0-0(cusp-config) > sip tls trusted-peer example.com
se-10-1-0-0(cusp-config) > sip tls connection-setup-timeout <1-60>
se-10-1-0-0(cusp-config) > sip tls v1.2

```



Note

From Cisco Unified Proxy Release 10.1 onwards, HTTPS is enabled by default. You need not manually generate a crypto key and pass it to the web session security to enable HTTPS. Cisco Unified Proxy Release 10.1 supports only TLS v1.2 for HTTPS. If you delete the certificate from the web session security and try to login through HTTP, you will be redirected to HTTPS. Only the latest connection is retained and the remaining connections are logged out.

Configuring Lite Mode

One of the ways you can configure the performance of the Cisco Unified SIP Proxy is to switch the module to Lite Mode. In Lite Mode, which requires you to disable record-route, the module's performance is boosted. In standard mode, the module processes calls up to the licensed limit.

By default, the module is in standard mode.

For information on the performance difference when using Lite Mode versus standard mode, see the [Release Notes for Cisco Unified SIP Proxy Release 10.1](#).

- [Summary Steps, page 25](#)
- [Detailed Steps, page 25](#)
- [Example, page 25](#)

Summary Steps

1. `culp`
2. `configure`
3. `lite-mode`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: se-10-1-0-0> <code>culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: se-10-1-0-0(culp)> <code>configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>lite-mode</code> Example: se-10-1-0-0(culp-config)> <code>lite-mode</code>	Puts the Cisco Unified SIP Proxy module into Lite Mode.

Example

The following example puts the module into Lite Mode:

```
se-10-1-0-0> culp
se-10-1-0-0(culp)> configure
se-10-1-0-0(culp-config)> lite-mode
```

Configuring Performance Control

- [About Performance Control, page 26](#)
- [Summary Steps, page 26](#)
- [Detailed Steps, page 26](#)
- [Example, page 10](#)

About Performance Control

One of the ways you can configure the performance of the Cisco Unified SIP Proxy is to restrict the number of calls that the Cisco Unified SIP Proxy can handle.

Summary Steps

1. `culp`
2. `configure`
3. `call-rate-limit limit`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>culp</code> Example: <code>se-10-1-0-0> culp</code>	Enters Cisco Unified SIP Proxy EXEC mode.
Step 2	<code>configure</code> Example: <code>se-10-1-0-0(culp)> configure</code>	Enters Cisco Unified SIP Proxy configuration mode.
Step 3	<code>call-rate-limit limit</code> Example: <code>se-10-1-0-0(culp-config)> call-rate-limit 50</code>	Sets the maximum call rate that the Cisco Unified SIP Proxy can handle.

Example

The following example limits the number of calls that the system can process to 50:

```
se-10-1-0-0> culp
se-10-1-0-0(culp)> configure
se-10-1-0-0(culp-config)> call-rate-limit 50
```

Committing the Configuration

Now you must commit the configuration. Committing the configuration serves two purposes: the configuration becomes active, and is persisted.

- To see the current active configuration, enter the **show configuration active** command.
- To see what the active configuration will be after you commit your changes, enter the **show configuration candidate** command.
- To commit the configuration for this example, enter the following command:

```
se-10-1-0-0(cusp-config) > commit
```




Configuring Users and Groups

All configuration and administration functions for Cisco Unified SIP Proxy are available through the graphical user interface (GUI). However, you may find using the command-line interface (CLI) is more efficient than using the GUI. For example, you may want to create a script to configure a large number of users for a specific system. In this case, the CLI can be more efficient.

This chapter describes the commands for the following tasks and contains the following sections:

- [Adding and Modifying a User, page 1](#)
- [Adding and Modifying a Group, page 5](#)

Adding and Modifying a User

Users, or users, configured in Cisco Unified Communications Manager can be imported to the Cisco Unified SIP Proxy database.

The procedure described in this section allows you to create a new user in the system. Use the same procedures to modify an existing user's properties.

The maximum number of users is determined by the license of the module.

**Note**

Ensure not to use reserved keywords or any name that may conflict with the regular users or process names in Linux (root, bin, daemon, adm, lp, sync, shutdown, halt, mail, operator, games, and so on.) while creating the users.

Required Data for This Procedure

The following information is required for adding or modifying a user:

- Username—The user ID. The username must be at least 3 and no more than 32 characters. Cisco Unified SIP Proxy allows only letters, numbers, underscore (_), dot (.), and dash (-) in user IDs. User IDs must start with a letter. Do not use spaces in the username.
- (Optional) Full name—First and last name of the user. It must start and end with quotation marks (“ ”).
- (Optional) Group—Name of an existing group in which this user is a member.

- (Optional) Password—Password for logging into the Cisco Unified SIP Proxy GUI. The password must include a minimum length ranging from 8 through 64 characters. There is no limit on the maximum number of characters. Spaces are not allowed. A valid password should have at least one uppercase letter, one lowercase letter, one number, and a symbol.
- (Optional) PIN—No PIN is required for vCUSP users.

SUMMARY STEPS

EXEC mode:

1. **username** *userid* [**create** | **delete** | **fullname** [**first** "*first-name*" | **last** "*last-name*" | **display** "*full-name*"] | **group** *group-name* | **language** "*language*" | **password** "*password*" | **pin** *number*]
2. **show users**
or
show user detail **username** *userid*
3. **copy running-config startup-config**

Configuration mode:

1. **config t**
2. **username** *userid* [**create** | **onenumber** *phone-number* | **onenumberE164** *full-number*]
3. **exit**
4. **show users**
or
show user detail **username** *userid*
5. **copy running-config startup-config**

DETAILED STEPS

EXEC mode:

	Command or Action	Purpose
Step 1	<pre>username <i>userid</i> [create delete fullname [first "<i>first-name</i>" last "<i>last-name</i>" display "<i>full-name</i>"] group <i>group-name</i> language "<i>language</i>" password "<i>password</i>" pin <i>number</i>]</pre> <p>Example:</p> <pre>se-10-0-0-0# username user1 create se-10-0-0-0# username user2 fullname display "User 2" se-10-0-0-0# username user2 group sales se-10-0-0-0# username user2 password "Green123!" se-10-0-0-0# username user2 pin 4444 se-10-0-0-0# username user2 delete</pre>	<p>Creates the user with the specified user ID. The optional parameters configure more information for the user:</p> <ul style="list-style-type: none"> • userid—User ID of the user. The user ID must be at least 2 and no more than 31 characters. Cisco Unified SIP Proxy allows only letters, numbers, underscore (_), dot (.), and dash (-) in user IDs. Do not use spaces in the username. User IDs must start with a letter. • create—Creates the user with no other information. • delete—Deletes an existing user. • fullname—Specifies a full name for this user. This full name appears on telephone displays. • group—Associates this user with an existing group. • language—Specifies the default language used for the specified user. See the Release Notes for Cisco Unified SIP Proxy for a list of available languages. • password—Specifies a password for this user. The <i>password</i> value must be entered within quotation marks (" "). Spaces are not allowed. Acceptable password characters are lowercase letters a to z, uppercase letters A to Z, digits 0 to 9, and the following symbols: - , . + = _ ! @ # \$ ^ * () ? / ~ < > & %. • pin—Specifies a personal identification number (PIN) for this user. The user enters this number from the telephone when accessing the voice-mail system. The PIN can contain a maximum number of 16 digits. The asterisk (*) and pound sign (#) cannot be used.

	Command or Action	Purpose
Step 2	<pre>show users</pre> <p>or</p> <pre>show user detail username <i>userid</i></pre> <p>Example: <pre>se-10-0-0-0# show user detail username user2</pre></p>	<p>Displays a list of user IDs for all users configured on the system.</p> <p>or</p> <p>Displays the detailed information configured for the specified user.</p>
Step 3	<pre>copy running-config startup-config</pre> <p>Example: <pre>se-10-0-0-0# copy running-config startup-config</pre></p>	<p>Copies the configuration changes to the startup configuration.</p>

Examples

The following output illustrates the **show users** and **show user detail username** commands:

```
se-10-0-0-0# show users
user1
user2

se-10-0-0-0# show user detail username user2
Full Name:      User 2
First Name:
Last Name:      user2
Nickname:       user2
Phone:
Phone (E.164) :
Language:       en_ENU
se-10-0-0-0#
```

Configuration mode:

	Command or Action	Purpose
Step 1	<pre>config t</pre> <p>Example: <pre>se-10-0-0-0# config t</pre></p>	<p>Enters configuration mode.</p>
Step 2	<pre>username <i>userid</i> [create phonenum <i>phone-number</i> phonenumE164 <i>full-number</i>]</pre> <p>Example: <pre>se-10-0-0-0(config)# username user3 create se-10-0-0-0(config)# username user3 password Usr@50180</pre></p>	<p>Creates the user with the specified user ID. The optional parameters configure more information for the user:</p> <ul style="list-style-type: none"> userid—User ID of the user. The user ID must be at least 2 and no more than 31 characters. Cisco Unified SIP Proxy allows only letters, numbers, underscore (_), dot (.), and dash (-) in user IDs. Do not use spaces in the username. User IDs must start with a letter. create—Creates the user with no other information. password—Specifies a password for this user.

	Command or Action	Purpose
Step 3	exit Example: se-10-0-0-0(config)# exit	Exits configuration mode.
Step 4	show users or show user detail username userid Example: se-10-0-0-0# show user detail username user2	Displays a list of user IDs for all users configured on the system. or Displays the detailed information configured for the specified user.
Step 5	copy running-config startup-config Example: se-10-0-0-0# copy running-config startup-config	Copies the configuration changes to the startup configuration.

Examples

The following example illustrates configuring a user and the output from the **show** commands:

```
se-10-0-0-0(config)# username user3 create
se-10-0-0-0(config)# username user3 password User@5521
se-10-0-0-0(config)# exit
se-10-0-0-0# show users
user1
user2
user3
se-10-0-0-0# show user detail username user3
Full Name:          User 3
First Name:
Last Name:          user3
Nickname:           user3
Password:           *****
Language:           en_ENU
```

Adding and Modifying a Group

A group is a collection of users, usually with a common function or purpose, such as sales, main office, customer service, or technicians. A group has the following characteristics:

- Members of the group can be individual users or other groups.
- The group is assigned an extension.
- A group can have zero or more users as owners. An owner of a group can add and delete members. Additionally, an owner can add and delete other owners to the group.
- Members can belong to more than one group.
- Members can be added to the group using the configuration mode **groupname** command or using the EXEC mode **username** command. See [“Adding and Modifying a User” on page 1](#) for details about the **username** command.



Note Users must exist before being added to a group. See [“Adding and Modifying a User” on page 1](#) to configure the user’s detailed information.

The following procedure allows you to create a new group in the system.

Required Data for This Procedure

The following information is required to define a group:

- EXEC mode:
 - Name of group
 - (Optional) Description of group
 - (Optional) Full name of group
- Configuration mode:
 - Name of group
 - (Optional) One or more existing user or group IDs to be added as members
 - (Optional) One or more existing user IDs to be added as owners
 - (Optional) Extension or telephone number of the group
 - (Optional) Full E.164 telephone number of the group

SUMMARY STEPS

EXEC mode:

1. **groupname** *userid* [**create** | **delete** | **description** "*description*" | **fullname** "*full-name*"]
2. **show groups**
or
show group detail *groupname* *groupid*
3. **copy running-config startup-config**

Configuration mode:

1. **config t**
2. **groupname** *groupid* [**member** *username* | **owner** *ownername* | **phonenumber** *phone-number* | **phonenumberE164** *full-number*]
3. **exit**
4. **show groups**
or
show group detail *groupname* *groupid*
5. **copy running-config startup-config**

DETAILED STEPS

EXEC mode:

	Command or Action	Purpose
Step 1	<p>groupname <i>groupid</i> [create delete description "<i>description</i>" fullname "<i>full-name</i>"]</p> <p>Example: se-10-0-0-0# groupname sales fullname "Sales Department" se-10-0-0-0# groupname sales description "Retail Sales Department" se-10-0-0-0# groupname sales delete</p>	<p>Creates the group with the <i>groupid</i> value. The optional parameters configure more information for the group:</p> <ul style="list-style-type: none"> • create—Creates the group with no other information. • delete—Deletes an existing group. • description—Specifies a description of the group. • fullname—Specifies a long name for the group.
Step 2	<p>show groups</p> <p>or</p> <p>show group detail <i>groupname</i> <i>groupid</i></p> <p>Example: se-10-0-0-0# show group detail groupname sales</p>	<p>Displays a list of group IDs for all configured groups. This command does not display the details for the groups.</p> <p>or</p> <p>Displays the detailed configuration information for the group <i>groupid</i> value.</p>
Step 3	<p>copy running-config startup-config</p> <p>Example: se-10-0-0-0# copy running-config startup-config</p>	<p>Copies the configuration changes to the startup configuration.</p>

Examples

The following example creates a group and displays the output of the **show** commands:

```

se-10-0-0-0# groupname sales fullname "Sales Department"
se-10-0-0-0# groupname sales description "CA office"

se-10-0-0-0# show groups
Administrators
sales

se-10-0-0-0# show group detail groupname sales
Full Name:      Sales Department
Description:    CA office
Phone:
Phone(E.164):
Language:      en_ENU
Owners:
Members:
se-10-0-0-0#

```

Configuration mode:

	Command or Action	Purpose
Step 1	<code>config t</code> Example: <code>se-10-0-0-0# config t</code>	Enters configuration mode.
Step 2	<code>groupname groupid [member username owner ownername phonenumber phone-number phonenumberE164 full-number]</code> Example: <code>se-10-0-0-0(config)# groupname sales member user1</code> <code>se-10-0-0-0(config)# groupname sales owner user2</code> <code>se-10-0-0-0(config)# groupname sales phonenumber 50163</code> <code>se-10-0-0-0(config)# groupname sales phonenumberE164 14445550163</code>	Creates the group with the <i>groupid</i> value. The optional parameters configure more information for the user: <ul style="list-style-type: none"> • member—Associates an existing user as a member of this group. Repeat this command to assign multiple users to the group. • owner—Specifies the owner of the group. The owner is not considered a member. If the owner is to have access to the group's voice mailbox, also assign the owner as a member. • phonenumber—Associates a number or extension with this group. No spaces or dashes are allowed. • phonenumberE164—Associates a telephone number and area code with this group. No spaces or dashes are allowed.
Step 3	<code>exit</code> Example: <code>se-10-0-0-0(config)# exit</code>	Exits configuration mode.
Step 4	<code>show groups</code> or <code>show group detail groupname groupid</code> Example: <code>se-10-0-0-0# show group detail groupname sales</code>	Displays a list of group IDs for all configured groups. This command does not display the details for the groups. Displays the detailed configuration information for the group <i>groupid</i> value.
Step 5	<code>copy running-config startup-config</code> Example: <code>se-10-0-0-0# copy running-config startup-config</code>	Copies the configuration changes to the startup configuration.

Examples

The following example adds an owner and two members to the group sales and assigns sales a phone number:


```
se-10-0-0-0# config t
se-10-0-0-0(config)# groupname sales member user1
se-10-0-0-0(config)# groupname sales member user2
se-10-0-0-0(config)# groupname sales owner user1
```



```
se-10-0-0-0(config)# groupname sales phonenumber 50163
se-10-0-0-0(config)# groupname sales phonenumberE164 12225550163
se-10-0-0-0(config)# exit

se-10-0-0-0(# show groups
Administrators
sales

se-10-0-0-0# show group detail groupname sales
Full Name:           Sales Department
Description:         CA office
Phone:               50163
Phone(E.164):       12225550163
Language:            en_ENU
Owners:              user1
Members:             user1 user2
se-10-0-0-0(#
```

Backing Up and Restoring Data



Note

Setting up a backup server is part of the initial configuration process. If you have not already done this, see “[Setting Backup Parameters](#)” on page 18.

- [About Backing Up and Restoring Data, page 1](#)
- [Restrictions for Backing Up and Restoring Data, page 1](#)
- [Backing Up Files, page 2](#)
- [Restoring Files, page 4](#)
- [Related Topics, page 5](#)

About Backing Up and Restoring Data

Cisco Unified SIP Proxy backup and restore functions use an SFTP server to store and retrieve data. The backup function copies the files from the Cisco Unified SIP Proxy module to the SFTP server and the restore function copies the files from the SFTP server to the Cisco Unified SIP Proxy application. The SFTP server can reside anywhere in the network as long as the backup and restore functions can access it with an IP address or hostname.

We recommend that you back up your configuration files whenever you make changes to the system or application files. Do backups regularly to preserve configuration data.

The system supports the following types of backup:

- All—Backs up all files and data.
- Configuration—Backs up only system and application settings.
- Data—Backs up only routes and application data.

Restrictions for Backing Up and Restoring Data

- You must be in offline mode when you back up or restore the system, so we recommend performing these tasks when call traffic is least impacted. Offline mode terminates all calls.
- Cisco Unified SIP Proxy does not support the following backup and restore capabilities:
 - Scheduled backup and restore operations. The backup and restore procedures begin when the appropriate command is entered.

- Centralized message storage arrangement. Cisco Unified SIP Proxy backup files cannot be used or integrated with other message stores.
- Selective backup and restore. Only full backup and restore functions are available. Individual messages or other specific data can be neither stored nor retrieved.

Backing Up Files

- [About Backing Up Files, page 2](#)
- [Summary Steps, page 2](#)
- [Detailed Steps, page 3](#)
- [Examples, page 3](#)

About Backing Up Files

Cisco Unified SIP Proxy automatically assigns a backup ID to each backup. Although there are the three different types of backups, the system does not take into account the type of backup when generating the backup ID. Therefore, you will never have two backups with the same backup ID, even if one is a configuration file and the other a data file.

To determine the backup ID of the file you want to restore, use the **show backup server** or **show backup history** commands in either EXEC or offline mode. Those commands list all available backup copies on the remote backup server and their respective backup IDs.

Summary Steps

1. **offline**
2. **backup category {all | configuration | data}**
3. **continue**
4. **show backup history**
5. **show backup server**

Detailed Steps

	Command or Action	Purpose
Step 1	offline Example: <pre>se-10-1-0-0# offline !!!WARNING!!!: Putting the system offline will terminate all active calls. Do you wish to continue[n]? : y</pre>	Enters offline mode. All calls are terminated. Note Cisco Unified SIP Proxy still routes calls in offline mode.
Step 2	backup category {all configuration data} Example: <pre>se-10-1-0-0(offline)# backup category all se-10-1-0-0(offline)# backup category configuration se-10-1-0-0(offline)# backup category data</pre>	Specifies the type of data to be backed up and stored.
Step 3	continue Example: <pre>se-10-1-0-0(offline)# continue</pre>	Exits offline mode and returns the system to the previous online mode. The system begins processing new calls and voice messages.
Step 4	show backup history Example: <pre>se-10-1-0-0> show backup history</pre>	Displays each backup file, its backup ID, the type of data stored in the file, and the success or failure of the backup procedure.
Step 5	show backup server Example: <pre>se-10-1-0-0> show backup server</pre>	Displays a list of the backup files available on the backup server. The files are grouped by category, with the date of each backup and the backup file ID.

Examples

The following examples display the output from the **show backup history** and **show backup server** commands:

```
se-10-1-0-0> show backup history

blade522> show backup history
#Start Operation
Category: Configuration
Backup Server: sftp://192.168.1.35/pub/cusp_backup
Operation: Backup
Backupid: 1
Date: Tue Sep 24 06:14:30 EDT 2019
Result: Success
Reason:
#End Operation

#Start Operation
Category: Configuration
Backup Server: sftp://192.168.1.35/pub/cusp_backup
Operation: Restore
```

```
Backupid: 1
Restoreid: 1
Date: Tue Sep 24 06:17:21 EDT 2019
Result: Success
Reason:
#End Operation

se-10-1-0-0> show backup server

Category: Data
Details of last 5 backups
Backupid: 1
Date: Tue Aug 21 10:55:52 PDT 2019
Description:
Backupid: 2
Date: Tue Aug 21 18:06:33 PDT 2019
Description:
Backupid: 3
Date: Tue Aug 21 19:10:32 PDT 2019
Description:
Category: Configuration
Details of last 5 backups
Backupid: 1
Date: Tue Aug 22 10:55:48 PDT 2019
Description:
Backupid: 2
Date: Tue Aug 29 18:06:27 PDT 2019
Description:
Backupid: 3
Date: Tue Aug 29 19:10:29 PDT 2019
Description:

se-10-1-0-0>
```

Restoring Files

- [About Restoring Files, page 4](#)
- [Summary Steps, page 4](#)
- [Detailed Steps, page 5](#)

About Restoring Files

After you create the backup files, you can restore them when needed. Restoring is done in offline mode, which terminates all calls. You should therefore consider restoring files when call traffic is least impacted.

To determine the backup ID of the file you want to restore, use the **show backup server** or **show backup history** commands in either EXEC or offline mode.

Summary Steps

1. **show backup server**
2. **offline**

3. `restore id backup_ID category {all | configuration | data}`
4. `show backup history`
5. `reload`

Detailed Steps

	Command or Action	Purpose
Step 1	<pre>show backup server</pre> <p>Example: se-10-1-0-0> <code>show backup server</code></p>	Lists the data and configuration backup files. Look in the backup ID field for the revision number of the file that you want to restore.
Step 2	<pre>offline</pre> <p>Example: se-10-1-0-0# <code>offline</code> !!!WARNING!!!: Putting the system offline will terminate all active calls. Do you wish to continue[n]? : <code>y</code></p>	Enters offline mode. All calls are terminated. Note Cisco Unified SIP Proxy still routes calls in offline mode.
Step 3	<pre>restore id backup_ID category {all configuration data}</pre> <p>Example: se-10-1-0-0(offline)# <code>restore id 22 category all</code></p>	Specifies the backup ID value and the file type to be restored.
Step 4	<pre>show backup history</pre> <p>Example: se-10-1-0-0> <code>show backup history</code></p>	Displays the success or failure of backup and restore procedures, and also the backup IDs.
Step 5	<pre>reload</pre> <p>Example: se-10-1-0-0(offline)# <code>reload</code></p>	Activates the uploaded file information and restarts the Cisco Unified SIP Proxy system.

Related Topics

- For information about setting up the backup server as part of the initial configuration process, see [“Setting Backup Parameters” on page 18](#).
- For information on the CLI commands used to back up and restore the configuration, see the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.1](#).



Maintaining the Cisco Unified SIP Proxy System

- [Copying Configurations, page 1](#)
- [Checking Hard Disk Memory Wear Activity, page 3](#)

Copying Configurations

Use module EXEC commands to copy the startup configuration and running configuration to and from the hard disk on the Cisco Unified SIP Proxy module, the network SFTP server, and the network TFTP server.



Note

Depending on the specific TFTP server you are using, you might need to create a file with the same name on the TFTP server and verify that the file has the correct permissions before transferring the running configuration to the TFTP server.

- [Copying the Startup Configuration from the Hard Disk to Another Location, page 1](#)
- [Copying the Startup Configuration from the Network SFTP Server to Another Location, page 2](#)
- [Copying the Running Configuration from the Hard Disk to Another Location, page 2](#)
- [Copying the Running Configuration from the Network TFTP Server to Another Location, page 3](#)

Copying the Startup Configuration from the Hard Disk to Another Location

Starting in module EXEC mode, use the following command to copy the startup configuration on the hard disk to another location:

```
copy startup-config {sftp: user-id:password@sftp-server-url | tftp:tftp-server-url}
```

Syntax Description

<code>sftp: user-id:password@</code>	Username and password for the SFTP server. Include the colon (:) and the at sign (@) in your entry.
<code>sftp-server-url</code>	Absolute URL of the SFTP server including directory and filename. An example is <code>userid:password@sftp-server-address/directory/filename</code> .
<code>tftp:tftp-server-url</code>	URL of the TFTP server including directory and filename. An example is <code>tftp://server/dir/filename</code> .

This command is interactive and prompts you for the information. You cannot enter the parameters in one line. In this example, the startup configuration is copied to the SFTP server, which requires a username and password to transfer files. The startup configuration file is saved on the SFTP server with the filename “start”.

```
se-10-1-0-0> copy startup-config sftp
Address or name of remote host? test:test123@10.3.61.16/home/test/
Source filename? startup-config
```

The following example shows the startup configuration copied to the TFTP server, which does not require a username and password. The command saves the startup configuration in the TFTP directory called “configs” as a file called “temp_start”.

```
se-10-1-0-0> copy startup-config tftp
Address or name of remote host? tftp://server/dir/temp_start
Source filename? temp_start
```

Copying the Startup Configuration from the Network SFTP Server to Another Location

Starting in module EXEC mode, use the following command to copy the startup configuration on the network SFTP server to another location:

```
copy sftp: {nvram:startup-config | running-config | startup-config | system:running-config}
```

For a description of this command, see the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.2](#).

This command is interactive and prompts you for the information. You cannot enter the parameters in one line. The following example illustrates this process. In this example, the SFTP server requires a username and password. This command copies the file called “start” that resides in the SFTP server directory called “configs” to the startup configuration.

```
se-10-1-0-0> copy sftp: startup-config
!!!WARNING!!! This operation will overwrite your startup configuration.
Do you wish to continue[y]? y
Address or name or remote host? admin:messaging@tftp://server/configs
Source filename? start
```

Copying the Running Configuration from the Hard Disk to Another Location

Starting in module EXEC mode, use the following command to copy the running configuration on the hard disk to another location:

```
copy running-config {sftp: user-id:password@sftp://server/dir/filename | startup-config | tftp:tftp://server/dir/filename }
```

For a description of this command, see the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.1](#).

The command works in two ways, depending on where you are copying the command:

- If you copy the running configuration to the startup configuration, enter the command on one line, like in the following example:

```
se-10-1-0-0> copy running-config startup-config
```

- If you copy the running configuration to the SFTP or TFTP server, this command becomes interactive and prompts you for the information. You cannot enter the parameters in one line. In the following example, the running configuration is copied to the SFTP server, which requires a username and password. The running configuration is copied to the directory called “configs” as a file called “saved_start”.

```
se-10-1-0-0> copy running-config sftp:
Address or name of remote host? admin:messaging@sftp://server/configs
Source filename? saved_start
```

Copying the Running Configuration from the Network TFTP Server to Another Location

Starting in module EXEC mode, use the following command to copy the running configuration from the network TFTP server to another location:

```
copy tftp: {running-config | startup-config} tftp://server/dir/filename
```

Syntax Description

running-config	Active configuration on hard disk.
startup-config	Startup configuration on hard disk.
<i>tftp-server-url</i>	URL of the TFTP server.

This command is interactive and prompts you for the information. You cannot enter the parameters in one line. The following example illustrates this process. In this example, the file called “start” that resides in the directory called “configs” on the TFTP server is copied to the startup configuration.

```
se-10-1-0-0> copy tftp: startup-config
!!!WARNING!!! This operation will overwrite your startup configuration.
Do you wish to continue[y]? y
Address or name of remote host? tftp://server/configs
Source filename? start
```

Checking Hard Disk Memory Wear Activity

Cisco Unified SIP Proxy tracks the use and wear of the hard disk memory as log and trace data are saved to the module. To display this data, use the **show interfaces** command in module EXEC mode.

The following is sample output:

```
se-10-1-0-0> show interfaces
GigabitEthernet 0 is up, line protocol is up
  Internet address is 10.10.1.20 mask 255.255.255.0 (configured on router)
    25629 packets input, 1688582 bytes
    0 input errors, 0 dropped, 0 overrun, 0 frame errors
    25634 packets output, 1785015 bytes
    0 output errors, 0 dropped, 0 overrun, 0 collision errors
    0 output carrier detect errors
IDE hd0 is up, line protocol is up
  2060 reads, 32704512 bytes
  0 read errors
  489797 write, 2520530944 bytes
  0 write errors
```




Patch Upgrade

- [About Patch Upgrade, page 1](#)
- [Downloading the Patch File, page 1](#)
- [Configuring Patch Upgrade, page 1](#)
- [Installing the Patch File, page 2](#)

About Patch Upgrade

You can install a patch file that is downloaded from [cisco.com](http://www.cisco.com) on the existing Cisco Unified SIP Proxy release software. Installing the patch file helps you upgrade to a newer patch version of the Cisco Unified SIP Proxy without any modifications to your existing virtual machine.

Downloading the Patch File

- Step 1** Open the Cisco Unified SIP Proxy Server site:
<http://www.cisco.com/c/en/us/support/unified-communications/unified-sip-proxy-software/tsd-product-s-support-series-home.html>
- Step 2** If prompted, login using your Cisco.com username and password.
- Step 3** Locate the patch file in the “Download Software” section and download the file.
-

Configuring Patch Upgrade

Summary Steps

1. `configure terminal`
2. `software download url <url> username <username> password <password>`

Detailed Steps

	Command or Action	Purpose
Step 1	<code>configure terminal</code>	Enables privileged EXEC mode.
	Example: <code>se-10-1-0-0# configure terminal</code>	
Step 2	<code>software download url <url> username <username> password <password></code>	Specifies the SFTP url, username, and password where the patch file is stored.
	Example: <code>se-10-1-0-0(config)# software download url sftp://10.64.86.60/test/ username myuid password mypwd</code>	SFTP server URL should be the absolute path to the directory containing the patch. For example: <i>sftp://<hostname>/full/path/from/root/to/patch_directory</i>


Installing the Patch File

Summary Steps

1. offline
2. software upgrade
3. continue
4. show software version

Detailed Steps

	Command or Action	Purpose
Step 1	<p>offline</p> <p>Example: <pre>se-10-1-0-0# offline !!!WARNING!!!: Putting the system offline will terminate all active calls. Do you wish to continue[n]? : y</pre></p>	<p>Enters offline mode. All calls are terminated.</p> <p>Note Cisco Unified SIP Proxy still routes calls in offline mode. However, calls may get impacted depending upon the nature of the patch being installed.</p>
Step 2	<p>software upgrade</p> <p>Example: <pre>se-10-1-0-0# offline !!!WARNING!!!: If you are going offline to do a backup, it is recommended that you save the current running configuration using the 'write' command, prior to going to the offline state. Putting the system offline will disable management interfaces. Are you sure you want to go offline?[confirm] se-10-1-0-0(offline)# software upgrade Source filename: vCUSP_10.2.0_v1.cop.sha512 File download completed Authenticating patch file... Patch file authenticated. Taking backup before upgrade... Backup completed Proceeding with patch installation.. Do you wish to continue?[confirm]y Please wait while the patch is being installed... Status: ##### Patch installation is successful. Use 'continue' to bring the system back online se-10-1-0-0(offline)#</pre></p>	<p>Begins the upgrade process. The system takes backup of configuration and data as part of the upgrade process.</p>
Step 3	<p>continue</p> <p>Example: <pre>se-10-1-0-0(offline)# continue</pre></p>	<p>Exits offline mode and returns the system to the previous online mode. The system begins processing new calls and voice messages.</p>
Step 4	<p>show software versions</p> <pre>se-10-50-10-125> show software versions Cisco Unified SIP Proxy version (10.2.0v1) Technical Support: http://www.cisco.com/techsupport Copyright (c) 2018-2020 by Cisco Systems, Inc.</pre>	<p>Displays the current version of the configured software. Verify if you are on the latest patch release version.</p>



Troubleshooting



Note

Use the information in this chapter in conjunction with the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.2](#). That document contains detailed information about each CLI command listed here, including when to use it, how to use it, and any cautionary information.

This chapter contains a brief overview of troubleshooting using the CLI and contains the following sections:

- [Using CLI Commands to Troubleshoot the System, page 1](#)
- [Troubleshooting Configuration Changes, page 3](#)
- [Related Topics, page 3](#)

Using CLI Commands to Troubleshoot the System

Cisco technical support personnel may request that you run one or more of these commands when troubleshooting a problem. Cisco technical support personnel provides additional information about the commands at that time.



Caution

Some of these commands may impact performance of your system. We strongly recommend that you do not use these commands unless directed to do so by Cisco Technical Support.

- [About Logging, page 1](#)
- [Log Commands, page 2](#)
- [Example of Log Output, page 2](#)
- [Using Trace Commands, page 2](#)
- [Using Show Commands, page 3](#)

About Logging

You can use log messages to help you debug system problems. Log messages are saved to the messages.log file.

Logging and tracing to the hard disk is turned off by default. Executing the **log trace boot** command starts the log and trace functions immediately.

To check the log and trace files on the hard disk, use the **show logs** command in Cisco Unified SIP Proxy EXEC mode. It displays the list of logs available, their size and their dates of most recent modification.

Each file has a fixed length of 10 MB, and tracing or logging stops automatically when the file reaches this length. New files overwrite the old files.



Tip

If you cannot view the contents of the log files, copy the log files from Cisco Unified SIP Proxy to an external server and use a text editor, such as **vi**, to display the content.

Log Commands

Cisco Unified SIP Proxy has the following log commands:

- **log console** command
- **log console monitor** command
- **log server** command
- **log trace boot** command
- **log trace buffer save** command
- **show logs** command
- **show trace log** command

Example of Log Output

The following is an example of the log output:

```
se-Module(exec-mping) > show logs

SIZELAST_MODIFIED_TIMENAME
28719Mon Dec 22 14:15:06 EST 2008linux_session.log
2573Fri Dec 19 08:28:13 EST 2008install.log
8117Fri Dec 19 08:27:51 EST 2008dmesg
2274Fri Dec 19 08:27:55 EST 2008syslog.log
10455Thu Dec 18 16:38:13 EST 2008sshd.log.prev
1268Fri Dec 19 08:28:09 EST 2008atrace.log
384 Fri Dec 19 08:27:55 EST 2008debug_server.log
10380Thu Dec 18 16:06:58 EST 2008postgres.log.prev
1361Fri Dec 19 08:28:14 EST 2008sshd.log
5598Fri Dec 19 08:30:13 EST 2008postgres.log
1014Fri Dec 19 08:27:57 EST 2008klog.log
2298494Sun Dec 21 23:30:00 EST 2008messages.log
85292Fri Dec 19 08:25:33 EST 2008shutdown_installer.log
```

Using Trace Commands

To troubleshoot network configuration in Cisco Unified SIP Proxy, use the **trace enable** command in Cisco Unified SIP Proxy EXEC mode.

Cisco Unified SIP Proxy has the following trace commands:

- **log trace boot** command
- **log trace buffer save** command
- **show trace log** command
- **show trace options** command
- **trace disable** command
- **trace enable** command
- **trace level** command

Using Show Commands

In addition to the standard show commands, use the following commands to troubleshoot your Cisco Unified SIP Proxy configuration:

- **show status queue**
- **show status server-group radius** [*server-group-name*]
- **show status server-group sip** [*server-group-name*]
- **show status sip**

Troubleshooting Configuration Changes

Problem You lost some configuration data.

Recommended Action Copy your changes to the running configuration at frequent intervals. See [“Copying Configurations” on page 1](#).

Problem You lost configuration data when you rebooted the system.

Explanation You did not save the data before the reboot.

Recommended Action Use the **copy running-config startup-config** command to copy your changes from the running configuration to the startup configuration. When Cisco Unified SIP Proxy reboots, it reloads the startup configuration. See [“Copying Configurations” on page 1](#).



Note Messages are considered application data and are saved directly to the disk in the startup configuration. (They should be backed up on another server in case of a power outage or a new installation.) All other configuration changes require an explicit “save configuration” operation to preserve them in the startup configuration.

Related Topics

- For information about the CLI commands, see the [CLI Command Reference for Cisco Unified SIP Proxy Release 10.1](#).
- For information about copying configurations, see [“Copying Configurations” on page 1](#).



Configuration Example

The following is an example of what you will see after you have configured your Cisco Unified SIP Proxy system and then enter the **show configuration active verbose** command.

```
se-10-1-0-0(cusp-config)> show configuration active verbose
Building CUSP configuration...
!
server-group sip global-load-balance call-id
server-group sip retry-after 0
server-group sip element-retries udp 3
server-group sip element-retries tls 1
server-group sip element-retries tcp 1
sip alias myhostname
sip dns-srv
  enable
  no naptr
  end dns
!
no sip header-compaction
no sip logging
!
sip max-forwards 70
sip network cube-es standard
  no non-invite-provisional
  allow-connections
  retransmit-count invite-server-transaction 9
  retransmit-count non-invite-client-transaction 9
  retransmit-count invite-client-transaction 5
  retransmit-timer clientTn 64000
  retransmit-timer serverTn 64000
  retransmit-timer T4 5000
  retransmit-timer T2 4000
  retransmit-timer T1 500
  retransmit-timer TU2 32000
  retransmit-timer TU1 5000
  end network
!
sip network cube-sp standard
  no non-invite-provisional
  allow-connections
  retransmit-count invite-server-transaction 9
  retransmit-count invite-client-transaction 5
  retransmit-count non-invite-client-transaction 9
  retransmit-timer T4 5000
  retransmit-timer T2 4000
  retransmit-timer T1 500
  retransmit-timer TU2 32000
  retransmit-timer TU1 5000
```

```

retransmit-timer clientTn 64000
retransmit-timer serverTn 64000
end network
!
sip network enterprise standard
no non-invite-provisional
allow-connections
retransmit-count invite-client-transaction 5
retransmit-count invite-server-transaction 9
retransmit-count non-invite-client-transaction 9
retransmit-timer serverTn 64000
retransmit-timer T4 5000
retransmit-timer T2 4000
retransmit-timer T1 500
retransmit-timer TU2 32000
retransmit-timer TU1 5000
retransmit-timer clientTn 64000
end network
!
sip network service-provider standard
no non-invite-provisional
allow-connections
retransmit-count invite-server-transaction 9
retransmit-count non-invite-client-transaction 9
retransmit-count invite-client-transaction 5
retransmit-timer serverTn 64000
retransmit-timer TU1 5000
retransmit-timer TU2 32000
retransmit-timer T1 500
retransmit-timer T2 4000
retransmit-timer T4 5000
retransmit-timer clientTn 64000
end network
!
sip overload reject retry-after 0
!
no sip peg-counting
!
sip privacy service
sip queue message
drop-policy head
low-threshold 80
size 2000
thread-count 20
end queue
!
sip queue radius
drop-policy head
low-threshold 80
size 2000
thread-count 20
end queue
!
sip queue request
drop-policy head
low-threshold 80
size 2000
thread-count 20
end queue
!
sip queue response
drop-policy head
low-threshold 80
size 2000

```

```
thread-count 20
end queue
!
sip queue st-callback
drop-policy head
low-threshold 80
size 2000
thread-count 10
end queue
!
sip queue timer
drop-policy none
low-threshold 80
size 2500
thread-count 8
end queue
!
sip queue xcl
drop-policy head
low-threshold 80
size 2000
thread-count 2
end queue
!
route recursion
!
sip tcp connection-timeout 240
sip tcp max-connections 256
sip tls
!
trigger condition call-from-cube-es
sequence 1
  in-network cube-es
end sequence
end trigger condition
!
trigger condition call-from-cube-sp
sequence 1
  in-network cube-sp
end sequence
end trigger condition
!
trigger condition call-from-enterprise
sequence 1
  in-network enterprise
end sequence
end trigger condition
!
trigger condition call-from-service-provider
sequence 1
  in-network service-provider
end sequence
end trigger condition
!
trigger condition mid-dialog
sequence 1
  mid-dialog
end sequence
end trigger condition
!
accounting
no enable
no client-side
no server-side
```

```

    end accounting
  !
  server-group sip group cme.example.com enterprise
  element ip-address 192.168.10.6 5060 tls q-value 1.0 weight 0
  failover-resp-codes 503
  lbtype global
  ping
  end server-group
  !
  server-group sip group cube-es.example.com cube-es
  element ip-address 192.168.20.4 5060 tls q-value 1.0 weight 0
  element ip-address 192.168.20.3 5060 tls q-value 1.0 weight 0
  failover-resp-codes 503
  lbtype global
  ping
  end server-group
  !
  server-group sip group cube-sp.example.com cube-sp
  element ip-address 10.10.20.3 5060 tls q-value 1.0 weight 0
  element ip-address 10.10.20.4 5060 tls q-value 1.0 weight 0
  failover-resp-codes 503
  lbtype global
  ping
  end server-group
  !
  server-group sip group cucm.example.com enterprise
  element ip-address 192.168.10.4 5060 tls q-value 1.0 weight 50
  element ip-address 192.168.10.5 5060 tls q-value 1.0 weight 50
  element ip-address 192.168.10.3 5060 tls q-value 1.0 weight 100
  failover-resp-codes 503
  lbtype weight
  ping
  end server-group
  !
  server-group sip group sp.example.com service-provider
  element ip-address 10.10.10.3 5060 udp q-value 1.0 weight 0
  failover-resp-codes 503
  lbtype global
  ping
  end server-group
  !
  route table cube-es-table
  key * response 404
  key 5101 target-destination cme.example.com enterprise
  key 510 target-destination cucm.example.com enterprise
  end route table
  !
  route table cube-sp-table
  key * target-destination sp.example.com service-provider
  end route table
  !
  route table enterprise-table
  key * response 404
  key 5101 target-destination cme.example.com enterprise
  key 91 target-destination cube-es.example.com cube-es
  key 510 target-destination cucm.example.com enterprise
  end route table
  !
  route table service-provider-table
  key * response 404
  key 510 target-destination cube-sp.example.com cube-sp
  end route table
  !
  policy normalization outgoing-norm-policy

```



```

uri-component update TO all user ^91 ""
uri-component update request-uri user ^91 ""
end policy
!
policy lookup cube-es-policy
sequence 1 cube-es-table request-uri uri-component user
rule prefix
end sequence
end policy
!
policy lookup cube-sp-policy
sequence 1 cube-sp-table request-uri uri-component user
rule prefix
end sequence
end policy
!
policy lookup enterprise-policy
sequence 1 enterprise-table request-uri uri-component user
rule prefix
end sequence
end policy
!
policy lookup service-provider-policy
sequence 1 service-provider-table request-uri uri-component user
rule prefix
end sequence
end policy
!
trigger routing sequence 5 policy enterprise-policy condition call-from-enterpri
se
trigger routing sequence 4 policy cube-es-policy condition call-from-cube-es
trigger routing sequence 3 policy cube-sp-policy condition call-from-cube-sp
trigger routing sequence 2 policy service-provider-policy condition
call-from-service-provider
trigger routing sequence 1 by-pass condition mid-dialog
trigger pre-normalization sequence 2 policy outgoing-norm-policy condition
call-from-cube-sp
trigger pre-normalization sequence 1 by-pass condition mid-dialog
!
no server-group sip global-ping
!
sip listen service-provider udp 10.10.10.99 5060
sip listen cube-sp tls 10.10.20.99 5060
sip listen cube-es tls 192.168.20.99 5060
sip listen enterprise tls 192.168.10.99 5060
!
sip record-route cube-es tls 192.168.20.99 5060
sip record-route service-provider udp 10.10.10.99 5060
sip record-route cube-sp tls 10.10.20.99 5060
sip record-route enterprise tls 192.168.10.99 5060
!
end
se-10-1-0-0(cusp-config) >

```




B

backup

- configuring [7](#)
- SFTP server [7, 35](#)
- parameters [7](#)
- restrictions [35](#)

backup category command [36](#)

backup revisions number command [8](#)

backup server url command [8](#)

C

call-rate-limit command [34](#)

certificate, creating [29](#)

Cisco Unified Communications Manager [18](#)

clock timezone command [13](#)

command

- backup category [36](#)
- backup revisions number [8](#)
- backup server url [8](#)
- call-rate-limit [34](#)
- clock timezone [13](#)
- configure [16, 17, 19, 20, 22, 23, 25, 26, 27, 28, 31, 32, 33](#)
- configure terminal [8, 10, 11, 13, 30](#)
- continue [36](#)
- copy sftp [42](#)
- copy running-config [42](#)
- copy running-config startup-config [10, 11, 47](#)
- copy startup-config [41](#)
- copy tftp [43](#)

crypto key certreq label 30
crypto key generate 30
crypto key import cer label 30
crypto key import rsa label 30
cusp 15, 17, 19, 20, 22, 23, 25, 26, 27, 28, 31, 32, 33
element ip-address 19
end 8, 10
end network 16
end policy 22, 23
end route table 21
end sequence 17, 23
end server-group 19
end trigger condition 17
exit 11
in-network 17
key response 20
key target-destination 20
lb-type 19
lite-mode 33
log console 46
log console monitor 46
log server 46
log trace boot 46, 47
log trace buffer save 46, 47
mid-dialog 17
ntp server 10, 11
offline 36, 38
policy lookup 23
policy normalization 22
reload 39
restore id 39
route table 20
rule 23
sequence 17, 23
server-group sip group 19
show backup 8
show backup history 36, 39
show backup server 36, 38
show clock detail 13

- show configuration active [34](#)
- show configuration candidate [34](#)
- show interfaces [43](#)
- show logs [46](#)
- show ntp associations [12](#)
- show ntp configuration [10, 11](#)
- show ntp servers [12](#)
- show ntp source [12](#)
- show ntp status [10, 11, 12](#)
- show status queue [47](#)
- show status server-group radius [47](#)
- show status server-group sip [47](#)
- show status sip [47](#)
- show trace log [46, 47](#)
- show trace options [47](#)
- sip alias [28](#)
- sip listen [27](#)
- sip network [16](#)
- sip record-route [27](#)
- sip tls [31](#)
- sip tls trusted-peer [31](#)
- trace disable [47](#)
- trace enable [47](#)
- trace level [47](#)
- trigger condition [17](#)
- trigger pre-normalization sequence [26](#)
- trigger routing sequence [25](#)
- uri-component update header [22](#)
- uri-component update request-uri [22](#)
- command-line interface
 - about [1](#)
- committing the configuration [34](#)
- configuration
 - committing [34](#)
 - copying [41](#)
- configuration tasks
 - configuring hostname [28](#)
 - configuring listen and record-route ports [27](#)
 - configuring logical networks [15](#)

- configuring lookup policies [23](#)
- configuring normalization policies [22](#)
- configuring normalization triggers [26](#)
- configuring NTP servers [9](#)
- configuring route tables [20](#)
- configuring routing triggers [25](#)
- configuring server groups [18](#)
- configuring TLS [29](#)
- configuring trigger conditions [16](#)
- configure command [16, 17, 19, 20, 22, 23, 25, 26, 27, 28, 31, 32, 33](#)
- configure terminal command [8, 10, 11, 13, 30](#)
- continue command [36](#)
- copy sftp command [42](#)
- copying
 - configurations [41](#)
- copy running-config command [42](#)
- copy running-config startup-config command [10, 11, 47](#)
- copy startup-config command [41](#)
- copy tftp command [43](#)
- crypto key certreq label command [30](#)
- crypto key generate comamnd [30](#)
- crypto key import cer label command [30](#)
- crypto key import rsa label command [30](#)
- culp command [15, 17, 19, 20, 22, 23, 25, 26, 27, 28, 31, 32, 33](#)

D

- displaying
 - NTP server [12](#)
- DNS server
 - resolving host name to IP address [9](#)

E

- element ip-address command [19](#)
- end command [8, 10](#)
- end network command [16](#)
- end policy command [22, 23](#)

end route table command [21](#)
end sequence command [17, 23](#)
end server-group command [19](#)
end trigger condition command [17](#)
exit command [11](#)

F

file size
 messages.log [46](#)
SFTP server
 backup and restore [7, 35](#)
 copying startup configuration from [42](#)
Fully Qualified Domain Name, configuring [18](#)

G

graphical user interface
 about [1, 2](#)

H

hard disk
 copying configuration from [42](#)
 copying startup configuration from [41](#)
 logs [46](#)
 wear [43](#)
hostnames, about [28](#)
hostnames, configuring [28](#)

I

initial configuration tasks
 configuring backup parameters [7](#)
 configuring NTP servers [9](#)
 setting the time zone [13](#)
in-network command [17](#)

K

- key response command [20](#)
- key target-destination command [20](#)

L

- lb-type command [19](#)
- licenses
 - installing [3](#)
- listen and record-route ports, configuring [27](#)
- lite-mode command [33](#)
- log console command [46](#)
- log console monitor command [46](#)
- logging, about [45](#)
- log messages [45](#)
- log server command [46](#)
- log trace boot command [46, 47](#)
- log trace buffer save command [46, 47](#)
- lookup policies
 - about [23](#)
 - configuring [23](#)
- lost data, troubleshooting [47](#)

M

- messages.log, file size [46](#)
- mid-dialog command [17](#)
- module
 - usage [43](#)
 - wear [43](#)

N

- normalization policies
 - about [22](#)
 - configuring [22](#)
- normalization triggers, about [26](#)

normalization triggers, configuring [26](#)

NTP server

 configuring [9](#)

 displaying [12](#)

 removing [11](#)

ntp server command [10, 11](#)

O

offline command [36, 38](#)

offline mode [38](#)

P

parameters

 backup [7](#)

policy lookup command [23](#)

policy normalization command [22](#)

Q

q-value [18](#)

R

record-route

 about ports [27](#)

 configuring ports [27](#)

reload command [39](#)

removing an NTP server [11](#)

resolving host name to IP address [9](#)

restore

 SFTP server [7, 35](#)

 procedure [38](#)

 restrictions [35](#)

restore id command [39](#)

restrictions

 backup and restore [35](#)

route table command [20](#)
route tables
 about [20](#)
 configuring [20](#)
routing triggers
 about [25](#)
 configuring [25](#)
rule command [23](#)

S

sequence command [17, 23](#)
server groups
 about [18](#)
 configuring [18](#)
server-group sip group command [19](#)
show backup command [8](#)
show backup history command [36, 39](#)
show backup server command [36, 38](#)
show clock detail command [13](#)
show commands [47](#)
show configuration active command [34](#)
show configuration candidate command [34](#)
show interfaces command [43](#)
show logs command [46](#)
show ntp associations command [12](#)
show ntp configuration command [10, 11](#)
show ntp servers command [12](#)
show ntp source command [12](#)
show ntp status command [10, 11, 12](#)
show status queue command [47](#)
show status server-group radius command [47](#)
show status server-group sip command [47](#)
show status sip command [47](#)
show trace log command [46, 47](#)
show trace options command [47](#)
sip alias command [28](#)
sip listen command [27](#)
sip network command [16](#)

sip record-route command 27
sip tls command 31
sip tls trusted-peer command 31

T

TFTP server, copying configuration from 43
time zone 13
TLS, configuring 29
trace commands 46
trace disable command 47
trace enable command 47
trace level command 47
Transmission Control Protocol 29
transport layer security, configuring 29
trigger condition command 17
trigger conditions
 configuring 16
trigger pre-normalization sequence command 26
trigger routing sequence command 25
troubleshooting 45
 lost data 47
 using show commands 47
 using trace commands 46

U

uri-component update header command 22
uri-component update request-uri command 22
User Datagram Protocol 29

