


Cisco TelePresence TRC 6 Quick Reference Guide CE9.1




Place Call From Contact List


1 Use the cursor keys of the remote control and navigate to the green **Call** button. Press **OK** on the remote control.



2 To search for someone in a specific list (Favorites, Directory or Recents), navigate to that headline and press **OK**. Navigate down to locate the entry to be called.




3 At that entry press **OK** on the remote to produce the green **Call** button. Press **OK** again or press the **Call** button on the remote control.




4 The call will now be placed.

To end the call, navigate to the red **End** button and press **OK** or press the red button on the remote.




Place Call Using Name, Number or Address


1 Use the cursor keys of the remote control and navigate to the green **Call** button. Press **OK** on the remote control.



2 Navigate to the **Search or Dial** field and press **OK** on the remote control. This will invoke the keyboard.




3 To enter numbers use the keys on the remote control. To use the virtual keyboard, navigate down to and about the keyboard and select characters. Press **OK** to select a character.




4 Then press the green **Call** button to place the call.

End the call as shown at left.




Initiate Video Conference


1 In a call, navigate to **Add** and press **OK** on the remote control. This will put the current call on hold.



2 Locate or type in the participant to be added in the usual way.




3 This will produce the **Add** button. Navigate to **Add** and press **OK** or press the **Call** button on the remote control.



4 This new call will now be added to the existing, creating a conference.



Repeat to add more people.







Cisco TelePresence TRC 6 Quick Reference Guide CE9.1



Forwarding Calls, Proximity & Do not Disturb



Share Content in a Call



To share using Proximity, activate Proximity on your computer. Once paired you will be offered to share your screen.

Transfer an Ongoing Call

