


In-Room Control on Touch 10

User Interface Extensions

Cisco TelePresence

**MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80**



In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



CE8.2
JULY 2016

Table of contents

<i>Introduction</i>	4
<i>Definition of terms</i>	4
<i>In-room controls</i>	5
<i>Create a user interface for the Touch 10</i>	7
<i>Launch the In-room Control editor</i>	8
<i>Create an In-room Control panel</i>	9
<i>API for programming in-room controls</i>	14
<i>Widgets</i>	20
The Widget Identifier.....	20
Toggle button	21
Slider	22
Spinner	23
Button with custom text.....	24
Button with symbol.....	25
Group button	26
Text box.....	27
<i>Command reference</i>	29
Events.....	30
Commands.....	32
Statuses	33
<i>Troubleshooting</i>	35
Development tools on the web interface	35
<i>Tips and tricks</i>	38
<i>Examples</i>	41

How to use this guide

The left menu bar and the entries in the table of contents are all hyperlinks. You can click on them to go to the topic.

Product documentation

User guides and compliance and safety information for Cisco TelePresence systems are available at <http://www.cisco.com/go/telepresence/docs>

We recommend that you visit the Cisco web site regularly for updated versions of this guide.

Who has access to the editor?

In order to access the In-room control editor you will need to have administrator rights.

However, an administrator may create an In-room Control User account. With this account it is possible to log into the codec to run the In-room Control Editor. No other part of the web interface is accessible from this account.

If you use SSH to log into the codec, only a very limited set of the API will be accessible.

Introduction

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Introduction

With In-Room Control you can add custom elements to our Touch 10 user interface. Such *user interface extensions* may be controls for lights or blinds, or other peripherals controlled by external control systems.

Since both the Cisco video system and the other peripherals now are controlled from the Touch 10 user interface, you will get a consistent user experience throughout the meeting room.

The version of the in-room control feature described in this document, is available for the SX Series and MX Series video systems running Collaboration Endpoint Software, version CE8.2 or later.

Definition of terms

Video system. Video system or codec in the Cisco TelePresence MX Series or SX Series running Collaboration Endpoint Software, version CE8.2 or later. Sometimes referred to as *video device*.

Control system. Third-party control system with hardware drivers for peripherals, for example Crestron, AMX, Apple HomeKit, or Android.

Touch 10. Out touch-based control device for the MX Series and SX Series video systems. Full product name: Cisco TelePresence Touch 10. Also known as Touch 10 controller, or Touch 10 user interface.

In-room control panel. Panel with controls for third-party peripherals in the room. The panel opens when you tap the corresponding in-room control icon in the status bar on Touch 10. See the [Create a user interface](#) chapter for more on this.

In-room control editor. Our easy to use drag-and-drop editor for making in-room control panels.

xAPI. The bidirectional API of the video system. The xAPI allows third-party applications to interface with and interact with the video system, and vice versa.

Widget. User interface element, for example buttons, sliders, and text fields, that you can use to build an in-room control panel for Touch 10.

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



In-room controls



Example of Global and Homescreen in-room control panels on Touch 10. Any In-Call panel icons existing will be visible during calls only.

You can customize the Touch 10 user interface to allow control of peripherals in a meeting room, for example playback of a sound or movie source, lights and blinds.

You can also add content sensitive controls appearing only when in a call and/or only outside calls.

This means that altogether you have three sets of panels at your disposal:


- **Global** panel has its entry icon in the status bar at the top of the Touch 10 display. Once established, this entry icon is visible at all times.
- **Homescreen** panel has its entry icon located to the right of the buttons appearing along the bottom of the Touch 10 display. This entry icon is visible outside calls only.
- **In-Call** panel has its entry icon located to the right of the buttons appearing along the bottom of the Touch 10 display. This entry icon is visible when in a call only.

You need a Cisco video system with a Touch 10 user interface, and a third-party control system, for example Crestron, AMX.

The video system's API, referred to as the xAPI, is the link between the video system and the control system. Use the events and commands exposed by the xAPI when you program the control system.

The simple drag-and-drop in-room control editor offers a library of user interface elements, referred to as widgets. You can use these widgets to create your own in-room control panel for the Touch 10 user interface.

Together, all of this provides a powerful combination of the control system's functionality and the user-friendly Touch 10 user interface.



In-room control schematics

Create a user interface

Use the in-room control editor to create the user interface and to apply it to the video system

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Create a user interface for the Touch 10


Use the *in-room control editor* to create customized panels for peripheral controls on the video system's Touch 10 user interface.

Connected to the video system

If you have access to the video system, you can launch the editor from the video system's web interface.

If an in-room control panel already has been created on the Touch 10, this will automatically load into the editor, ready to act as a starting point for your design.

When you push a new panel to the video system, you will immediately see the result on the Touch 10.



In-room control editor launched from the video system's web interface

Offline


There are two places you can download the offline editor from:

- Download from <http://www.cisco.com/go/in-room-control-docs>
- Or, sign in to a video system's web interface with administrator credentials, navigate to *Integration > In-Room Control*, and click *Download Editor*.

If you choose to download the offline editor, extract the files from the downloaded zip-file. Retain the folder structure.

When using the offline editor you will be working with files, rather than communicating directly with the video system and Touch 10. Apart from this, the offline editor has full functionality.

The editor that you launch from the video system's web interface and the offline editor share the same file format, so files created in one version can be opened and modified in the other.



Offline in-room control editor

Launch the In-room Control editor

Sign in to the video system's web interface with administrator credentials, navigate to [Integration > In-Room Control](#), and click [Launch Editor](#).

If there is a set of in-room control panels on the video system already, it will load automatically into the editor. The Create icons (as in the below example) will then read Edit wherever a panel has already been created.

Offline version. If you are using the offline version of the editor, open the `index.html` file that you find in the `rceditor` folder.

The screenshot shows the 'Configure your panels' interface. On the left is a sidebar with 'Panels', 'Import', 'Export', and 'Help' options. The main area is divided into three columns: 'Global', 'Homescreen', and 'In-Call'. Each column lists recommended features and has a 'Create' button at the bottom. Annotations on the left side of the image point to the 'Import' button, the 'Export' button, the 'Help' button, and the three 'Create' buttons. A note at the bottom left explains that there are three sets of panels available and that each set may contain multiple pages.

Import the current panel from the video system (codec), or import a panel that has been exported to a file on an earlier occasion →

Export your panel to the video system (codec), or export it to a file that can be imported back into the editor at a later stage →

Link to online guides →

There are three sets of panels available; Global, Homescreen and In-Call. Each set may contain multiple pages. To create a panel, click here.

In-Room Control on Touch 10 for Cisco TelePresence MX200 G2, MX300 G2, MX700, MX800, SX10, SX20, SX80

Collaboration Endpoint software version CE8.2

D15358.02 - JULY 2016

www.cisco.com
© 2016 Cisco Systems, Inc.
All rights reserved.


Create an In-room Control panel

Start Designing the In-room Control Panel

If an existing in-room control panel failed to load automatically on launching the editor, choose one of these alternatives:

- [Create](#) creates a blank in-room control panel in the editor for either Global use, Homescreen use or In-Call use.
- [Import > From file](#) loads an in-room control panel, which has been exported to a local file on an earlier occasion, into the editor.
- [Import > From codec](#) loads the current in-room control panel from the video system into the editor. Not available in the offline editor.

All alternatives erase any unsaved data in the editor, but the existing in-room control panel on the video system is neither overwritten nor deleted until a new panel is exported to the video system.



Start or continue the design of an in-room control panel

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Populating the In-room Control panel

What you see in the editor's design panel is similar to how the in-room control panel will appear on the Touch 10.

An in-room control panel is arranged in pages. Each page consists of one or more rows, which you can populate with text and user interface elements known as widgets.

Widgets are arranged in a four-column grid. The widgets are placed into the grid according to the following rules:

- A widget fills between one and four columns depending on its size.

- Rows are right-aligned.
- If you add more widgets than fits in one line, widgets wrap to a new line within the same row.

How you use the user interface elements for your meeting room is up to you. You can, for example, create panels with preset buttons for lights and blinds, or support for more complex scenarios such as controls for many microphones in a large meeting room. You can find some examples for inspiration in the [Examples](#) chapter.

More on how to create the panel can be found on the next page.

This is how a panel looks before you have started to populate it.

The screenshot shows the editor interface. On the left is a sidebar with 'Panels' (Global), 'Import', 'Export', and 'Help'. The main area is the 'Design panel' showing a 'Global' page with a 'Page name' field and a 'Panel icon' dropdown. Below is a grid with 'Enter row name' and a '+', with the text 'Four-column grid' overlaid. On the right is the 'Widget library' with 'General' and 'Icons' tabs. The 'General' tab shows various controls like 'On / off', 'Slider', 'Up / down', 'Short', 'Medium', 'Wide', '2 Options', '3 Options', '4 Options', '21° C', and 'Aa' text formatting options. The 'Icons' tab shows familiar symbols like home, power, arrows, camera, and loudspeaker controls. Annotations with orange lines point to the 'Panels' button, the design panel, the widget library, and specific widget types.

Any panels already created, appears in a list beneath the Panels button. To create more panels, click *Panels*. This will show the panel front page again. Choose a new panel to create, or click an existing one to continue editing it.

Buttons with familiar symbols like home, power, arrows, camera and loudspeaker controls

Buttons with custom text, group buttons, toggle button, sliders, spinners, and other elements

Design panel

Page shows a setup of a Global in-room control, but the principles apply to all three sets of in-room controls.

Widget library

1 Give the page a name
Click the page text, and enter a name.

2 Give the row a name
Click the row text, and enter a name.

3 Add widgets from the library
Drag and drop as many widgets as you need from the widget library onto a row.

4 Enter custom text on widgets
Click the dummy-text on a button, group button, or text field, and enter the appropriate text.

5 Define unique identifiers
Click the widget, and type unique identifiers in the input fields that pops up below the design panel.
You can either use the pre-assigned identifiers or define your own.
All widgets have a unique *Widget ID*. Only Group buttons have *Group IDs*.

6 Add more rows
Click ⊕ to add a new row.
Repeat steps 2-5 for each row.


7 Add more pages
Click ⊕ to add a new page.
Repeat steps 1-6 for each page.

8 Choose an entry icon
Click *Panel icon* and choose a control icon (entry icon).
If you created a Global panel, the control icon appears in the status bar on Touch 10. When you tap the icon, the in-room Global control panel opens.

For Homescreen and In-Call, the entry icon will appear as a button to the right of the call control buttons.

8b Give the panel a name
Click *Panel name* and type in a descriptive name. This field is not available with the Global panel.

9 Click on the garbage bin icon to delete the entire panel from the editor.
To remove a panel from the Touch 10, remove it from the editor and then push your altered editor configuration to the video system. The panel's icon should disappear instantly.



For more on how to create more panels, see the previous page.

Tip Drag a page, row, or widget, and drop it in a new position. Drop it outside the design panel to delete it.

Apply In-room Control panel to the video system

(Not available when using the offline editor. Instead, you should export the in-room control panel to a file in order to save your work for later.)


Apply the in-room control panel to the video system. You will see the results immediately on the Touch 10.

- Choose [Export > To codec](#)

Check the result on Touch 10

(Not available when using the offline editor.)

Tap the in-room control icon in the Touch 10 status bar to open the in-room control panel.



Example of two sets of in-room control panels. The Global has been selected (blue light bulb) and a panel consisting of three panes is shown. To the right of the Share button, a in-room control Homescreen entry icon has been added.

Which in-room control icons (entry icons) used is defined by the [Panel icon](#) setting, as shown on the previous page.

Export the In-room Control panel to file

You may also export the in-room control panel to a file. This file can be imported back into the editor at a later stage. Note that you will export all your work (Global, Homescreen and In-Call panels)

- Choose [Export > To file](#)

If you are using the offline editor, this is the only way you can save your work for later.

Exporting to file may also be useful as a way of creating a design template if you are going to push the same in-room control panel to multiple video systems.

Files exported while connected to a video system are in the same format as files exported from an offline editor. This means that any of these files can be imported into an editor launched from a video system's web interface, and then pushed to the video system's Touch 10.

Remove a panel from Touch 10

To remove a panel from the Touch 10, remove it from the editor and then push your editor configuration to the video system. The panel's icon should disappear instantly.

API for in-room control

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



API for programming in-room controls

Connect to the video system

The video system's API (also known as the xAPI) allows bidirectional communication with third-party control systems, such as those from AMX or Crestron. There are multiple ways to access the xAPI:

- Telnet
- SSH
- HTTP/HTTPS
- Ethernet port
- RS-232 / serial connection

Regardless of the method you choose, the structure of the xAPI is the same. Choose the access method that suits your application and video system the best.

Consult the API guide for your video system to get a full description of available access methods and how to use the xAPI. Go to

<http://www.cisco.com/go/sx-docs> for SX Series, or

<http://www.cisco.com/go/mx-docs> for MX Series

Then, click *Reference Guides > Command References* to find the API guides.

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com


© 2016 Cisco Systems, Inc.
All rights reserved.



Communicate over the API

The video system and the control system exchange messages through the xAPI to make sure that the Touch 10 in-room control panel always reflects the actual status of the room.

The video system sends one or more *events* when someone uses one of the controls on the Touch 10 in-room control panel, and the control system should send a *command* to the video system when there is a change in the room settings.



The video system and the control system exchange messages through the xAPI.

Examples:

- When someone taps a *Lights On* button on Touch 10, the video system sends the associated events. The control system should respond to these events by switching on the lights in the room and send the corresponding command back to the video system.
- When someone switch on the lights in the room, the control system should send a command to the video system, so that the video system can update the Touch 10 in-room control panel to reflect that the light is on.

See the [Command reference](#) chapter for an overview of all relevant events, commands and statuses for in-room control.

Pairing the video system and the control system

You can register the control system as a peripheral that is connected to the video system.

```
xCommand Peripherals Connect ID: "ID" Type: ControlSystem
```

where ID is the unique ID for the control system, typically the MAC address.

See the API guide for more details about this command, and its options.

The control system must send heartbeats to the video system to let the video system know that the control system is connected. The control system stays on the connected devices list (refer to xStatus Peripherals ConnectedDevice) as long as the video system receives these heartbeats from the control system.

```
xCommand Peripherals HeartBeat ID: "ID" [Timeout: Timeout]
```

where ID is the unique ID for the control system, typically the MAC address, and Timeout is the number of seconds between each heartbeat. If Timeout is unspecified, it is assumed to be 60 seconds.

Events for widget actions

The video system sends one or more of the following events when someone uses the controls on the Touch 10 in-room control panel:

- **Pressed** - sent when a widget is first pressed
- **Changed** - sent when changing a widget's value (applies to toggle buttons and sliders only)
- **Released** - sent when a widget is released (also when moving away from the widget before releasing)
- **Clicked** - sent when a widget is clicked (pressed and released without moving away from the widget)

These events are sent in two versions.

- UserInterface Extensions Event - suited for *terminal output mode*
- UserInterface Extensions Widget - suited for *XML output mode*

See the table below to find out the version best suited for your control system to register to.

When, and by which widgets (user interface elements), these events are triggered, are described in the [Widgets](#) chapter.

UserInterface Extensions Event (suited for terminal output mode)	UserInterface Extensions Widget (suited for XML output mode)
<p>A single string contains information about the type of action, which widget triggered the event (identified by the Widget ID), and the widget value.</p> <p>How to register:</p> <pre>xfeedback register event/UserInterface/Extensions/Event</pre> <p>Example:</p> <pre>*e UserInterface Extensions Event <u>Pressed</u> Signal: "<u>WidgetId:Value</u>" ** end *e UserInterface Extensions Event <u>Changed</u> Signal: "<u>WidgetId:Value</u>" ** end *e UserInterface Extensions Event <u>Released</u> Signal: "<u>WidgetId:Value</u>" ** end *e UserInterface Extensions Event <u>Clicked</u> Signal: "<u>WidgetId:Value</u>" ** end</pre> <p style="text-align: center;">↑ Type of action</p>	<p>The type of action, which widget triggered the event (identified by the Widget ID), and the widget value are included as separate elements in the XML tree.</p> <p>How to register:</p> <pre>xfeedback register event/UserInterface/Extensions/Widget</pre> <p>Example:</p> <pre><Event> <UserInterface item="1"> <Extensions item="1"> <Widget item="1"> <Action item="1"> <WidgetId item="1"><u>WidgetId</u></WidgetId> <Value item="1"><u>Value</u></Value> <Type item="1"><u>Type</u></Type> </Action> </Widget> </Extensions> </UserInterface> </Event></pre> <p style="text-align: center;">↑ Type of action</p>

Two event versions that a control system can register to: one suited for terminal output mode, the other for XML output mode

Event for panel update

The video system sends the following event when a new in-room control panel is applied:

- **LayoutUpdated** - sent when a new in-room control panel for Touch 10 is exported to the video system

As a response to this event, the control system should send commands to initialize all widgets so that they reflect the true status of the room settings.

How to register:

```
xfeedback register event/UserInterface/Extensions/Widget/  
LayoutUpdated
```

Example:

Terminal output mode:

```
*e UserInterface Extensions Widget LayoutUpdated  
** end
```

XML output mode:

```
<Event>  
  <UserInterface item="1">  
    <Extensions item="1">  
      <Widget item="1">  
        <LayoutUpdated item="1"/>  
      </Widget>  
    </Extensions>  
  </UserInterface>  
</Event>
```

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.

Commands and Statuses

The SetValue command, which sets the value of a widget, is essential when working with in-room controls:

```
xCommand UserInterface Extensions Widget SetValue Value: Value
WidgetId: WidgetId
```

When the video system receives a SetValue command, the video system's status and the Touch 10 in-room control panel are updated accordingly.


It is important that the control system sends SetValue commands in the following situations, so that the Touch 10 in-room control panel truly reflects the status of the room:

- When the control system initially connects to the video system.
- When the video system restarts.
- When the control system restarts.
- When a new in-room control panel is exported to the video system from the in-room control editor (as response to the LayoutUpdated event).
- When someone physically changes something in the room, for example turns on the lights using a wall control.
- As a response to an event, for example when someone has tapped the *Lights On* button on the Touch 10 in-room control panel.


The control system must also do all that is necessary in the room to reflect the action on the Touch 10 in-room control panel, for example switch on the light.

Consult the [Widgets](#) chapter for more details about which commands apply to the different widgets (user interface elements).

Examples



Message flow—turn on the lights using the controls on Touch 10



Message flow—turn on the lights using the wall control

Widgets

Description of the user interface elements and their associated events and commands

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Widgets

The Touch 10 in-room control panel is composed of user interface elements called widgets. You can find the complete widget library in the right pane of the in-room control editor.

- **General** tab: Buttons with custom text, group buttons, toggle button, sliders, text fields and more.
- **Icons** tab: Buttons with familiar symbols for Home, Power, Arrow up/down/left/right, Camera controls, Loudspeaker controls, Microphone control, Media player controls, and more.

The content of the next few pages describes each widget type, with emphasis on:

- Commands that change the value of the widget
- Events that are sent (pressed, changed, released, clicked) and which actions trigger these events
- Examples of commands and events, both in terminal output mode and XML output mode

Syntax and semantics for all events, commands and statuses that are related to in-room controls (user interface extensions) are included in the Command reference chapter.


The Widget Identifier

All widgets on a Touch 10 in-room control panel need a unique identifier, a *Widget ID*. The Widget ID may either be defined by you, or assigned automatically. The Widget ID can be any name or number; we recommend using a descriptive name without special characters. The maximum number of characters is 40.

The Widget ID is the programming link between Touch 10, the video system, and the control system. The Widget ID will be included in all events that are associated with a widget, and you must use the same identifier when you send commands to that widget via the code that you write for your control system.

Group Identifiers

One of the widgets, the *Group button*, has two types of identifiers: The Widget ID refers to the complete group of buttons, while *Group IDs* are unique identifiers for the individual buttons within the group.



A Group ID is assigned automatically, but can be defined by you instead. A Group ID can be any name or number; we recommend using a descriptive name without special characters. The maximum number of characters is 255.

Toggle button



A two-state switch which indicates either *on* or *off*.

Events

Changed Triggered when the button is released.
Value: <on/off>

Example of use: Anything that can be turned on or off, for example lights, fan, and projector. You can use a toggle button together with a slider for lights that can be dimmed.

Example: Press "on" on the toggle button with WidgetId = "togglebutton".

```
..... Terminal mode .....  
*e UserInterface Extensions Event Changed Signal: "togglebutton:on"  
** end
```

```
..... XML mode .....  
<Event>  
  <UserInterface item="1">  
    <Extensions item="1">  
      <Widget item="1">  
        <Action item="1">  
          <WidgetId item="1">togglebutton</WidgetId>  
          <Value item="1">on</Value>  
          <Type item="1">changed</Type>  
        </Action>  
      </Widget>  
    </Extensions>  
  </UserInterface>  
</Event>
```

Commands

The visual appearance of the button changes immediately when you tap it. However, the control system must always send a SetValue command to the video system when the button toggles between *on* and *off*. This ensures that the status is updated accordingly.

Example: Set the button with WidgetId = "togglebutton" to "on".

```
xCommand UserInterface Extensions Widget SetValue  
WidgetId: "togglebutton" Value: "on"
```

Slider



Example of use: Dimmable lights, volume control.

Events

Pressed	Triggered when the slider is pressed Value: N/A
Changed	Triggered when the slider is moved while holding down, and when the slider is released Value: 0-255
Released	Triggered when the slider is released Value: 0-255

A slider selects values within a set range. The minimum value is represented by 0, and the maximum value is represented by 255. When the slider is being pressed and moved, events are sent maximum 5 times a second.

When you tap the bar, the slider is immediately moved to that new position.

Example: Press the slider with WidgetId = "slider", and move it into a new position ("68"), and release.

```
..... Terminal mode .....  
*e UserInterface Extensions Event Pressed Signal: "slider"  
** end  
*e UserInterface Extensions Event Changed Signal: "slider:32"  
** end  
*e UserInterface Extensions Event Changed Signal: "slider:68"  
** end  
*e UserInterface Extensions Event Released Signal: "slider:68"  
** end
```

```
..... XML mode .....  
. . .  
<Event>  
  <UserInterface item="1">  
    <Extensions item="1">  
      <Widget item="1">  
        <Action item="1">  
          <WidgetId item="1">slider</WidgetId>  
          <Value item="1">68</Value>  
          <Type item="1">released</Type>  
        </Action>  
      </Widget>  
    </Extensions>  
  </UserInterface>  
</Event>
```


Commands

The visual appearance of the slider changes immediately when you tap or slide it. However, the control system must always send a SetValue command to the video system to tell the new position of the slider. This ensures that the status is updated accordingly.

Example: Set the slider with WidgetId = "slider" to position "98".

```
xCommand UserInterface Extensions Widget SetValue WidgetId: "slider"  
Value: "98"
```

Spinner



Example of use: Set the desired temperature in the room.

Events

Pressed	Triggered when one of the spinner buttons is pressed Value: <increment/decrement>
Released	Triggered when one of the spinner buttons is released Value: <increment/decrement>
Clicked	Triggered when one of the spinner buttons is released Value: <increment/decrement>

A spinner is used to step through a list of values. You may use the two buttons to increment or decrement a number, or to step through a list of options.

Use the SetValue command to add text between the buttons.

Example: Press and release the decrement button of the spinner with WidgetId = "spinner".

```
..... Terminal mode .....
*e UserInterface Extensions Event Pressed Signal: "spinner:decrement"
** end
*e UserInterface Extensions Event Released Signal: "spinner:decrement"
** end
*e UserInterface Extensions Event Clicked Signal: "spinner:decrement"
** end
```

```
..... XML mode .....
.
.
.
<Event>
  <UserInterface item="1">
    <Extensions item="1">
      <Widget item="1">
        <Action item="1">
          <WidgetId item="1">spinner</WidgetId>
          <Value item="1">decrement</Value>
          <Type item="1">clicked</Type>
        </Action>
      </Widget>
    </Extensions>
  </UserInterface>
</Event>
```

Commands

Use the SetValue command to add or update the text between the two buttons.

Example: For the spinner with WidgetId = "spinner", add the text "22" between the spinner's increment and decrement buttons.

```
xCommand UserInterface Extensions Widget SetValue WidgetId: "spinner"
Value: "22"
```

Button with custom text



Example of use: Room presets for lighting, for example three buttons that show *Dark, Cool, Bright*.

Events

Pressed	Triggered when the button is pressed Value: N/A
Released	Triggered when the button is released Value: N/A
Clicked	Triggered when the button is released Value: N/A

Buttons with custom text come in different sizes. The size determines the maximum number of characters you can add. Text does not wrap to a new line. You cannot use the SetValue command to change the text dynamically.

A button has two states: *active* and *inactive*. You do not have to set the button in *active* state when someone taps it; the button can be used to just send a signal without changing the button's visual state.

If you want to have the buttons linked so that only one can be selected at a time (radio buttons), consider to use [Group buttons](#).

Example: Press and release the button with WidgetId = "button".

```
..... Terminal mode .....
*e UserInterface Extensions Event Pressed Signal: "button"
** end
*e UserInterface Extensions Event Released Signal: "button"
** end
*e UserInterface Extensions Event Clicked Signal: "button"
** end

..... XML mode .....
.
.
.
<Event>
  <UserInterface item="1">
    <Extensions item="1">
      <Widget item="1">
        <Action item="1">
          <WidgetId item="1">button</WidgetId>
          <Value item="1"></Value>
          <Type item="1">clicked</Type>
        </Action>
      </Widget>
    </Extensions>
  </UserInterface>
</Event>
```

Commands

Use the SetValue command to highlight or not the button in the user interface. A value of "active" will highlight the button, and a value of "inactive" will release it.

Example: Highlight the button with WidgetId = "button" (set it in *active* state).

```
xCommand UserInterface Extensions Widget SetValue WidgetId: "button"
Value: "active"
```


Button with symbol



Example of use: Controls for a media player, or other devices that can start, stop, pause.

Events

Pressed	Triggered when the button is pressed Value: N/A
Released	Triggered when the button is released Value: N/A
Clicked	Triggered when the button is released Value: N/A

There are buttons with different symbols under the *Icons* tab in the library. Such a button has similar behavior as a button with custom text.

A button has two states: *active* and *inactive*. You do not have to set the button in *active* state when someone taps it; the button can be used to just send a signal without changing its visual state.

Example: Press and release the button with WidgetId = "symbol".

```
..... Terminal mode .....  
*e UserInterface Extensions Event Pressed Signal: "symbol"  
** end  
*e UserInterface Extensions Event Released Signal: "symbol"  
** end  
*e UserInterface Extensions Event Clicked Signal: "symbol"  
** end
```

```
..... XML mode .....  
.  
.  
.  
<Event>  
  <UserInterface item="1">  
    <Extensions item="1">  
      <Widget item="1">  
        <Action item="1">  
          <WidgetId item="1">symbol</WidgetId>  
          <Value item="1"></Value>  
          <Type item="1">clicked</Type>  
        </Action>  
      </Widget>  
    </Extensions>  
  </UserInterface>  
</Event>
```

Commands


Use the SetValue command to highlight or not the button in the user interface. A value of "active" will highlight the button, and a value of "inactive" will release it.

Example: Highlight the button with WidgetId = "symbol" (set it in active state)

```
xCommand UserInterface Extensions Widget SetValue WidgetId: "symbol"  
Value: "active"
```

Group button

Example of use: Room presets that are mutually excluding, like room presets where you can choose between *Dark*, *Cool*, and *Bright*. Remember to deselect (release) the preset, if it is no longer valid (for instance when changing the lights with a wall control, or a Touch 10 slider.



No button selected



One button selected

Groups of either two, three or four buttons with custom text are available. The buttons within a group are linked so that only one can be selected at a time (also known as radio buttons).

The size of the button determines the maximum number of characters you can add. Text does not wrap to a new line. You cannot use the SetValue command to change the text dynamically.

Events

Pressed	Triggered when one of the buttons is pressed Value: The Group ID of the button (within the group) that was pressed
Released	Triggered when one of the buttons is released Value: The Group ID of the button (within the group) that was released

Example: There are four buttons in the group with WidgetId = "groupbutton". Press the button with Group ID = "two".

```
..... Terminal mode .....
*e UserInterface Extensions Event Pressed Signal: "groupbutton:two"
** end
*e UserInterface Extensions Event Released Signal: "groupbutton:two"
** end
```

```
..... XML mode .....
.
.
.
<Event>
  <UserInterface item="1">
    <Extensions item="1">
      <Widget item="1">
        <Action item="1">
          <WidgetId item="1">groupbutton</WidgetId>
          <Value item="1">two</Value>
          <Type item="1">released</Type>
        </Action>
      </Widget>
    </Extensions>
  </UserInterface>
</Event>
```

Commands

The visual appearance of the button changes immediately when you tap it. However, the control system must always send a SetValue command to the video system when one of the buttons are tapped. This ensures that the status is updated accordingly.

Use the UnSetValue command to release all buttons in the group so that no button is highlighted.

Example: Select (highlight) the button with Group ID = "one" in the group with WidgetId = "groupbutton". Then, release all buttons (no buttons are highlighted).

```
xCommand UserInterface Extensions Widget SetValue
WidgetId: "groupbutton" Value: "one"
xCommand UserInterface Extensions Widget UnsetValue
WidgetId: "groupbutton"
```

Text box



Example of use: Help text, instructions, explanation of what different presets mean, or informative text from the control system, such as “The projector is warming up”.

The text box with larger font size is primarily meant for status values, such as the current temperature in the room.

Text boxes come in different sizes. They have up to two lines of text and the text automatically wraps to the new line.

A small text box with larger font size and no line wrap is also available.

You can define the initial text for the text box in the editor, and later on use the `SetValue` command to enter text dynamically.

Events

None

Commands

Use the `SetValue` command to set the text in the text box.

Example: Set the following text in the text box with `WidgetId = "textbox"`: "The projector is warming up."

```
xCommand UserInterface Extensions Widget SetValue  
WidgetId: "textbox" Value: "The projector is warming up."
```

Command reference

Syntax and semantics for events, commands, and statuses, that are used with the user interface extensions

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Command reference

This chapter includes syntax and semantics for events, commands, and statuses, that are used with the user interface extensions.

Refer to the API guide to find descriptions of all configurations, commands, and statuses. Go to

<http://www.cisco.com/go/sx-docs> for SX Series,

<http://www.cisco.com/go/mx-docs> for MX Series

Then, click *Reference Guides > Command References* to find the API guides.

Overview of events, commands and statuses

<i>Events</i>	30
UserInterface Extensions Event Pressed.....	30
UserInterface Extensions Event Changed	30
UserInterface Extensions Event Released.....	30
UserInterface Extensions Event Clicked.....	30
UserInterface Extensions Widget Action.....	31
UserInterface Extensions Widget LayoutUpdated.....	31
 <i>Commands</i>	32
UserInterface Extensions Widget SetValue	32
UserInterface Extensions Widget UnsetValue	32
UserInterface Extensions Clear	32
UserInterface Extensions List.....	32
 <i>Statuses</i>	33
UserInterface Extensions Widget [n] WidgetId	33
UserInterface Extensions Widget [n] Value.....	33

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com
© 2016 Cisco Systems, Inc.
All rights reserved.



Events

UserInterface Extensions Event Pressed

Sent by the video system when a widget is first pressed.

Equivalent to the UserInterface Extensions Widget Action event with Type “Pressed”.

*e UserInterface Extensions Event Pressed Signal: Signal

where

Signal: String (0, 255)

The format of the string is “<WidgetId>:<Value>”, where <WidgetId> is the unique identifier of the widget that triggers the event, and <Value> is the value of the widget. The range of allowed values depends on the widget type.

UserInterface Extensions Event Changed

Sent by the video system when changing a widget’s value (applies only to toggle buttons and sliders).

Equivalent to the UserInterface Extensions Widget Action event with Type “Changed”.

*e UserInterface Extensions Event Changed Signal: Signal

where

Signal: String (0, 255)

The format of the string is “<WidgetId>:<Value>”, where <WidgetId> is the unique identifier of the widget that triggers the event, and <Value> is the value of the widget. The range of allowed values depends on the widget type.

UserInterface Extensions Event Released

Sent by the video system when a widget is released (even if moving the finger out of the widget before releasing it).

Equivalent to the UserInterface Extensions Widget Action event with Type “Released”.

*e UserInterface Extensions Event Released Signal: Signal

where

Signal: String (0, 255)

The format of the string is “<WidgetId>:<Value>”, where <WidgetId> is the unique identifier of the widget that triggers the event, and <Value> is the value of the widget. The range of allowed values depends on the widget type.

UserInterface Extensions Event Clicked

Sent by the video system when a widget is clicked (pressed and released without moving the finger out of the widget).

Equivalent to the UserInterface Extensions Widget Action event with Type “Clicked”.

*e UserInterface Extensions Event Clicked Signal: Signal

where

Signal: String (0, 255)

The format of the string is “<WidgetId>:<Value>”, where <WidgetId> is the unique identifier of the widget that triggers the event, and <Value> is the value of the widget. The range of allowed values depends on the widget type.

UserInterface Extensions Widget Action

Sent by the video system when someone uses one of the controls on the user interface (in-room control panel).

Equivalent to the UserInterface Extensions Event *Type* event.

Depending on the action type, this event is equivalent to the UserInterface Extensions Event Pressed, UserInterface Extensions Event Changed, UserInterface Extensions Event Released, or UserInterface Extensions Event Clicked events.

```
<Event>
  <UserInterface item="1">
    <Extensions item="1">
      <Widget item="1">
        <Action item="1">
          <WidgetId item="1">WidgetId</WidgetId>
          <Value item="1">Value</Value>
          <Type item="1">Type</Type>
        </Action>
      </Widget>
    </Extensions>
  </UserInterface>
</Event>
```

where

WidgetId: String (0, 40)

The unique identifier for the widget that triggered the event.

Value: String (0, 255)

The value of the widget. The range of allowed values depends on the widget type.

Type: <Pressed/Changed/Released/Clicked>

Pressed: Sent when a widget is first pressed.

Changed: Sent when changing a widget's value (only for toggle buttons and sliders).

Released: Sent when a widget is released (even if moving the finger out of the widget before releasing it).

Clicked: Sent when a widget is clicked (pressed and released without moving the finger out of the widget).

UserInterface Extensions Widget LayoutUpdated

Sent by the video system when the configuration file for the user interface extensions has been updated, i.e. when exporting a new configuration from the in-room control editor to the video system.

```
*e UserInterface Extensions Widget LayoutUpdated
```

or

```
<Event>
  <UserInterface item="1">
    <Extensions item="1">
      <Widget item="1">
        <LayoutUpdated item="1"/>
      </Widget>
    </Extensions>
  </UserInterface>
</Event>
```

Commands

UserInterface Extensions Widget SetValue

This command sets the value of the given widget, and the UserInterface Extensions statuses are updated accordingly. If the value is out of range, the command returns an error.

USAGE:

```
xCommand UserInterface Extensions Widget SetValue Value: Value  
WidgetId: WidgetId
```

where

Value: String (0, 255)

The value of the widget. The range of values depends on the widget type.

WidgetId: String (0, 40)

The unique identifier for the widget.

UserInterface Extensions Widget UnsetValue

This command empties the value of the given widget, and the UserInterface Extensions statuses are updated accordingly. The user interface is notified that the widget is no longer selected.

USAGE:

```
xCommand UserInterface Extensions Widget UnsetValue  
WidgetId: WidgetId
```

where

WidgetId: String (0, 40)

The unique identifier for the widget.

UserInterface Extensions Clear

This command deletes all user interface extensions (widgets) from the video system.

USAGE:

```
xCommand UserInterface Extensions Clear
```

UserInterface Extensions List

Use this command to list all user interface extensions (widgets) that exist on the video system.

USAGE:

```
xCommand UserInterface Extensions List
```


Statuses

UserInterface Extensions Widget [n] WidgetId

UserInterface Extensions Widget [n] Value

This status returns the identifier (WidgetId) and the current value of the widgets.

The value is an empty string until a value is set by using the UserInterface Extensions Widget SetValue command.

USAGE:

```
xStatus UserInterface Extensions
```

Value space of the result returned:

Value: The value of the widget. Depends on widget type.
String (0, 255).

WidgetId: The unique widget identifier. String (0, 40).

Example:

```
xstatus UserInterface Extensions
*s UserInterface Extensions Widget 1 Value: "on"
*s UserInterface Extensions Widget 1 WidgetId: "togglebutton"
*s UserInterface Extensions Widget 2 Value: "255"
*s UserInterface Extensions Widget 2 WidgetId: "slider"
*s UserInterface Extensions Widget 3 Value: "Blinds"
*s UserInterface Extensions Widget 3 WidgetId: "spinner"
*s UserInterface Extensions Widget 4 Value: "inactive"
*s UserInterface Extensions Widget 4 WidgetId: "button"
*s UserInterface Extensions Widget 5 Value: "2"
*s UserInterface Extensions Widget 5 WidgetId: "groupbutton"
*s UserInterface Extensions Widget 6 Value: "Projector is ready"
*s UserInterface Extensions Widget 6 WidgetId: "textfield"
** end
```

Troubleshooting

Help to identify the source of an error

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Troubleshooting

Development tools on the web interface

Sign in to the video system's web interface with administrator credentials, navigate to [Integration > In-Room Control](#). Click the arrow to show the *Development Tools*.

Overview of all widgets and their status

The Widget State Overview window lists all widgets, and their status. The status is shown in the *Current Value* column.

If the *Current Value* column is empty, the widget has not been initialized and has no value. We recommend that the control system initializes all widgets when it initially connects to the video system.

Send value updates to the video system

A control system sends SetValue commands to the video system, telling it to update a widget. For test purposes, you can use the *Update Value* column in the Widget State Overview window to simulate a control system.

Enter a value in one of the input fields to immediately send the corresponding SetValue command to the video system. The *Current Value* column (status) will be updated, and the Touch 10 in-room control panel changes accordingly.

Click *Unset* to clear the value of the widget (send an UnsetValue command).

If a control system is connected to the video system, the *Current Value* and *Update Value* columns may come out-of-sync. The *Current Value* column always shows the current status, regardless of whether the SetValue command is sent from a real control system, or from the *Update Value* column.

Widget State Overview

ID	Type	Current Value	Update Value
lights_on	Button	inactive	<input type="text"/> Unset
lights_off	Button	inactive	<input type="text"/> Unset
spotlights_slider	Slider	18	<input type="text"/> Unset
spotlights_on_off	ToggleButton	off	<input type="text"/> Unset

Widget status

Send command to update widget

Check for events and status updates

All events and status updates related to widgets appear immediately in the Log window. Events are prefixed with *e, and statuses are prefixed with *s.

Events appear when you use the controls on the Touch 10 user interface, and the status is updated when a command, which changes the video system's status, is sent to the video system.

The screenshot shows a 'Log' window with a search bar 'Filter logs by widget id...' and a 'Clear log' button. The log content is as follows:

```
Monitor started...
Fetched In-Room Control configuration...
*e UserInterface Extensions Widget Action WidgetId: spotlights_on_off Type: changed Value: on
*e UserInterface Extensions Widget Action WidgetId: spotlights_slider Type: pressed
*e UserInterface Extensions Widget Action WidgetId: spotlights_slider Type: changed Value: 103
*e UserInterface Extensions Widget Action WidgetId: spotlights_slider Type: released Value: 103
*s UserInterface Extensions Widget 15 Value: on
*s UserInterface Extensions Widget 16 Value: 8
*s UserInterface Extensions Widget 16 Value: 9
*s UserInterface Extensions Widget 16 Value: 10
*s UserInterface Extensions Widget 16 Value: 11
```

Annotations in the image include:

- A box around the event lines: `*e UserInterface Extensions Widget Action WidgetId: spotlights_on_off Type: changed Value: on`, `*e UserInterface Extensions Widget Action WidgetId: spotlights_slider Type: pressed`, `*e UserInterface Extensions Widget Action WidgetId: spotlights_slider Type: changed Value: 103`, and `*e UserInterface Extensions Widget Action WidgetId: spotlights_slider Type: released Value: 103`. A label 'Events' points to this box.
- A box around the status lines: `*s UserInterface Extensions Widget 15 Value: on`, `*s UserInterface Extensions Widget 16 Value: 8`, `*s UserInterface Extensions Widget 16 Value: 9`, `*s UserInterface Extensions Widget 16 Value: 10`, and `*s UserInterface Extensions Widget 16 Value: 11`. A label 'Status' points to this box.
- A box around the widget IDs: `[spotlights_on_off]`, `[spotlights_slider]`, `[spotlights_slider]`, `[spotlights_slider]`, `[spotlights_on_off]`, `[spotlights_slider]`, `[spotlights_slider]`, `[spotlights_slider]`, and `[spotlights_slider]`. A label 'Widget ID' points to this box.

Tips and tricks

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Tips and tricks

Re-register to feedback from the video system when either the video system or the control system restarts

When either the video system or the control system restarts, the control system must re-register to the events that the video system sends when someone uses the Touch 10 in-room controls or pushes a new in-room control panel to the Touch 10.

For terminal output mode:

```
xfeedback register event/UserInterface/Extensions/Widget
```

For XML output mode:

```
xfeedback register event/UserInterface/Extensions/Event
xfeedback register event/UserInterface/Extensions/Widget/
  LayoutUpdated
```

Consult the [API for in-room control](#) chapter for more details.

Initialize all widgets

It is important that the control system initializes all the widgets on the Touch 10 in-room control panel in the following situations:

- When the control system connects to the video system for the first time.
- When the video system restarts.
- When the control system restarts.
- When a new in-room control panel is exported to the video system (as response to a `LayoutUpdated` event).

If this is not done, then the Touch 10 may show incorrect values and not truly reflect the status of the room.

Use the `SetVaLue` command to set the initial values.

Always send values back to the video system when something changes

To avoid unexpected behavior and ambiguities, the control system must **always** send `SetVaLue` commands to the video system when something changes. This applies also when the change is triggered by someone using the controls on the Touch 10.

For example, it makes no difference if you use a slider on the Touch 10 in-control panel to dim the light, or a physical dimmer in the room, or another touch panel. The control system must always send the dimmer value back to the video system using the `SetVaLue` command.

Update the in-room control panel

When you export a new in-room control panel to the video system, the old panel is overwritten and replaced by the new one.

- a. Launch the in-room control editor from the video system's web interface.
- b. Create the in-room control panel you want, or import a previously saved panel from file (*Import > From file*).
- c. Click *Export > To codec*.

Other useful stuff

Remember previous values when turning lights off (eg a light with a slider for dimming and toggle for on/off), remember the current light state when turning off, and use that value when turning back on. Eg if the light is at 40 %, and the user presses off, she will expect it to go back to 40 % (not 100%) when pressing the "on" again. Remember also to set the power switch to off if sliding to 0 %.

For blinds, consider to use the following strategy: hort press on a direction arrow tilts the blinds. If tilted all the way already, moves the blinds slightly.

Long press on a direction arrow starts moving the blind that direction, doesn't stop until all the way up / down.

To stop movement after long pressing, short press any button (stop button is not really necessary)

Remove an entire in-room control panel and icon

If there is an in-room control panel on the video system then there is also a corresponding in-room control icon, either in the Touch 10 status bar or as a button to the right of the call control buttons. Even if a panel is empty and contains no widgets, both the icon and the panel will be visible.

Perform the following steps to remove the in-room control panel and icon from Touch 10:

- a. Launch the in-room control editor from the video system's web interface.
- b. Select the panel to be removed (Global, Homescreen or In-call)
- c. Click *Recycle bin* (🗑️) in the lower right corner.

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.



Examples

For inspiration and guidance on best practices

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com

© 2016 Cisco Systems, Inc.
All rights reserved.




Examples

The following examples are meant for inspiration and to give some guidance on best practices. It is not mandatory to design and implement controls as illustrated in these examples.

Group controls that belong together

Consider grouping controls that belong together on the same page. The pages you create in the in-room control editor appear as separate tabs on the control panel.



In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016


www.cisco.com
© 2016 Cisco Systems, Inc.
All rights reserved.



Control of lights

The combination of a slider and a toggle button could be used to control lights. The toggle button switches the lights on or off; the slider serves as a dimmer.

Combination of slider and toggle button



Group button with three mutually exclusive options

Consider the following strategy:

- Set the slider to minimum when the user turns the lights off.
- Set the toggle button to *off* when the user moves the slider to its minimum.
- Remember the value of the slider when the lights are turned off, so that you can return to this value when the lights are turned back on again.


If the light is at 40%, when the user switches it off, he or she would expect it to go back to 40% (not maximum) when switching the lights on again.

- When the user selects one of the options in the group button (a light preset), set the sliders and toggle buttons accordingly.
- If the lights are changed away from a preset, for instance by changing a slider or toggle button, deselect all options in the group button.

Control of temperature

The combination of a spinner and a large font text box (value) may be used to control temperature. Use the spinner to set the desired temperature, and the large font text box to show the current temperature.

Large font text box



A spinner with text between the up and down arrows


For the best user experience remember the following:

- Update the large font text box as the temperature in the room changes.
- Update the text field of the spinner when someone tap the up and down arrows.

Consult the [Widgets](#) chapter for details about how to update the spinner's text field and the large font text box.

Control of blinds

You can either use a spinner, or up and down arrows from the *Icons* tab in the widget library.



Consider the following strategy:


- Tilt the slides as response to a short press on a direction arrow. If tilted all the way, move the blinds up or down incrementally.
- As response to a long press on a direction arrow, start moving the blinds in that direction. They do not stop until all the way up or down.
- Short press any button in order to stop the movement after a long press. Then no separate stop button is necessary.

Use a button only to send a signal

A button can be used just to send a signal, without changing the button's state or visual appearance.

As an example, use the *All lights on* button to switch on all lights. Do not change the button's color from gray to blue, but update the other light controls to reflect the true status of the room.


A button that does not change color (from gray to blue) when used



Group buttons

Group buttons are ideal when you want buttons to be linked, so that only one can be selected at a time. For example room presets.

When the individual buttons in a group are too small to contain the text that describes their function, consider to use text boxes for the description.



In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com
© 2016 Cisco Systems, Inc.
All rights reserved.

Cisco contacts

On our web site you will find an overview of the worldwide Cisco contacts.

Go to: <http://www.cisco.com/go/offices>

Corporate Headquarters
Cisco Systems, Inc.
170 West Tasman Dr.
San Jose, CA 95134 USA

Intellectual property rights

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies are considered un-controlled copies and the original on-line version should be referred to for latest version.

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

In-Room Control on Touch 10
for Cisco TelePresence
MX200 G2, MX300 G2,
MX700, MX800,
SX10, SX20, SX80

Collaboration Endpoint
software version CE8.2

D15358.02 - JULY 2016

www.cisco.com
© 2016 Cisco Systems, Inc.
All rights reserved.

