Configure the Local Database Size on the Wireless LAN Controller

Contents

Introduction

Prerequisites

Requirements

Components Used

Database Size on the WLC

Configure

Configurations

Verify

Troubleshoot

Introduction

This document explains how to configure and view the local database size on the Wireless LAN Controller (WLC).

Prerequisites

Requirements

Cisco recommends that you have knowledge of these topics:

• Knowledge of how to configure the WLC and Cisco Access Point for basic operation.

Components Used

The information in this document is based on these software and hardware versions:

• Cisco WLC 3504 that runs software version 8.8.110.0.

The information in this document was created from the devices in a specific lab environment.

All of the devices used in this document started with a cleared (default) configuration. If your network is live, make sure that you understand the potential impact of any command.

Database Size on the WLC

The local database on the WLC stores entries for these items:

- Local management users (including lobby ambassadors)
- Local network users (including guest users)

- MAC filter entries
- Exclusion list entries
- Access point authorization list entries

The local user database is limited to a maximum of 12000 entries. The valid range is 512 to 12000, and the default setting is 12000. Together they cannot exceed the configured maximum value.

Configure

Configurations

The database size can be configured using the WLC CLI or the GUI.

In order to configure the local database using the CLI, enter this command:


```
<#root>
config database size
```

Examples:

```
(Cisco Controller) >config database size ?
<count> Enter the maximum number of entries (512-12000).
```

Please save the configuration and reset the system ("reset system") for the change to take effect.

In order to configure the database using the GUI, navigate to the **Security > General**page on the WLC. You can configure the database size as shown here:



Once you configure the database size using the controller CLI or GUI, you need to reboot the controller for the configuration to take effect.

Verify

The show data summary command lists the number of current database entries and the number of database

entries after reboot.

This command has no arguments or keywords. This command has no defaults. This command was introduced in version 4.1.

Examples:

In order to view the number of MAC filters configured, use the show macfilter summary command.

In order to view the number of local netusers configured, use the**show netuser summary**command.

```
<#root>
(Cisco Controller) >
show netuser summary

Maximum logins allowed for a given user name..... Unlimited
```

User	Name	WLAN	Ιd	User	Type	Lifetime	Description

testuser Any Permanent N/A

Troubleshoot

When the maximum configured database size is reached, you might receive any one of these errors when trying to add users to the local database:

- When attempting to add a MAC address to a long MAC filter list, the error messageError in creating MAC filtermight be seen.
- When adding a large number of users to the local database, a point can be reached where some user entries are silently ignored.
- Similarly, a point can be reached while adding SSCs for APs, where no more entries can be added, and the "Authorization entry does not exist in Controller's AP Authorization List." messages are seen.