



Troubleshooting Guide for Cisco NCS 1001, IOS XR Releases 7.x.x

First Published: 2020-01-16

Last Modified: 2024-02-08

Americas Headquarters

Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
<http://www.cisco.com>
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883



CONTENTS

CHAPTER 1

Alarm Troubleshooting 1

| | |
|---|---|
| 0/PM [0/1] Unit Unsupported | 2 |
| Clear the 0/PM [0/1] Unit Unsupported Alarm | 2 |
| 0/RP0 Unit Unsupported | 2 |
| Clear the 0/RP0 Unit Unsupported Alarm | 3 |
| AMPLI-GAIN-LOW, AMPLI-GAIN-HIGH | 3 |
| Clear the AMPLI-GAIN-LOW, AMPLI-GAIN-HIGH Alarm | 3 |
| AUTO-AMPLI-DISABLED | 3 |
| Clear the AUTO-AMPLI-DISABLED Alarm | 4 |
| AUTO-AMPLI-MISMATCH | 4 |
| Clear the AUTO-AMPLI-MISMATCH Alarm | 4 |
| AUTO-AMPLI-RUNNING | 5 |
| Clear the AUTO-AMPLI-RUNNING Alarm | 5 |
| AUTO-LASER-SHUT | 5 |
| Clear the AUTO-LASER-SHUT Alarm | 5 |
| AUTO-POW-RED | 6 |
| Clear the AUTO-POW-RED Alarm | 6 |
| Ctrl-FPGA PCIe Error | 6 |
| Clear the Ctrl-FPGA PCIe Error Alarm | 6 |
| Daisyduke - FPGA PCIe Error | 7 |
| Clear the Daisyduke - FPGA PCIe Error Alarm | 7 |
| Daisyduke Processor Hot Alarm | 7 |
| Clear the Daisyduke Processor Hot Alarm | 7 |
| EQPT-DEGRADE-<n> | 7 |
| Clear the EQPT-DEGRADE-<n> Alarm | 8 |
| EQPT-FAIL-<n> | 8 |

| | |
|---|----|
| Clear the EQPT-FAIL-<n> Alarm | 8 |
| Ethernet Switch Communication Error | 8 |
| Clear the Ethernet Switch Communication Error Alarm | 9 |
| Fan Tray Removal Alarm | 9 |
| Clear the Fan Tray Removal Alarm | 9 |
| FPDs are Incompatible - Need to Upgrade all the FPDs | 9 |
| Clear the FPDs are Incompatible - Need to Upgrade all the FPDs Alarm | 9 |
| I2C Access Error | 10 |
| Clear the I2C Access Error Alarm | 10 |
| [Low High] Voltage Alarm | 10 |
| Clear the [Low High] Voltage Alarm | 10 |
| More than One Fan Tray is Removed from Chassis | 11 |
| Clear the More than One Fan Tray is Removed from Chassis Alarm | 11 |
| OTDR-EXCESSIVE-ORL-[1 2]-[TX RX] | 11 |
| Clear the OTDR-EXCESSIVE-ORL-[1 2]-[TX RX] Alarm | 11 |
| OTDR-HIGH-REFLECTION-[1 2]-[TX RX] | 11 |
| Clear the OTDR-HIGH-REFLECTION-[1 2]-[TX RX] Alarm | 12 |
| Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Loss | 12 |
| Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Loss Alarm | 12 |
| Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Loss | 12 |
| Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Loss Alarm | 13 |
| Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Reflection | 13 |
| Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Reflection Alarm | 13 |
| Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Reflection | 13 |
| Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Reflection Alarm | 14 |
| OTDR-RUNNING-NEAR-END-[1 2]-[TX RX] | 14 |
| Clear the OTDR-RUNNING-NEAR-END-[1 2]-[TX RX] Alarm | 14 |
| OTDR-SCAN-FAIL-[1 2]-[TX RX] | 14 |
| Clear the OTDR-SCAN-FAIL-[1 2]-[TX RX] Alarm | 15 |
| Out of Tolerance Fault | 15 |
| Clear the Out of Tolerance Fault Alarm | 15 |
| Power Module Error (PM_I2C_ACCESS_ERROR) | 15 |
| Clear the Power Module Error (PM_I2C_ACCESS_ERROR) Alarm | 16 |
| Power Module Error (PM_NO_INPUT_DETECTED) | 16 |

| | |
|--|----|
| Clear the Power Module Error (PM_NO_INPUT_DETECTED) Alarm | 16 |
| Power Module Error (PM_VIN_VOLT_OOR) | 16 |
| Clear the Power Module Error (PM_VIN_VOLT_OOR) Alarm | 17 |
| Power Module Output Disabled (PM_OUTPUT_EN_PIN_HI) | 17 |
| Clear the Power Module Output Disabled (PM_OUTPUT_EN_PIN_HI) Alarm | 17 |
| Power Module Overloaded (PM_POWER_LIMITED) | 17 |
| Clear the Power Module Overloaded (PM_POWER_LIMITED) Alarm | 17 |
| Power Module Redundancy Lost | 18 |
| Clear the Power Module Redundancy Lost Alarm | 18 |
| Power Module Warning (Low Input Voltage) | 18 |
| Clear the Power Module Warning (Low Input Voltage) Alarm | 18 |
| Power Module Warning (PM_FAN_OUT_OF_TOLERANCE) | 19 |
| Clear the Power Module Warning (PM_FAN_OUT_OF_TOLERANCE) Alarm | 19 |
| Power Module Warning (PM_OT_Warning) | 19 |
| RX-LOC | 19 |
| Clear the RX-LOC Alarm | 20 |
| RX-LOS-P | 20 |
| Clear the RX-LOS-P Alarm | 20 |
| RX-POWER-FAIL-LOW | 20 |
| Clear the RX-POWER-FAIL-LOW Alarm | 21 |
| Sensor in a Failure State | 21 |
| SWITCH-TO-PROTECT | 21 |
| Clear the SWITCH-TO-PROTECT Alarm | 21 |
| Temperature Alarm | 21 |
| Clear the Temperature Alarm | 22 |
| TX-POWER-FAIL-LOW | 22 |
| Clear the TX-POWER-FAIL-LOW Alarm | 22 |
| CARLOSS (GE) | 22 |
| Clear the CARLOSS (GE) Alarm | 23 |



CHAPTER 1

Alarm Troubleshooting



Note Certain software releases have reached end-of-life status. For more information, see the [End-of-Life and End-of-Sale Notices](#).

This chapter gives a description, severity, and troubleshooting procedure for each commonly encountered Cisco NCS 1001 alarm and condition. When an alarm is raised, refer to its clearing procedure.

- 0/PM [0|1] Unit Unsupported, on page 2
- 0/RP0 Unit Unsupported , on page 2
- AMPLI-GAIN-LOW, AMPLI-GAIN-HIGH, on page 3
- AUTO-AMPLI-DISABLED, on page 3
- AUTO-AMPLI-MISMATCH, on page 4
- AUTO-AMPLI-RUNNING, on page 5
- AUTO-LASER-SHUT, on page 5
- AUTO-POW-RED, on page 6
- Ctrl-FPGA PCIe Error, on page 6
- Daisyduke - FPGA PCIe Error, on page 7
- Daisyduke Processor Hot Alarm, on page 7
- EQPT-DEGRADE-<n>, on page 7
- EQPT-FAIL-<n>, on page 8
- Ethernet Switch Communication Error, on page 8
- Fan Tray Removal Alarm, on page 9
- FPDs are Incompatible - Need to Upgrade all the FPDs, on page 9
- I2C Access Error, on page 10
- [Low | High] Voltage Alarm, on page 10
- More than One Fan Tray is Removed from Chassis, on page 11
- OTDR-EXCESSIVE-ORL-[1|2]-[TX|RX], on page 11
- OTDR-HIGH-REFLECTION-[1|2]-[TX|RX], on page 11
- Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Loss, on page 12
- Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Loss, on page 12
- Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Reflection, on page 13
- Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Reflection, on page 13
- OTDR-RUNNING-NEAR-END-[1|2]-[TX|RX], on page 14

- OTDR-SCAN-FAIL-[1|2]-[TX|RX], on page 14
- Out of Tolerance Fault, on page 15
- Power Module Error (PM_I2C_ACCESS_ERROR), on page 15
- Power Module Error (PM_NO_INPUT_DETECTED), on page 16
- Power Module Error (PM_VIN_VOLT_OOR), on page 16
- Power Module Output Disabled (PM_OUTPUT_EN_PIN_HI), on page 17
- Power Module Overloaded (PM_POWER_LIMITED), on page 17
- Power Module Redundancy Lost, on page 18
- Power Module Warning (Low Input Voltage), on page 18
- Power Module Warning (PM_FAN_OUT_OF_TOLERANCE), on page 19
- Power Module Warning (PM_OT_Warning), on page 19
- RX-LOC, on page 19
- RX-LOS-P, on page 20
- RX-POWER-FAIL-LOW, on page 20
- Sensor in a Failure State, on page 21
- SWITCH-TO-PROTECT, on page 21
- Temperature Alarm, on page 21
- TX-POWER-FAIL-LOW, on page 22
- CARLOSS (GE), on page 22

0/PM [0|1] Unit Unsupported

Default Severity: Critical (CR), Service Affecting (SA)

Logical Object: EQUIPMENT

The 0/PM [0|1] Unit Unsupported alarm is raised when a an unsupported PSU is plugged within NCS1001 chassis. The alarms has two forms because of the two PSU:

- 0/PM0 unit unsupported
- 0/PM1 unit unsupported

Clear the 0/PM [0|1] Unit Unsupported Alarm

Procedure

Replace the PSU with correct part number and hardware revision.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

0/RP0 Unit Unsupported

Default Severity: Critical (CR), Service Affecting (SA)

Logical Object: EQUIPMENT

The 0/RP0 Unit Unsupported alarm is raised when an unsupported CPU board is plugged in the chassis.

Clear the 0/RP0 Unit Unsupported Alarm

Procedure

Replace the control board with a proper part number and or hardware revision

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AMPLI-GAIN-LOW, AMPLI-GAIN-HIGH

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: OTS

The Amplifier Gain Low or High alarm is raised when the EDFA module cannot reach the gain setpoint. This condition occurs if the amplifier reaches its range boundaries.

Clear the AMPLI-GAIN-LOW, AMPLI-GAIN-HIGH Alarm

Procedure

- Step 1** If the Amplifier-control-mode is set to "Manual", the applied gain comes from configuration. You need to adjust the gain setting to a correct value (not too low or too high).
- Step 2** If the Amplifier-Control-Mode is set to "Automatic" it may be due to a too long/too short span or other conditions (i.e. measured channels). Check the overall system settings and performance.
- Step 3** If the alarm persist, it may indicate an amplifier hardware failure.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AUTO-AMPLI-DISABLED

Default Severity: Minor (MN), Not-Service-Affecting (NSA)

Logical Object: OTS

The AUTO-AMPLI-DISABLED alarm is triggered when the amplifier operates in automatic mode and the power level difference between two channels goes beyond the configured **Channel Power Max Delta** value.

When the difference exceeds the configured delta value, the Amplifier control is disabled. Although the output power is still visible, the gain regulation does not occur as intended.

Clear the AUTO-AMPLI-DISABLED Alarm

The alarm is cleared automatically when the power level difference between two channels is below the configured delta value. To further troubleshoot and clear this alarm, perform the following steps:

Procedure

-
- Step 1** Check the channel plan at the system level and verify if the OTS-OCH power levels of the amplifier meet the expected values. It's possible that one or more channels may have power issues compared to others. The channel with the minimum power value and the channel with the maximum power value should have a power difference greater than `channel-power-max-delta`.
 - Step 2** Check the patch panel for channels with low power. Clean or replace fibers of affected incoming channels.
 - Step 3** Check the channel plan at the system level including the channel launch power vs channel path. If it cannot be determined, adjust the **Channel Power Max Delta** value using the command `channel-power-max-delta value` to be higher than the difference between the highest and lowest channel power.

Note Ensure to revert the configuration to the default delta value once the power level difference between two channels is below the configured delta value.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AUTO-AMPLI-MISMATCH

Default Severity: NotAlarmed (NA), Not-Service-Affecting (NSA)

Logical Object: OTS

The Amplifier Automatic Configuration Mismatch alarm is raised when the amplifier-control-mode is configured as auto but there is no grid mode configuration. Hence the amplifier control cannot work.

Clear the AUTO-AMPLI-MISMATCH Alarm

Procedure

-
- Step 1** Cisco NCS1001 configuration depends on how the system works (automatic control vs manual control).
 - Step 2** Check Cisco NCS1001 running configuration using `show running config` command.
 - Step 3** Enter the grid-mode configuration for the EDFA module, if required.
 - Step 4** Change the amplifier configuration in manual mode, if required.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AUTO-AMPLI-RUNNING

Default Severity: NotAlarmed (NA), Not-Service-Affecting (NSA)

Logical Object: OTS

The Automatic Amplifier Running alarm is raised when the internal algorithm performs calculation to reach the target power. The alarm notifies the user that the final power is not reached.

Clear the AUTO-AMPLI-RUNNING Alarm

Procedure

The Automatic Amplifier Running alarm clears automatically when the target power is reached.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AUTO-LASER-SHUT

Default Severity: NotAlarmed (NA), Not-Service-Affecting (NSA)

Logical Object: OTS

The Amplifier Laser Shutdown alarm is raised for safety concern. If an OTS port supports an amplifier and the safety-control-mode is set to "auto", the amplifier may shut down its Tx power if it is not receiving the same Rx port due to a fiber cut.

Clear the AUTO-LASER-SHUT Alarm

Procedure

- Step 1** For Controller OTS 1 (LINE), check the RX-LOC or RX-LOSP alarm. For Controller OTS 0 (COM), check if any RX-POWER-FAIL-LOW on Controller OTS 3 (COM-CHECK).
- Step 2** Check the fiber is properly plugged or if there is no fiber cut on the span.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AUTO-POW-RED

Default Severity: NotAlarmed (NA), Not-Service-Affecting (NSA)

Logical Object: OTS

The Automatic Power Reduction alarm is raised when the temporary conditions in the amplifier restarts hence pulsing the APR power levels.

Clear the AUTO-POW-RED Alarm

Procedure

Step 1 Wait for the APR cycles complete, say, 100 seconds, 8 seconds APR levels. The alarms disappear once the amplifier ends the APR phase.

Step 2 If the alarm persist check the fiber cut is repaired.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Ctrl-FPGA PCIe Error

Default Severity: Critical (CR), Service Affecting (SA)

Logical Object: EQUIPMENT

The Ctrl-FPGA PCIe error is raised when the Contro FPGA is unreachable due to PCIe bus error.

Clear the Ctrl-FPGA PCIe Error Alarm

Procedure

Reload Cisco NCS1001. If the alarm does not clear it may due to the hardware failure.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Daisyduke - FPGA PCIe Error

Default Severity: Critical (CR), Service Affecting (SA)

Logical Object: EQUIPMENT

The Daisyduke - FPGA PCIe error alarm occurs when the Daisy Duke CPU FPGA is unable to communicate with the CPU controller due to a Peripheral Component Interconnect Express (PCIe) error.

Clear the Daisyduke - FPGA PCIe Error Alarm

Procedure

Step 1 Reload the chassis.

Step 2 If not cleared it may be due to hardware fault.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Daisyduke Processor Hot Alarm

Default Severity: Minor(MN), Non-Service Affecting (NSA)

Logical Object: EQUIPMENT

The Daisyduke Processor Hot alarm is raised when the CPU detects high temperature of the Processor.

Clear the Daisyduke Processor Hot Alarm

Procedure

Verify proper functioning of all the fans in the system.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

EQPT-DEGRADE-<n>

Default Severity: MINOR (MN), Not-Service-Affecting (SA)

Logical Object: EQUIPMENT

The Equipment Degrade alarm is raised when there is misbehavior detected by the optical module however the module is still considered as working properly.

Clear the EQPT-DEGRADE-<n> Alarm

Procedure

The Module is still working but requires further diagnosis. Plan for a module replacement.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

EQPT-FAIL-<n>

Default Severity: Critical (SA), Service-Affecting (SA)

Logical Object: EQUIPMENT

The Equipment Failure alarms is raised on an optical module equipment that has an internal failure or is not able to communicate with the NCS1001 chassis.

Clear the EQPT-FAIL-<n> Alarm

Procedure

Step 1 From admin plane try to trigger a module reset (this operation is traffic affecting).

Step 2 If the problem persists it typically indicates an internal hardware failure for the optical module.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Ethernet Switch Communication Error

Default Severity: Major (MN), Service Affecting (SA)

Logical Object: EQUIPMENT

The Ethernet Switch Communication error is raised when the interconnected board is unable to communicate with CPU due to a Peripheral Component Interconnect Express (PCIe).

Clear the Ethernet Switch Communication Error Alarm

Procedure

Power Cycle the Cisco NCS1001.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Fan Tray Removal Alarm

Default Severity: Minor (MN), Not-Service-Affecting (NSA)

Logical Object: FT

The Fan Tray Removal alarm is raised when the fan tray is removed from Cisco NCS1001 chassis.

Clear the Fan Tray Removal Alarm

Procedure

Insert the missing or removed fan tray.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

FPDs are Incompatible - Need to Upgrade all the FPDs

Default Severity: Major (MN), Service Affecting (SA)

Logical Object: EQUIPMENT

The FPDs are incompatible - need to upgrade all the FPDs alarm is raised when FPDs are incompatible.

Clear the FPDs are Incompatible - Need to Upgrade all the FPDs Alarm

Procedure

Update the firmware.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

I2C Access Error

Default Severity: Major (MN), Service Affecting (SA)

Logical Object: EQUIPMENT

The I2C access error alarm is raised when Cisco NCS1001 detect errors in interconnected card I2C busses.

Clear the I2C Access Error Alarm

Procedure

This alarm indicates hardware failure.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

[Low | High] Voltage Alarm

Default Severity: Critical (CR), Service Affecting (SA)

Logical Object: EQUIPMENT

A [Low | High] Voltage alarm is raised when one of the internal voltage measurement is not within the operating range. The format of the voltage alarm is:

- [sensor name]: high voltage alarm.
- [sensor name]: low voltage alarm.

Clear the [Low | High] Voltage Alarm

Procedure

Voltage alarms clears when the voltage is within the operating conditions.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

More than One Fan Tray is Removed from Chassis

Default Severity: Critical (CR), Not-Service-Affecting (NSA)

Logical Object: EQUIPMENT

This alarm is raised when more than one fan tray is removed from Cisco NCS1001 chassis.

Clear the More than One Fan Tray is Removed from Chassis Alarm

Procedure

Step 1 Check if at least three fan trays are inserted.

Step 2 Ensure that there is no fan tray failure.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTDR-EXCESSIVE-ORL-[1|2]-[TX|RX]

Default Severity: Critical (CR), Not Service Affecting (NSA)

Logical Object: EQUIPMENT

The OTDR-EXCESSIVE-ORL-[1|2]-[TX|RX] alarm is raised when the OTDR scan detects an excessive Optical Return Loss (ORL) value. For example, this alarm is raised when the ORL read from OTDR module exceeds the relative threshold.

Clear the OTDR-EXCESSIVE-ORL-[1|2]-[TX|RX] Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTDR-HIGH-REFLECTION-[1|2]-[TX|RX]

Default Severity: Critical (CR), Not Service Affecting (NSA)

Logical Object: EQUIPMENT

The OTDR-HIGH-REFLECTION-[1|2]-[TX|RX] alarm is raised when OTDR measurement with excessively high reflection is completed.

Clear the OTDR-HIGH-REFLECTION-[1|2]-[TX|RX] Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Loss

Default Severity: Critical (CR), Non-Service-Affecting (NSA)

Logical Object: EQUIPMENT

OTDR scan detects a loss value. This alarm is raised when the loss value read from the OTDR module plus the relative loss threshold exceeds the scan value stored in the baseline.

Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Loss Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction, or change the Relative Loss Threshold.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Loss

Default Severity: Critical (CR), Non-Service-Affecting (NSA)

Logical Object: EQUIPMENT

OTDR scan detects a loss value. This alarm is raised when the loss value read from the OTDR module plus the relative loss threshold exceeds the scan value stored in the baseline.

Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Loss Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction, or change the Relative Loss Threshold.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Reflection

Default Severity: Critical (CR), Non-Service-Affecting (NSA)

Logical Object: EQUIPMENT

OTDR scan detects a reflection value. This alarm is raised when the reflection value read from the OTDR module plus the relative reflection threshold exceeds the scan value stored in the baseline.

Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Auto Relative Reflection Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction, or change the reflection relative threshold.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Reflection

Default Severity: Critical (CR), Non-Service-Affecting (NSA)

Logical Object: EQUIPMENT

OTDR scan detects a reflection value. This alarm is raised when the reflection value read from the OTDR module plus the relative reflection threshold exceeds the scan value stored in the baseline.

Clear the Otdr Port [1-2] Direction [Tx-Rx] Mode Expert Relative Reflection Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction, or change the reflection relative threshold.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTDR-RUNNING-NEAR-END-[1|2]-[TX|RX]

Default Severity: Not-Alarm (NA), Not-Service-Affecting (NSA)

Logical Object: EQUIPMENT

The OTDR-RUNNING-NEAR-END-[1|2]-[TX|RX] alarm is raised when an OTDR scan is in progress and OTDR [1|2] is locally performing a [Tx|Rx] measurement.

This alarm indicates that an OTDR scan is ongoing.

Clear the OTDR-RUNNING-NEAR-END-[1|2]-[TX|RX] Alarm

Procedure

This alarm is automatically cleared when OTDR scan is completed.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTDR-SCAN-FAIL-[1|2]-[TX|RX]

Default Severity: Critical (CR), Not Service Affecting (NSA)

Logical Object: EQUIPMENT

The OTDR-SCAN-FAIL-[1|2]-[TX|RX] alarm is raised when OTDR scan failed.

This alarm is raised when OTDR scan failed.

Clear the OTDR-SCAN-FAIL-[1|2]-[TX|RX] Alarm

Procedure

Start a new OTDR scan on the same slot, port, and direction.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Out of Tolerance Fault

Default Severity: Minor (MN), Not-Service-Affecting (NSA)

Logical Object: EQUIPMENT

An Out of Tolerance alarm is raised when a sensor detects wrong working condition. The alarm appears in the following format of:

- [sensor name]: out of tolerance fault.

Clear the Out of Tolerance Fault Alarm

Procedure

Check the sensor for hardware failure.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Error (PM_I2C_ACCESS_ERROR)

Default Severity: Major (MJ), Service Affecting (SA)

Logical Object: PEM

The Power Module Error (PM_I2C_ACCESS_ERROR) alarm is raised when there is an error on the power module. The detected error is a communication error on I2C bus.

Clear the Power Module Error (PM_I2C_ACCESS_ERROR) Alarm

Procedure

Check the health status of PEM module through the admin console.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Error (PM_NO_INPUT_DETECTED)

Default Severity: Major (MJ), Service Affecting (SA)

Logical Object: PEM

The Power Module Error (PM_NO_INPUT_DETECTED) alarm is raised when there is an error on the power module. This error is detected when the input power is not available.

Clear the Power Module Error (PM_NO_INPUT_DETECTED) Alarm

Procedure

Check the health status of PEM module using the admin console.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Error (PM_VIN_VOLT_OOR)

Default Severity: Major (MJ), Service Affecting (SA)

Logical Object: PEM

The Power Module Error (PM_VIN_VOLT_OOR) alarm is raised when there is an out of range input voltage issue on the power module.

Clear the Power Module Error (PM_VIN_VOLT_OOR) Alarm

Procedure

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Output Disabled (PM_OUTPUT_EN_PIN_HI)

Default Severity: Major (MJ), Service Affecting (SA)

Logical Object: PEM

The Power Module Output Disabled (PM_OUTPUT_EN_PIN_HI) alarm is raised when the output power is disabled and PEM module does not work.

Clear the Power Module Output Disabled (PM_OUTPUT_EN_PIN_HI) Alarm

Procedure

Enable the power supply to clear the alarm.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Overloaded (PM_POWER_LIMITED)

Default Severity: Major (MJ), Service Affecting (SA)

Logical Object: PEM

The Power Module Overloaded (PM_POWER_LIMITED) alarm is raised when there is power limitation control in the Power module.

Clear the Power Module Overloaded (PM_POWER_LIMITED) Alarm

Procedure

Check the health status of the PEM module through the admin console.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Redundancy Lost

Default Severity: Major (MJ), Service Affecting (SA)

Logical Object: PEM

The Power Module Redundancy Lost alarm is raised when any one of the two active power module is removed from the chassis.

Clear the Power Module Redundancy Lost Alarm

Procedure

This alarm is cleared when an active power supply module is inserted on Cisco NCS 1001.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Warning (Low Input Voltage)

Default Severity: Minor (MN), Not-Service-Affecting (NSA)

Logical Object: PEM

The Power Module Warning (Low Input Voltage) alarm is raised when the input power reaches warning level.

Clear the Power Module Warning (Low Input Voltage) Alarm

Procedure

Check the PEM module power supply.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Warning (PM_FAN_OUT_OF_TOLERANCE)

Default Severity: Minor (MN), Not-Service-Affecting (NSA)

Logical Object: PEM

The Power Module Warning (PM_FAN_OUT_OF_TOLERANCE) alarm is raised when there is a warning on the power module. The detected problem is a PSU fan out during normal working condition.

Clear the Power Module Warning (PM_FAN_OUT_OF_TOLERANCE) Alarm

Procedure

Check the health status of the PEM module through the admin console.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Power Module Warning (PM_OT_Warning)

Default Severity: Minor (MN), Not-Service-Affecting (NSA)

Logical Object: PEM

The Power Module Warning (PM_OT_Warning) is raised when the PEM Module reaches the warning level.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

RX-LOC

Default Severity: Critical (SA), Service-Affecting (SA)

Logical Object: OTS

The RX Loss Of Continuity (LOC) alarm is raised when there is an optical power failure on the port receiving from a span. This alarm represents a fiber cut on the span and is a combination between RX-LOS-P and RX-POWER-FAIL-LOW.

Clear the RX-LOC Alarm

Procedure

Check the RX power reading on the ports received from the fiber spans. For EDFA Pluggable module, check the RX total power on OTS Port Controller 1 (LINE Port) and the TX power on OTS Port Controller 2 (OSC port).

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

RX-LOS-P

Default Severity: Critical (SA), Service-Affecting (SA)

Logical Object: OTS

The RX-LOS-P alarm is raised when there is an optical signal power loss on an OTS port as it transmits the signal.

Clear the RX-LOS-P Alarm

Procedure

Step 1 Check if the threshold settings is as per expected system performance.

Step 2 Check if the receiving power is functional.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

RX-POWER-FAIL-LOW

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: OTS, OTS-OCH, Optics Controller

The RX-POWER-FAIL-LOW alarm is triggered on an OTS-OCH, optics, or OTS controller whenever the optical power of the incoming signal drops below the set RX-low-threshold on the corresponding controllers.

Clear the RX-POWER-FAIL-LOW Alarm

Procedure

- Step 1** Check if the threshold settings is as per expected system performance.
- Step 2** Check if the receiving power is correct or is missing due to a fiber cut or connected to a removed channel.
- If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
-

Sensor in a Failure State

Default Severity: Critical, Service Affecting

Logical Object: EQUIPMENT

The Sensor in a Failure State alarm is raised when there is a failure indication in the sensor.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

SWITCH-TO-PROTECT

Default Severity: NotAlarmed (NA), Not-Service-Affecting

Logical Object: OTS

The Switch to Protect alarm is raised when the status of "Protect" Controller type is Active and the status of "Working" Controller is Standby status. (Only PSM OTS controllers 1 and 2 have these types).

Clear the SWITCH-TO-PROTECT Alarm

Procedure

This alarm is cleared when a switch event happens.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Temperature Alarm

Default Severity: Critical (CR), Not Service Affecting (NSA)

Logical Object: EQUIPMENT

The Temperature alarm is raised when the temperature of a sensor exceeds normal operating range. The alarm appears in the form of:

- [sensor name]: temperature alarm.

Clear the Temperature Alarm

Procedure

- Step 1** Verify the temperature of Cisco NCS1001 or the temperature of the optical modules displayed on the chassis.
- Step 2** Verify the environmental temperature of the room is not abnormally high.
- Step 3** Verify the functioning of fans and ensure that the air flow for the fans is proper.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

TX-POWER-FAIL-LOW

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: OTS, OTS-OCH

The TX Power Fail Low alarm is raised when the transmit optical power is below the tx-low-threshold.

Clear the TX-POWER-FAIL-LOW Alarm

Procedure

- Step 1** Check if the threshold settings are as per the expected system performance.
- Step 2** Check if the corresponding receiving power is correct. For example, an OTS Controller 1 TX receives power from Controller 0 RX.
- Step 3** Check for any hardware failure.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CARLOSS (GE)

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: GE

The CARLOSS alarm for Gigabit Ethernet (GE) controller occurs when the GE fiber cable is disconnected at the optical controller port.

Clear the CARLOSS (GE) Alarm

Procedure

- Step 1** Check that OSC SFP Rx port fiber is plugged into the EDFA appropriate slot where the alarm is raised.
- Step 2** If the fiber is correctly plugged, you need to clean the connector or change the fiber to clear the alarm.
- If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
-

