



Troubleshooting Guide for Cisco NCS 1004, IOS XR Release 7.2.1

Alarm Troubleshooting	4
XGE_EEPROM_ERROR	4
AVST-Failure Alarm	4
BH-CARD-NOT-SEATED	4
BH-CARD-POWER-OFF-STATUS	5
BH-CARD-PWR-ON-TIMEOUT	5
BH-CPU-CARD-NOT-SEATED	5
BH-INVALID-CARD-SLOT	6
BIOS-IMAGE-CORRUPTION	6
BP_FPGA-SEU-UNCORRECTED-ERROR	6
BP-FPGA-ERROR	7
CD Alarm	7
CPU-FPGA-PCIE-ERROR	8
CPU-FLASH-0-ERROR	8
CPU-FLASH-1-ERROR	8
CPU_SSD_ATA-ERRORS Alarm	9
CPU_SSD-TEMPERATURE_HIGH Alarm	9
CRYPTO_HW_FAILURE	9
CRYPTO-INDEX-MISMATCH	10

CRYPTO-KEY-EXPIRED 10
DATAPATH-DEV-FAILURE Alarm 10
DGD Alarm 11
EQUIPMENT_FAILURE 11
EQUIPMENT-FAILURE Alarm 11
FAN FAIL Alarm 12
FAN-POWER-ERROR 12
FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT Alarm 13
FAN-TRAY-REMOVAL Alarm 13
FPD IN NEED UPGD Alarm 13
HIBER Alarm 14
HI-LASERBIAS Alarm 14
HI-RXPOWER Alarm 14
HI-TXPOWER Alarm 15
IMPROPRMVL Alarm 15
IMPROPRMVL Alarm 16
INSTALL IN PROGRESS Alarm 16
BP-FPGA-PCIE-ERROR 16
BP-FPGA-IMAGE-CORRUPTION 17
BP_FPGA_XR_EP-FPGA-PCIE-ERROR 17
LCMODE-CONFIG-CHANGED Alarm 17
LCMODE-CONFIG-INVALID Alarm 18
LCMODE-NOT-CONFIG Alarm 18
LC_BOOT_TIMEOUT Alarm 18
LC-CPU-IMAGE-CORRUPTION 19
LC-DP-IMAGE-CORRUPTION Alarm 19
TEMPERATURE Alarm 19
LC-OFFLINE-ERROR 20
LC-SUDI-CERT-VERIFICATION-FAILURE Alarm 20
LOCAL-FAULT Alarm 20
LO-RXPOWER Alarm 21
LO-TXPOWER Alarm 21
LOM Alarm 22
LOS-P Alarm 22



MB_SSD_ATA-ERRORS Alarm	23
MEA Alarm	23
NODE-OBFL-ERROR	24
ODU-AIS Alarm	24
ODU-BDI Alarm	24
ODU-CSF Alarm	25
ODU-IAE/BIAE	25
ODU-LCK	25
ODU-OCI	26
OSNR Alarm	26
OTNSEC-LOCALLY-SECURED	27
OTUK-AIS	27
OTUK-BDI Alarm	27
OTUK-LOF Alarm	28
OTUK-SD Alarm	28
OTUK-SF Alarm	29
OTUK-TIM Alarm	29
OTN-XP-DP-FPD-PKG-MISSING Alarm	29
PEX_SWITCH_ACCESS_FAILURE Alarm	30
POWER MODULE OUTPUT DISABLED Alarm	30
POWER-MODULE-REDUNDANCY-LOST Alarm	30
PPM FAIL Alarm	31
Provisioning Failed Alarm	31
PROVISIONING-INCOMPAT Alarm	32
Provisioning in Progress Alarm	32
RACK-OBFL-ERROR	32
REMOTE-FAULT Alarm	33
RUNNING FANS AT MAX SPEED Alarm	33
SIGLOSS Alarm	34
SQUELCHED Alarm	34
SYNCLOSS Alarm	34
UNC-WORD Alarm	35
USB_OC_1	35
USB_OC_0	36
VOLTAGE Alarm	36
WVL-OUT-OF-LOCK Alarm	36
XGE-FLASH-ERROR	37

Revised: December 11, 2020

Alarm Troubleshooting

This chapter provides a description, severity, and troubleshooting procedure for each commonly encountered Cisco NCS 1004 alarm and condition. When an alarm is raised, refer to its clearing procedure.

XGE_EEPROM_ERROR

Default Severity: Major (MJ), Service-Affecting (SA))

Logical Object: SC

XGE_EEPROM_ERROR is raised when system detects the XGE EEPROM corruption.

Clear the XGE_EEPROM_ERROR Alarm

Procedure

This alarm is cleared after the XGE EEPROM corruption is cleared.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

AVST-Failure Alarm

Default Severity: Major (MJ), Non-Service-Affecting (NSA)

Logical Object: LC

An AVST-Failure alarm is raised when the FPGA configuration fails on the line card inserted on any port from 0 to 13.

Clear the AVST-FAILURE Alarm

Copy the **Datapath FPGA** file to the /emmcdata/fpd location for the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BH-CARD-NOT-SEATED

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-CARD-NOT-SEATED alarm is raised when the line card is not inserted completely into the chassis.

Clear the BH-CARD-NOT-SEATED Alarm

Procedure

This alarm is cleared when the line card is reinserted properly into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BH-CARD-POWER-OFF-STATUS

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-CARD-POWER-OFF-STATUS alarm is raised in the following conditions: a. When you perform a line card shut operation
b. When the line card fails to get the power allocation due to power budget.

Clear the BH-CARD-POWER-OFF-STATUS Alarm

Procedure

This alarm is cleared when line card is reloaded, OIR of the line card, or if the line card is successful in getting the power allocation.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BH-CARD-PWR-ON-TIMEOUT

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-CARD-PWR-ON-TIMEOUT alarm is raised if there is a delay in getting the PWR_ON request from the shelf_mgr.

Clear the BH-CARD-PWR-ON-TIMEOUT Alarm

Procedure

This alarm is cleared immediately after the PWR_ON request is received from the shelf_mgr.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BH-CPU-CARD-NOT-SEATED

Default Severity: Critical(CR), Service-Affecting (SA)

Logical Object: RP

The BH-CPU-CARD-NOT-SEATED alarm is raised when the CPU card is not inserted completely into the chassis.

Clear the BH-CPU-CARD-NOT-SEATED Alarm

Procedure

This alarm is cleared when the CPU card is reinserted properly by removing it and reinserting it into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BH-INVALID-CARD-SLOT

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The BH-INVALID-CARD-SLOT alarm is raised when the line card EEPROM is corrupted or when the line card fails to connect within the timeout period of a maximum of two minutes.

Clear the BH-INVALID-CARD-SLOT Alarm

Procedure

This alarm is cleared when the line card is inserted with the proper EEPROM.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BIOS-IMAGE-CORRUPTION

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The BIOS-IMAGE-CORRUPTION alarm is raised when the BIOS image is corrupted and system is booted with the Golden image.

Clear the BIOS-IMAGE-CORRUPTION Alarm

Procedure

This alarm is cleared after the BIOS corruption is corrected and reloaded.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BP_FPGA-SEU-UNCORRECTED-ERROR

Default Severity: Major (MJ), Service-Affecting (SA))

Logical Object: SC

The BP_FPGA-SEU-UNCORRECTED-ERROR alarm is raised when the BP detects the corruption of the FPGA.

Clear the BP_FPGA-SEU-UNCORRECTED-ERROR Alarm

Procedure

This alarm is cleared when the hardware corrects the FPGA corruption.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BP-FPGA-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The BP-FPGA-ERROR alarm is raised when the BP FPGA SPI flash is not accessible.

Clear the BP-FPGA-ERROR Alarm

Procedure

This alarm is cleared when the BP FPGA SPI Flash error is corrected.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CD Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Chromatic Dispersion (CD) alarm is raised when the detected chromatic dispersion value is above or below the configured threshold values.

Clear the CD Alarm

Procedure

Configure threshold value within range if CD value is not within the threshold range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CPU-FPGA-PCIE-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The CPU-FPGA-PCIE-ERROR alarm is raised when the device goes out of the PCIe tree.

Clear the CPU-FPGA-PCIE-ERROR Alarm

Procedure

This alarm is cleared when the device comes back to the PCIe tree.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CPU-FLASH-0-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The CPU-FLASH-0-ERROR alarm is raised when the BIOS upgrade flash is not accessible.

Clear the CPU-FLASH-0-ERROR Alarm

Procedure

This alarm is cleared when the BIOS upgrade flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CPU-FLASH-1-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The CPU-FLASH-1-ERROR alarm is raised when BIOS primary is not accessible.

Clear the CPU-FLASH-1-ERROR Alarm

Procedure

This alarm is cleared when the BIOS primary flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CPU_SSD_ATA-ERRORS Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: LC

The CPU_SSD_ATA-ERRORS alarm is raised when the CPU Solid State Disk (SSD) has ATA errors.

Clear the CPU_SSD_ATA-ERRORS Alarm Alarm

Procedure

The CPU_SSD_ATA-ERRORS alarm is cleared when the CPU SSD is replaced.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CPU_SSD-TEMPERATURE_HIGH Alarm

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The CPU_SSD-TEMPERATURE_HIGH alarm is raised when the CPU SSD temperature is high.

Clear the CPU_SSD-TEMPERATURE_HIGH Alarm Alarm

Procedure

The CPU_SSD-TEMPERATURE_HIGH alarm is cleared when the CPU SSD temperature returns to the normal range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CRYPTO_HW_FAILURE

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: Shelf

The CRYPTO_HW_FAILURE alarm is raised whenever any one of the line card port related KAT tests fail and the card is locked that prevents any card configurations.

Clear the CRYPTO_HW_FAILURE Alarm

Procedure

If the line card is locked and in failed state due to KAT errors, power-cycle the line card to restart the KAT process again. If it is successful, the system continues its regular operations else contact TAC for further assistance.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CRYPTO-INDEX-MISMATCH

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: OTN

The CRYPTO-INDEX-MISMATCH alarm is raised when the AN# of Rx on the near end node does not match the AN# of Tx on the far end node, or

the AN# of Tx on the near end node does not match with the AN# of Rx on the far end node.

Else, this alarm will be raised

Clear the CRYPTO-INDEX-MISMATCH Alarm

Procedure

The alarm is cleared when the index AN numbers match with the peer node.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

CRYPTO-KEY-EXPIRED

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: OTN

The CRYPTO-KEY-EXPIRED alarm is raised when a hardware programmed key expires and there is no new key available for rollover.

Clear the CRYPTO-KEY-EXPIRED Alarm

Procedure

The alarm is cleared after the new sak key is made available.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

DATAPATH-DEV-FAILURE Alarm

Default Severity: Major (MJ)

Logical Object: LC

The DATAPATH-DEV-FAILURE alarm is raised when the datapath FPGA fails to configure on the line card inserted, which will impact ports from 0 - 13.

Clear the DATAPATH-DEV-FAILURE Alarm

Reload the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

DGD Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Differential Group Delay (DGD) alarm is raised when the value of the differential group delay read by the pluggable port module exceeds the configured threshold value.

Clear the DGD Alarm

Procedure

Configure the threshold value within range if DGD value is not within the threshold range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

EQUIPMENT_FAILURE

Default Severity: Major/Minor (MJ/MI), Service-Affecting (SA) / Non Service-Affecting(NSA)

Logical Object: LC

The EQUIPMENT_FAILURE alarm is raised when an optical module, PLL device, CDR device, line card RAM device, line card, FPGA, or line card disk has failed.

Clear the EQUIPMENT_FAILURE Alarm

Procedure

This alarm is cleared when the failed device is recovers.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

EQUIPMENT-FAILURE Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object:

The EQUIPMENT-FAILURE alarm is raised because of one of these reasons:

- When the system fails to detect equipment on IO port 12.
- When the system fails to detect equipment on IO port 13.
- When a software sequence failure occurs on any port from 0 - 13, and it fails to turn on the motherboard successfully.

Clear the EQUIPMENT-FAILURE Alarm

Reload the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

FAN FAIL Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: ENVMON

The FAN FAIL alarm is raised on the NCS 1004 when one of the three fans fail. When any fan fails, the temperature of the NCS 1004 can rise above its normal operating range. This condition can trigger the TEMPERATURE alarm.

Clear the FAN FAIL Alarm

Procedure

Verify that a fan is correctly inserted. The fan should run immediately when correctly inserted.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

FAN-POWER-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: Environ

The FAN-POWER-ERROR alarm is raised when POWER to FT has failed.

Clear the FAN-POWER-ERROR Alarm

Procedure

This alarm is cleared when the power failure is recovered or OIR of the FT.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: Environ

The FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT alarm is raised when one or more fans in the fan tray are faulty.

Clear the FAN SPEED SENSOR 0: OUT OF TOLERANCE FAULT Alarm

Procedure

Replace the fans in the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

FAN-TRAY-REMOVAL Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: Environ

The FAN-TRAY-REMOVAL alarm is raised on the NCS 1004 when all the fan trays are removed from the chassis.

Clear the FAN-TRAY-REMOVAL Alarm

Procedure

Insert the fan trays into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

FPD IN NEED UPGD Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: ANY

The FPD IN NEED UPGD alarm is raised when the FPD image is not aligned with the available package version.

Clear the FPD IN NEED UPGD Alarm

Procedure

Upgrade the respective FPD with the **upgrade hw-module location 0/x fpd y** command.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

HIBER Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The High Bit Error Rate (HIBER) alarm is raised when the client and trunk ports receive 16 or more invalid sync-headers in 125 microseconds.

Clear the HIBER Alarm

Procedure

Step 1 Ensure the card port does not receive a high bit error rate.

Step 2 Clean the optical connectors.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

HI-LASERBIAS Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The HI-LASERBIAS alarm is raised when the physical pluggable port laser detects a laser bias value beyond the configured high threshold.

Clear the HI-LASERBIAS Alarm

Procedure

Configure the threshold value within range if high laser bias threshold value is not within the threshold range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

HI-RXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The HI-RXPOWER alarm occurs on the client optics controller when the measured individual lane optical signal power of the received signal exceeds the default or user-defined threshold. The HI-RXPOWER alarm occurs on the trunk optics controller when the total optical signal power of the received signal exceeds the default or user-defined threshold.

Clear the HI-RXPOWER Alarm

Procedure

Configure the high receive power threshold value in range. If the value is within the range of the high receive power threshold, physically verify, that the optical input power is overcoming the expected power threshold using a standard power meter.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

HI-TXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The HI-TXPOWER alarm occurs on the client optics controller when the measured individual lane optical signal power of the transmitted signal exceeds the default or user-defined threshold. The HI-TXPOWER alarm occurs on the trunk optics controller when the total optical signal power of the transmitted signal exceeds the default or user-defined threshold.

Clear the HI-TXPOWER Alarm

Procedure

Configure the high transmit power threshold in range. If the value is within the range of the high transmit power threshold, physically verify, that the optical output power is overcoming the expected power threshold using a standard power meter

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

IMPROPRMVL Alarm

Default Severity: Critical(CR), Service affecting (SA)

Logical Object: LC

The IMPROPRMVL Alarm is raised when the configured line card is physically removed from the chassis.

Clear the IMPROPRMVL Alarm Alarm

Procedure

The IMPROPRMVL Alarm is cleared when the line card is re-inserted into the chassis.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

IMPROPRMVL Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: PPM

The Improper Removal (IMPROPRMVL) alarm is raised when a physical pluggable is not present on a service-provisioned port.

Clear the IMPROPRMVL Alarm

Procedure

Insert the appropriate QSFP.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

INSTALL IN PROGRESS Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: Environ

The INSTALL IN PROGRESS alarm is raised when the install operation is in progress or if an install commit is not performed after activating a new image or package.

Clear the INSTALL IN PROGRESS Alarm

Procedure

Step 1 Wait until the install operation is over.

Step 2 Perform the "install commit" operation after the "install activate" operation.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BP-FPGA-PCIE-ERROR

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: SC

The BP-FPGA-PCIE-ERROR alarm is raised when the BP device goes out of the PCIe tree.

Clear the BP-FPGA-PCIE-ERROR Alarm

Procedure

This alarm is cleared when the BP device comes back to the PCIe tree.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BP-FPGA-IMAGE-CORRUPTION

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The BP-FPGA-IMAGE-CORRUPTION alarm is raised when the system detects the BP corruption and boots with the Golden image.

Clear the BP-FPGA-IMAGE-CORRUPTION Alarm

Procedure

This alarm is cleared after the BP corruption is corrected and reloaded.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

BP_FPGA_XR_EP-FPGA-PCIE-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The BP_FPGA_XR_EP-FPGA-PCIE-ERROR alarm is raised when the BP device XR end point goes out of the PCIe tree.

Clear the BP_FPGA_XR_EP-FPGA-PCIE-ERROR Alarm

Procedure

This alarm is cleared when BP device XR end point comes back to the PCIe tree.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LCMODE-CONFIG-CHANGED Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The LCMODE-CONFIG-CHANGED alarm is raised when the LC Mode configuration of the line card is changed.



Note This alarm is specific to OTN-XP line card on NCS 1004. It is not supported for 1.2T card.

Clear the LCMODE-CONFIG-CHANGED Alarm

Delete the existing configuration on the line card and reload the card.

LCMODE-CONFIG-INVALID Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The LCMODE-CONFIG-INVALID alarm is raised when the LC-MODE configuration is invalid for the chosen line card.



Note This alarm is specific to OTN-XP line card on NCS 1004. It is not supported for 1.2T card.

Clear the LCMODE-CONFIG-INVALID Alarm

Configure the line card with a configuration that is supported on the card.

LCMODE-NOT-CONFIG Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The LCMODE-NOT-CONFIG alarm is raised when the LC-MODE configuration is not successfully configured for the chosen line card.



Note This alarm is specific to OTN-XP Line card on NCS 1004. It is not supported for 1.2T card.

Clear the LCMODE-NOT-CONFIG Alarm

Configure the line card with a configuration that is supported on the card.

LC_BOOT_TIMEOUT Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: LC

The LC_BOOT_TIMEOUT Alarm is raised when the line card fails to boot in the expected amount of time or when the line card modules do not boot correctly.

Clear the LC_BOOT_TIMEOUT Alarm Alarm

Procedure

The LC_BOOT_TIMEOUT alarm is cleared when the line card successfully reboots.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LC-CPU-IMAGE-CORRUPTION

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The LC-CPU-IMAGE-CORRUPTION alarm is raised when the line card is booted with the Golden image.

Clear the LC-CPU-IMAGE-CORRUPTION Alarm

Procedure

This alarm is cleared when the line card boots with a proper CPU image.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LC-DP-IMAGE-CORRUPTION Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: EQPT

The LC-DP-IMAGE-CORRUPTION alarm is raised when the Datapath FPGA bootup with back up or golden image due to corruption of primary image.

Clear the LC-DP-IMAGE-CORRUPTION Alarm

Perform a force upgrade of DP FPD to load proper image to the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

TEMPERATURE Alarm

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: Environ

The TEMPERATURE alarm is raised when the temperature is not within the operating range.

Clear the TEMPERATURE Alarm

Procedure

This alarm clears when the temperature falls within the operating range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LC-OFFLINE-ERROR

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: LC

The LC-OFFLINE-ERROR alarm is raised when the LC app is disconnected due to lcapp crash, restart, or warm reload of lcapp.

Clear the LC-OFFLINE-ERROR Alarm

Procedure

This alarm is cleared if the LC app connects within one minute.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LC-SUDI-CERT-VERIFICATION-FAILURE Alarm

Default Severity: Major (MJ), Non-Service-Affecting (NSA)

Logical Object: LC

The LC-SUDI-CERT-VERIFICATION-FAILURE alarm is raised when the SUDI certificates are not programmed.

Clear the LC-SUDI-CERT-VERIFICATION-FAILURE Alarm

To clear the alarm, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LOCAL-FAULT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The LOCAL-FAULT alarm is raised when a local fault character sequence is received in the incoming MAC stream.

Clear the LOCAL-FAULT Alarm

Procedure

Verify that the port receives proper MAC streams from the far-end router or switch.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LO-RXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The LO-RXPOWER alarm is raised on the client or trunk optics controller when the measured individual lane optical signal power of the received signal falls below the default or user-defined threshold.

Clear the LO-RXPOWER Alarm

Procedure

Step 1 Configure low receive power threshold in range.

Step 2 or

Step 3 Verify that the trunk-rx port is cabled correctly, and clean the fiber connecting the faulty TXP/MXP card to the drop port of the DWDM card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LO-TXPOWER Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: PPM

The LO-TXPOWER alarm is raised on the client or trunk optics controller when the measured individual lane optical signal power of the transmitted signal falls below the default or user-defined threshold.

Clear the LO-TXPOWER Alarm

Procedure

Configure low transmit power threshold in range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

LOM Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: TRUNK

The Loss of Multiframe (LOM) alarm is raised when the MFAS overhead field is invalid for more than five frames and persists for more than three milliseconds.

Clear the LOM Alarm

Procedure

- Step 1** If the bit error rate (BER) threshold is correct and at the expected level, use an optical test set to measure the power level of the line to ensure it is within guidelines.
 - Step 2** If the optical power level is good, verify that optical receive levels are within the acceptable range.
 - Step 3** If the receive levels are good, clean the fibers at both ends according to site practice.
 - Step 4** If the condition does not clear, verify that a single-mode fiber is used.
 - Step 5** If the fiber is of the correct type, verify that a single-mode laser is used at the far-end node.
 - Step 6** Clean the fiber connectors at both ends for a signal degrade according to site practice.
 - Step 7** Verify that a single-mode laser is used at the far end.
 - Step 8** If the problem does not clear, the transmitter at the other end of the optical line could be failing and requires replacement.
- If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
-

LOS-P Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: TRUNK

The Loss of Signal Payload (LOS-P) alarm for the trunk layer indicates that the PPM does not receive any incoming payload signal. The purpose of the LOS-P alarm is to alert the user that optical power is not being received from the fiber. A common fault condition signaled by this alarm is a fiber cut. In this case, the payload and the overhead signals are not received.

In non-Optical Signal to Noise Ratio (OSNR) loaded links, the RX power threshold for LOS condition (as LOS is expected before the actual traffic) goes down approximately to -23 dBm.

Clear the LOS-P Alarm

Procedure

- Step 1** Verify that the trunk port is configured with the proper wavelength.

- Step 2** Verify whether there is a loss of received optical power. Compare the actual power levels with the expected power range.
- Step 3** Verify the fiber continuity to the port of NCS 1004 and fix the fiber connection.
- If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
-

MB_SSD_ATA-ERRORS Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: LC

The MB_SSD_ATA-ERRORS alarm is raised when the chassis SSD has ATA errors.

Clear the MB_SSD_ATA-ERRORS Alarm Alarm

Procedure

The MB_SSD_ATA-ERRORS alarm is cleared when the chassis SSD is replaced.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

MEA Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: PPM

The Mismatch Equipment Attributes (MEA) alarm for the PPM or QSFP is raised on a pluggable port when there is a mismatch in the configured client data rate and the supported QSFP physical data rate.

Clear the MEA Alarm

Procedure

-
- Step 1** Verify the supported physical data rate of the QSFP on NCS 1004 using the **show inventory** command.
- Step 2** Verify the configured client data rate on NCS 1004 using the **show hw-module slice** command.
- Step 3** If the above values do not match, insert the appropriate QSFP pluggable or configure the required client data rate.
- If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).
-

NODE-OBFL-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The NODE-OBFL-ERROR alarm is raised when there is an OBFL read or write failure for the NODE scope.

Clear the NODE-OBFL-ERROR Alarm

Procedure

This alarm is cleared when the OBFL flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

ODU-AIS Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The ODU-AIS alarm is raised on ODU controllers when there is an alarm on the upstream data.

Clear the ODU-AIS Alarm

Procedure

The ODU-AIS alarm clears when the alarm clears on the upstream data.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

ODU-BDI Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The Optical Data Unit Backward Defect Indication (ODU BDI) alarm is raised when there is a path termination error in the upstream data. This error is read as a BDI bit in the path monitoring area of the ODU controller.

Clear the ODU-BDI Alarm

Procedure

The ODU-BDI alarm clears when the path termination error clears on the upstream data.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

ODU-CSF Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The ODU-CSF alarm is raised when there is a failure of the client signal.

Clear the ODU-CSF Alarm

Procedure

This alarm clears when no alarm exists on the client port.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

ODU-IAE/BIAE

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The ODU-IAE/BIAE alarm is raised when there are incoming alignment errors on the upstream data.

Clear the ODU-IAE/BIAE Alarm

Procedure

This alarm is cleared when the alignment errors are cleared on the upstream data.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

ODU-LCK

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The Locked (ODU-LCK) signal is raised when an OTN interface is administratively locked out and not available to carry traffic.

Clear the ODU-LCK Alarm

Procedure

This alarm is cleared when the administrator releases the lock out on the OTN interface.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

ODU-OCI

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK-ODU

The Open Connection Indication (ODU-OCI) alarm is raised when there is no connection between the client and trunk ports.

Clear the ODU-OCI Alarm

Procedure

This alarm is cleared when the connection is created between the client and trunk ports.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OSNR Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Signal Noise Ratio (OSNR) alarm occurs when the measured OSNR falls below the threshold.

Clear the OSNR Alarm

Procedure

Step 1 Verify the value of the minimum acceptable OSNR value of NCS 1004 using the **show controller optics R/S/I/P** command.

Step 2 If the value is not within the OSNR threshold range, configure the minimum acceptable OSNR value using the **controller optics R/S/I/P osnr-low-threshold** command in the configuration mode. The range is 0 to 4000 (in units of 0.1db).

Step 3 If the value is within the range of the minimum acceptable OSNR, contact TAC .

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTNSEC-LOCALLY-SECURED

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: Software

The OTNSEC-LOCALLY-SECURED alarm is raised when the IKE session goes down and the OTNsec session is locally secured.

Clear the OTNSEC-LOCALLY-SECURED Alarm

Procedure

This alarm is cleared when the respective IKE session is up.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTUK-AIS

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK

An Alarm Indication Signal (AIS) signal communicates to the receiving node when the transmit node does not send a valid signal. AIS is not an error. The OTUK-AIS alarm is raised by the receiving node on each input when it detects the AIS instead of an actual signal.

Clear the OTUK-AIS Alarm

Procedure

This alarm will be cleared when the signal recovers.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTUK-BDI Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Transport Unit Backward Defect Indication (OTUK BDI) alarm is raised when there is a path termination error in the upstream data. This error is read as a BDI bit in the path monitoring area of the digital wrapper overhead.

Clear the OTUK-BDI Alarm

Procedure

Step 1 At the near-end node, use site practices to clean trunk transmitting fiber toward the far-end node and the client receiving fiber.

Step 2 At the far-end node, determine whether any OTUK-AIS condition, is present on the trunk rx port. If yes, inspect the trunk rx side on the near-end card (the one alarmed for OTUK-BDI) because the AIS bit must be inserted in that section.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTUK-LOF Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: TRUNK

The Optical Transport Unit Loss of Frame (OTUK-LOF) alarm is raised when a frame loss is detected by an invalid frame alignment in the received frames. This alarm indicates that the card has lost frame delineation on the input data. Loss of frame occurs when the optical transport unit overhead frame alignment (FAS) area is invalid for more than five frames and that the error persists more than three milliseconds.

This alarm is also raised when the FEC settings on the trunk ports of the source and destination cards are different.

Clear the OTUK-LOF Alarm

Procedure

Verify whether the FEC settings on the trunk ports of the source and destination cards are the same.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTUK-SD Alarm

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Transport Unit Signal Degrade (OTUK-SD) alarm is raised when the quality of signal is poor that the bit error rate on the incoming optical line exceeds the signal degrade threshold.

Clear the OTUK-SD Alarm

Procedure

Identify the cause for poor quality signal and resolve. This alarm typically indicates poor incoming signal strength due to bad fiber or dirt in the pluggable or fiber.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTUK-SF Alarm

Default Severity: Not Alarmed (NA), Non Service-Affecting (NSA)

Logical Object: TRUNK

The Optical Transport Unit Signal Fail (OTUK-SF) is raised on hardware and software when LOS, LOF, and LOM alarms exist.

Clear the OTUK-SF Alarm

Procedure

The alarm is cleared when the LOS, LOF, or LOM alarms are cleared.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTUK-TIM Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: TRUNK

The Trail Trace Identifier Mismatch (OTUK-TIM) alarm is raised when the expected TTI string does not match the received TTI string.

Clear the OTUK-TIM Alarm

Procedure

Identify the cause for different expected and received TTI strings and resolve. The TIM mismatch can be caused due to mismatch in fiber connections.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

OTN-XP-DP-FPD-PKG-MISSING Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: EQPT

The OTN-XP-DP-FPD-PKG-MISSING alarm is raised when the user tries to update DP FPD without installing the OTN-XP-DP-FPD software package.

Clear the OTN-XP-DP-FPD-PKG-MISSING Alarm

This alarm is cleared when you download and install the OTN-XP-DP-FPD package.

PEX_SWITCH_ACCESS_FAILURE Alarm

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: LC

The PEX_SWITCH_ACCESS_FAILURE Alarm is raised when the Chassis PEX PCIe switch is not accessible.

Clear the PEX_SWITCH_ACCESS_FAILURE Alarm Alarm

Procedure

The PEX_SWITCH_ACCESS_FAILURE Alarm is cleared when the PEX PCIe switch is accessible again. The chassis needs to be reloaded manually if it does not reload on its own in a few minutes.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

POWER MODULE OUTPUT DISABLED Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: PEM

The POWER MODULE OUTPUT DISABLED alarm is raised on the NCS 1004 when the power supply is disabled on the active PEM.

Clear the POWER MODULE OUTPUT DISABLED Alarm

Procedure

Enable the power supply.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

POWER-MODULE-REDUNDANCY-LOST Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: PEM

The POWER-MODULE-REDUNDANCY-LOST alarm is raised on the NCS 1004 under one of the following conditions.

- When power supply to PSU is removed.
- When PEM is removed from NCS 1004.

Clear the POWER-MODULE-REDUNDANCY-LOST Alarm

Procedure

This alarm clears when the user re-inserts the power supply or when the user connects the power cable again.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

PPM FAIL Alarm

Default Severity: Critical (CR), Service-Affecting (SA)

Logical Object: PPM

The PPM FAIL alarm is raised on the pluggable when a fault is detected in the PPM and the pluggable cannot be accessed.

Clear the PPM FAIL Alarm

Procedure

Replace the pluggable.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Provisioning Failed Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: LC

The Provisioning Failed alarm is raised when invalid configuration is configured on the controller; For example, configuring an invalid CD-min value on the optics controller.

Clear the Provisioning Failed Alarm

Procedure

Step 1 Verify whether the provisioning configurations are supported for the line card.

Step 2 Change it to supported configurations for the line card.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

PROVISIONING-INCOMPAT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: LC

The PROVISIONING-INCOMPAT alarm is raised when you configure incompatible submarine parameters on 1.2T line card.

Clear the PROVISIONING-INCOMPAT Alarm

Procedure

The alarm is cleared only when valid submarine parameters are provided.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

Provisioning in Progress Alarm

Default Severity: Minor (MN), Non-Service-Affecting (NSA)

Logical Object: LC

The Provisioning in Progress alarm is raised when the provisioning request is in progress on the line card or controller.

Clear the Provisioning in Progress Alarm

Procedure

Step 1 Verify the status of the alarm using the following debug command:

```
RP/0/RP0/CPU0:ios#show hw-module location '<0/n>' mxponder
```

Step 2 Wait till the status changes to **Provisioned**.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

RACK-OBFL-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The RACK-OBFL-ERROR alarm is raised when there is an OBFL read or write failure for the RACK scope.

Clear the RACK-OBFL-ERROR Alarm

Procedure

This alarm is cleared when the OBFL flash access is restored.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

REMOTE-FAULT Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The REMOTE-FAULT alarm is raised on the NCS 1004 when a remote fault character sequence is received in the incoming MAC stream.

Clear the REMOTE-FAULT Alarm

Procedure

Step 1 Verify and resolve the client port fault and remote fault errors on the remote or upstream node.

Step 2 Verify and resolve loss of signal synchronization error on the remote or upstream node.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

RUNNING FANS AT MAX SPEED Alarm

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: environ

The RUNNING FANS AT MAX SPEED alarm is raised when one or more line cards are missing or when one or more fans fail or are removed or when the temperature exceeds threshold values.

Clear the RUNNING FANS AT MAX SPEED Alarm

Procedure

Step 1 Insert line card or filler card in all the slots.

Step 2 Insert all the fan trays and ensure all are working.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

SIGLOSS Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The Signal Loss on Data Interface (SIGLOSS) alarm is raised on the client-side QSFP when there is a loss of ethernet signal.

Clear the SIGLOSS Alarm

Procedure

Step 1 Ensure that the port connection at the near end of the client peer router is operational.

Step 2 Verify fiber continuity to the port.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

SQUELCHED Alarm

Default Severity: Not Alarmed (NA), Non-Service-Affecting (NSA)

Logical Object: CLIENT

Laser-squelch is configured under the client controller. Laser-squelching occurs on a QSFP pluggable when all the four lanes operating in the 10GE client mode are turned off after the upstream receive facility has experienced a loss of signal such as LOS or LOF.

Clear the SQUELCHED Alarm

Procedure

This alarm will be cleared when optical alarms clear.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

SYNCLOSS Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: CLIENT

The Loss of Synchronization on Data Interface (SYNCLOSS) alarm is raised on the client and trunk ports when there is a loss of signal synchronization on the port. This alarm is demoted by the SIGLOSS alarm.

Clear the SYNCLOSS Alarm

Procedure

Step 1 Ensure that the data port connection at the near end of the ethernet link is operational.

Step 2 Verify the fiber continuity to the port. To do this, follow site practices.

Step 3 For 100 GE, verify that the FEC settings match between the router.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

UNC-WORD Alarm

Default Severity: Not Reported (NR), Non-Service-Affecting (NSA)

Logical Object: TRUNK

The Uncorrected FEC Word (UNC-WORD) condition is raised when the FEC is unable to correct the frame.

Clear the UNC-WORD Alarm

Procedure

Step 1 Ensure that the fiber connector for the card is completely plugged in.

Step 2 Ensure that the ports on the far end and near end nodes have the same port rates and FEC settings.

Step 3 If the BER threshold is correct and at the expected level, use an optical test set to measure the power level of the line to ensure it is within guidelines. For specific procedures to use the test set equipment, consult the manufacturer.

Step 4 If the optical power level is good, verify that the optical receive levels are within the acceptable range.

Step 5 If receive levels are good, clean the fibers at both ends.

Step 6 If the condition does not clear, verify that a single-mode fiber is used.

Step 7 Verify if the fiber is of single-mode type.

Step 8 Clean the fiber connectors at both ends for a signal degrade.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

USB_OC_1

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The USB_OC_1 alarm is raised when the over current is observed on USB1.

Clear the USB_OC_1 Alarm

Procedure

This alarm is cleared when the over current is removed for the USB.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

USB_OC_0

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: RP

The USB_OC_0 alarm is raised when the over current is observed on USB0.

Clear the USB_OC_0 Alarm

Procedure

This alarm is cleared when the over current is removed for the USB.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

VOLTAGE Alarm

Default Severity: Critical (CR) , Service-Affecting (SA)

Logical Object: environ

The VOLTAGE alarm is raised on the NCS 1004 when the voltage is not within the operating range.

Clear the VOLTAGE Alarm

Procedure

This alarm clears when the voltage falls within the operating range.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

WVL-OUT-OF-LOCK Alarm

Default Severity: Major (MJ), Service-Affecting (SA)

Logical Object: TRUNK

The Wavelength Out of Lock (WVL-OUT-OF-LOCK) alarm is raised when the trunk port detects the optical input frequency to be out of range.

Clear the WVL-OUT-OF-LOCK Alarm

Procedure

Step 1 Verify the wavelength configuration.

Step 2 Verify whether the pluggable is inserted properly.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).

XGE-FLASH-ERROR

Default Severity: Major (MJ), Non Service-Affecting (NSA)

Logical Object: SC

The XGE-FPGA-ERROR alarm is raised when the XGE FPGA SPI flash is not accesible.

Clear the XGE-FLASH-ERROR Alarm

Procedure

This alarm is cleared when the XGE FPGA SPI Flash error is corrected.

If the alarm does not clear, log into the Technical Support Website at <http://www.cisco.com/c/en/us/support/index.html> for more information or call Cisco TAC (1 800 553-2447).



Americas Headquarters
Cisco Systems, Inc.
San Jose, CA 95134-1706
USA

Asia Pacific Headquarters
CiscoSystems(USA)Pte.Ltd.
Singapore

Europe Headquarters
CiscoSystemsInternationalBV
Amsterdam,TheNetherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.